Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY QYSY-AKTV3222T

ALLIMITY Replacement Remote Control for Akai TVs: Instruction Manual

Brand: ALLIMITY | Model: QYSY-AKTV3222T

1. Introduction

This manual provides instructions for the ALLIMITY replacement remote control, designed to operate various Akai television models. This remote offers full functionality without the need for complex programming, serving as a direct replacement for your original remote.
Please read this manual carefully to ensure proper setup and operation of your new remote control.

2. Setup

2.1 Battery Installation

The remote control requires two AAA alkaline batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off.
3. Insert two AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Back view of the ALLIMITY remote control, illustrating the battery compartment location.

Important: Always replace both batteries at the same time. Do not mix old and new batteries, or different types of batteries.

2.2 Initial Operation

This ALLIMITY replacement remote control is pre-programmed for compatible Akai TV models. No additional programming or setup is required. Once batteries are installed, the remote is ready for immediate use with your television.

3. Operating the Remote Control

3.1 Remote Control Layout

The following image illustrates the layout of the ALLIMITY remote control and its various buttons.




P.MODE
S.MODE
FREEZE
TXT
FAV.LIST
SUBTITLE
AUDIO
ZOOM
MIX
SIZE
CANCEL
INDEX
HOLD
REVEAL
SUBPAGE
MENU
EXIT
ENTER
PLAY/PAUSE
STOP
MUTE
VOL
TV/RADIO
CH
1
2
3
4
5
6
7
8
9
DISPLAY
RECALL
0



Image: Front view of the ALLIMITY remote control, highlighting all functional buttons.

3.2 Button Functions

Below is a list of common button functions:

- **STANDBY (Red Button):** Powers the TV on or off.
- **SOURCE:** Selects input sources (e.g., HDMI, AV).
- **P.MODE:** Picture Mode selection.
- **S.MODE:** Sound Mode selection.
- **FREEZE:** Freezes the current image on screen.
- **TXT:** Accesses Teletext.
- **FAV.LIST:** Displays favorite channels list.
- **SUBTITLE:** Toggles subtitles on/off.
- **AUDIO:** Selects audio tracks or languages.
- **ZOOM:** Adjusts screen zoom level.
- **MIX:** Teletext mix function.
- **SIZE:** Teletext size adjustment.
- **CANCEL:** Cancels current operation or exits a menu.
- **RECORD (Red Dot):** Initiates recording (if supported by TV and connected device).
- **SUBPAGE:** Navigates Teletext subpages.
- **INDEX:** Teletext index page.
- **HOLD:** Holds Teletext page.
- **REVEAL:** Reveals hidden Teletext information.
- **MENU:** Opens the main TV menu.
- **Navigation Buttons (Up, Down, Left, Right, ENTER):** Navigates through menus and confirms selections.
- **EXIT:** Exits the current menu or function.
- **PLAY/PAUSE, STOP, Fast Forward, Rewind, Skip:** Media playback controls.
- **VOL +/-:** Adjusts volume level.
- **MUTE:** Mutes or unmutes the TV sound.
- **TV/RADIO:** Switches between TV and Radio modes.
- **CH ^/v:** Changes channels up or down.
- **Number Buttons (0-9):** Direct channel selection.
- **DISPLAY:** Displays current channel information.
- **RECALL:** Returns to the previously viewed channel.

4. Compatible Models

This ALLIMITY remote control is compatible with the following Akai TV models:

- AKTV4023T-SMART
- AKTV4023
- AKTV3222T
- AKT3222T
- IP-LE410983
- IP-LE32/410004

- AKTV2419J-SAT
- AKTV2212TS
- AKTV5512TS
- AKTV403TS
- AKTV221
- AKTV551

If your Akai TV model is listed above, this remote control should function correctly without any additional configuration.

5. Troubleshooting

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote not responding:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Ensure you are within the effective operating range (up to 10 meters) and pointing the remote directly at the TV.
- **Some buttons not working:**
  - This remote is designed to cover all functions of your original remote. If a specific button does not work, verify if your TV model supports that function.
  - Clean the remote control's surface and buttons with a soft, dry cloth to remove any dirt or residue.
- **Intermittent operation:**
  - Weak batteries can cause intermittent operation. Replace them.
  - Strong light sources (e.g., direct sunlight, fluorescent lights) can interfere with the infrared signal. Try operating the remote in a different lighting condition.

6. Specifications

Brand	ALLIMITY
Model Number	QYSY-AKTV3222T
Color	Grey
Connectivity Technology	Infrared
Compatible Devices	Akai TVs (AKTV4023T-SMART, AKTV4023, AKTV3222T, AKT3222T, IP-LE410983, IP-LE32/410004, AKTV2419J-SAT, AKTV2212TS, AKTV5512TS, AKTV403TS, AKTV221, AKTV551)
Maximum Range	10 Meters
Battery Type	Alkaline (AAA)
Number of Buttons	45

7. Warranty and Support

For any questions, concerns, or support regarding your ALLIMITY replacement remote control, please contact the seller or retailer from whom you purchased the product. Please refer to your purchase documentation for specific warranty information, as it may

vary by region and retailer.

© 2023 ALLIMITY. All rights reserved. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CBRSWWWX

More documents and user manuals: **https://manuals.plus/**