CG MOBILE GUBH604GE

GUESS BT 4G PU LEATHER W/SCRIPT METAL LOGO - BLUE Wireless Headphones User Manual

Model: GUBH604GE

1. Introduction

Thank you for choosing the GUESS BT 4G PU LEATHER W/SCRIPT METAL LOGO - BLUE Wireless Headphones. This manual provides essential information for setting up, operating, and maintaining your new headphones. Please read it carefully before use to ensure optimal performance and longevity of your device.

2. Product Overview

The GUESS BT 4G Wireless Headphones offer high-quality audio with a comfortable design, featuring Bluetooth 5.3 connectivity for seamless wireless listening.

2.1. Package Contents

- GUESS BT 4G Wireless Headphones
- Charging Cable
- User Manual (this document)

2.2. Headphone Components and Controls



Figure 2.1: Front view of the GUESS BT 4G Wireless Headphones, showcasing the blue earcups and gold accents.



Figure 2.2: Side view of the headphones, highlighting the control buttons and DC IN charging port.



Figure 2.3: Product packaging displaying key features, specifications, and control button functions.

Control Button Functions:

- **Volume Up** / **Next Track:** Short press for volume up, long press for next track.
- **Volume Down** / **Previous Track:** Short press for volume down, long press for previous track.
- **Power** / **Play/Pause** / **Call Control:** Press and hold to power on/off. Short press to play/pause music. Answer/end calls with a short press.
- **Connect** / **Disconnected:** Button for Bluetooth pairing and connection management.

3. Setup

3.1. Charging the Headphones

Before first use, fully charge your headphones. Connect the charging cable to the DC IN port on the headphones and the other end to a USB power source (e.g., computer USB port, USB wall adapter).

- **Charging Time:** Approximately 2 hours for a full charge.

3.2. Bluetooth Pairing

To connect your headphones to a Bluetooth-enabled device (smartphone, tablet, computer):

1. Ensure the headphones are powered off.
2. Press and hold the Power button until the indicator light flashes, indicating pairing mode.
3. On your device, enable Bluetooth and search for available devices.
4. Select "GUESS BT 4G" (or similar name) from the list of found devices.
5. Once connected, the indicator light on the headphones will change (e.g., solid blue or off), and you may hear a

confirmation tone.

6. If prompted for a password, enter "0000".

The headphones will automatically attempt to reconnect to the last paired device when powered on.

4. Operating Instructions

4.1. Power On/Off

- **Power On:** Press and hold the Power button for approximately 3 seconds.
- **Power Off:** Press and hold the Power button for approximately 3 seconds.

4.2. Music Playback

- **Play/Pause:** Short press the Power button.
- **Volume Up:** Short press the "Volume Up / Next Track" button.
- **Volume Down:** Short press the "Volume Down / Previous Track" button.
- **Next Track:** Long press the "Volume Up / Next Track" button.
- **Previous Track:** Long press the "Volume Down / Previous Track" button.

4.3. Call Management

- **Answer/End Call:** Short press the Power button during an incoming call.
- **Reject Call:** Press and hold the Power button during an incoming call.
- **Redial Last Number:** Double-press the Power button.

5. Maintenance

- Clean the headphones with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the headphones to extreme temperatures, humidity, or direct sunlight.
- Store the headphones in a cool, dry place when not in use.
- Do not attempt to disassemble or repair the headphones yourself, as this will void the warranty.

6. Troubleshooting

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair with device.	Headphones not in pairing mode; Bluetooth off on device; device too far.	Ensure headphones are in pairing mode. Turn on Bluetooth on your device. Move device closer to headphones (within 10 meters).
No sound or low volume.	Volume too low on headphones or device; not properly connected.	Increase volume on both headphones and connected device. Re-pair the headphones.

Problem	Possible Cause	Solution
Sound distortion.	Interference; device too far; low battery.	Move away from sources of interference. Move device closer. Charge headphones.

7. Specifications

Feature	Detail
Model Number	GUBH604GE
Product Dimensions	3.94 x 1.18 x 0.79 inches
Weight	3.53 ounces
Bluetooth Version	V5.3
Wireless Range	Up to 10 meters (33 feet)
Frequency Response	20Hz - 20KHz
Sensitivity	102 +/- 3 dB
Impedance	32 ohm +/- 15%
DC Input	5V / 100mA
Battery Type	1 Lithium Ion (3.7V / 250 mAh)
Charging Time	Approximately 2 hours
Play Time	Approximately 10 hours
Country of Origin	China

8. Warranty and Support

This product is manufactured by CG MOBILE. For warranty information and technical support, please contact CG MOBILE directly through their official website or customer service channels. Please retain your proof of purchase for warranty claims.
For more information, you may visit theCG MOBILE Store on Amazon.

© 2024 CG MOBILE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question