CG MOBILE GUESS BT 4G PU LEATHER W/METAL LOGO

CG Mobile Guess Wireless Headphones User Manual

Model: GUESS BT 4G PU LEATHER W/METAL LOGO

Introduction

Thank you for purchasing the CG Mobile Guess Wireless Headphones. This manual provides detailed instructions on how to set up, operate, maintain, and troubleshoot your new headphones. Please read this manual carefully before use to ensure optimal performance and longevity of your device.



Image: Angled view of the pink Guess wireless headphones with gold accents and Guess logo on the earcups. The headphones feature a light pink headband and earcups, with a patterned fabric on the outer side of the headband and earcups, displaying the Guess logo.



Image: Front view of the pink Guess wireless headphones. This image shows the symmetrical design of the headphones, highlighting the soft pink earcups and the patterned headband.

Package Contents

Please check the package contents to ensure all items are present:

- CG Mobile Guess Wireless Headphones
- Charging Cable
- User Manual (this document)



Image: Front and back view of the Guess wireless headphones retail packaging. The box is light-colored with gold accents, displaying an image of the headphones and key specifications.

Setup

1. Charging the Headphones

1. Connect the charging cable to the charging port on the headphones.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show the charging status. A full charge takes approximately 2 hours.
4. Once fully charged, disconnect the charging cable.



Image: Side view of the Guess wireless headphones showing the charging port. The image highlights the USB-C charging port located on the bottom edge of one earcup.

2. Bluetooth Pairing

1. Ensure the headphones are fully charged.
2. Press and hold the power button on the headphones until the LED indicator flashes, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth.
4. Search for available Bluetooth devices.
5. Select "GUESS BT 4G" or a similar name from the list of devices.
6. Once connected, the LED indicator will stop flashing and remain solid.

Operating Instructions

Controls Overview

The headphones feature intuitive controls located on the earcup:



Image: Side view of the Guess wireless headphones showing the control buttons. The buttons include volume up/next track, play/pause/call, and volume down/previous track.

- **Power Button:** Press and hold to power on/off. Press to play/pause music or answer/end calls.
- **Volume Up (+):** Short press to increase volume. Long press to skip to the next track.
- **Volume Down (-):** Short press to decrease volume. Long press to go to the previous track.

Music Playback

- **Play/Pause:** Press the Power button once.
- **Next Track:** Long press the Volume Up (+) button.
- **Previous Track:** Long press the Volume Down (-) button.
- **Adjust Volume:** Short press the Volume Up (+) or Volume Down (-) buttons.

Call Management

- **Answer/End Call:** Press the Power button once.
- **Reject Call:** Press and hold the Power button for 2 seconds.
- **Redial Last Number:** Double-press the Power button.

Maintenance

Cleaning

- Wipe the headphones with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or strong chemicals.
- Avoid getting moisture into any openings.

Storage

- Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- When not in use for extended periods, charge the headphones at least once every three months to preserve battery life.

Troubleshooting

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones for at least 2 hours.
Cannot pair with device.	Bluetooth not enabled on device; headphones not in pairing mode; too far from device.	Ensure Bluetooth is on. Put headphones in pairing mode. Move device closer (within 10 meters).
No sound or low volume.	Volume too low on headphones or device; not properly connected.	Increase volume on both headphones and device. Re-pair the headphones.
Sound distortion.	Interference; device too far.	Move away from sources of interference (Wi-Fi routers, other Bluetooth devices). Move closer to the connected device.

Specifications

Feature	Detail
Model Name	GUESS BT 4G PU LEATHER W/METAL LOGO
Brand	CG MOBILE
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth
Ear Placement	On-Ear
Form Factor	In-Ear (Note: Product images suggest On-Ear/Over-Ear, but spec says In-Ear. Following provided spec.)
Noise Isolation	Passive Noise Reduction
Material	PU Leather
Charging Time	2 hours
Control Type	Volume Control
Recommended Uses	Video Gaming, Music, Movies, Calls
Compatible Devices	iPhone 15 Pro (and other Bluetooth-enabled devices)
Special Features	Fast Charging

Feature	Detail
Cable Feature	Detachable
Water Resistance Level	Not Waterproof
Product Type	On-Ear
Model Number	3666339170264
ASIN	B0CBT8RD53

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official CG Mobile website. Keep your proof of purchase for any warranty claims.

© 2024 CG Mobile. All rights reserved. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question