Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SPPRANDOM V20

SPPRANDOM V20 2.7K 42MP Camcorder Video Camera User Manual

Model: V20

1. Introduction

Thank you for purchasing the SPPRANDOM V20 2.7K 42MP Camcorder. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference. The SPPRANDOM V20 is a digital video camera designed for capturing high-quality video and still images. It features 2.7K video resolution, 42MP photo resolution, an 18X digital zoom, a 3.0-inch LCD screen, and an integrated LED fill light. A remote controller is included for convenient operation.

2. Safety Information

- Do not expose the camcorder to water or moisture.
- Avoid dropping the device or subjecting it to strong impacts.
- Keep out of reach of children.
- Use only the specified power adapter and batteries.
- Do not attempt to disassemble or modify the camcorder.
- Clean the lens with a soft, dry cloth.

3. Package Contents

Verify that all items are present in the package:

- SPPRANDOM V20 Camcorder
- Remote Controller
- USB Cable
- User Manual (this document)
- *(Note: Batteries and SD card may be included depending on the specific package variant.)*

4. Setup

4.1. Charging the Battery

Insert the battery into the camcorder. Connect the camcorder to a power source using the provided USB cable and a compatible USB power adapter (not always included). The charging indicator will illuminate during charging and turn off when fully charged.

4.2. Inserting an SD Card

The camcorder requires an SD card (not included) for storing photos and videos. Open the SD card slot cover and insert the SD card with the metal contacts facing the front of the camcorder until it clicks into place. Ensure the card is formatted before first use (refer to Section 5.3).



Figure 1: SPPRANDOM V20 Camcorder. This image shows the camcorder with its LCD screen open, revealing the controls and lens.

5. Operating the Camcorder

5.1. Power On/Off

Press and hold the **Power** button to turn the camcorder on or off. The LCD screen will illuminate.

5.2. Recording Video

1. Turn on the camcorder.
2. Ensure the mode is set to video recording (usually indicated by a camera icon).
3. Press the **Record** button to start recording. A red indicator light will typically flash.
4. Press the **Record** button again to stop recording.

5.3. Taking Photos

1. Turn on the camcorder.
2. Switch to photo mode (usually indicated by a still camera icon).
3. Frame your shot using the LCD screen.
4. Press the **Shutter** button to take a photo.

5.4. Using Digital Zoom

Use the **W (Wide)** and **T (Telephoto)** buttons on the camcorder or remote control to adjust the 18X digital zoom. Note that digital zoom can reduce image quality at higher magnifications.

5.5. LED Fill Light

The integrated LED fill light can be activated in low-light conditions. Refer to the on-screen menu for options to turn the light on/off or adjust its intensity.

5.6. Playback

To view recorded videos or photos, switch to playback mode. Use the navigation buttons to browse through your media. Press the **OK** or **Play** button to view a selected item.

5.7. Connecting to a Computer

Connect the camcorder to your computer using the provided USB cable. The camcorder will appear as a removable disk, allowing you to transfer files. Ensure the camcorder is powered on during connection.

6. Maintenance

6.1. Cleaning

- Use a soft, lint-free cloth to clean the camcorder body.
- For the lens, use a specialized lens cleaning cloth and solution. Avoid touching the lens surface with your fingers.
- Do not use harsh chemicals or abrasive cleaners.

6.2. Storage

When not in use, store the camcorder in a cool, dry place away from direct sunlight and extreme temperatures. Remove the battery if storing for extended periods.

7. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Camcorder does not power on.	Battery is depleted or not inserted correctly.	Charge the battery. Ensure the battery is inserted with correct polarity.
Cannot record video/take photos.	SD card is full, not inserted, or not formatted.	Insert an SD card. Delete unnecessary files. Format the SD card (this will erase all data).
Poor video/photo quality.	Low light conditions, dirty lens, excessive digital zoom.	Use the LED fill light. Clean the lens. Avoid using maximum digital zoom. Ensure adequate lighting.
Remote control not working.	Battery in remote is depleted or not inserted correctly. Obstruction between remote and camcorder.	Replace remote battery. Ensure clear line of sight to the camcorder's IR receiver.

8. Specifications

Feature	Detail
Model	V20
Video Resolution	2.7K
Photo Resolution	42MP
Digital Zoom	18X
Screen Size	3.0 Inches LCD
Flash Memory Type	SD Card (up to 128GB, Class 10 recommended)
Maximum Aperture	3.2 f
Product Dimensions	6.5 x 5.3 x 3.1 inches
Item Weight	1.15 pounds
Included Components	Camcorder, Remote Controller, USB Cable, User Manual

9. Warranty and Support

SPPRANDOM products are covered by a limited warranty. For detailed warranty information, please refer to the warranty card included in your package or visit the official SPPRANDOM website. For technical support or customer service inquiries, please contact our support team via the contact information provided on our website or your purchase platform. Please have your model number (V20) and purchase date available when contacting support.

© 2023 SPPRANDOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CBTT6CJL

More documents and user manuals: **https://manuals.plus/**