Russell Hobbs 27290-56

Russell Hobbs SatisFry Snappi Dual Basket Air Fryer Instruction Manual

Model: 27290-56

1. Important Safety Information

Please read and understand all instructions before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is placed on a stable, heat-resistant surface, away from walls and other appliances, to allow adequate air circulation.
- Do not immerse the main unit, cord, or plug in water or any other liquid.
- Keep children and pets away from the appliance during operation. The exterior surfaces can become hot.
- Do not block any air vents.
- Unplug the appliance from the outlet when not in use and before cleaning. Allow it to cool completely before handling.
- Do not operate the appliance if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any way.
- Only use accessories recommended by the manufacturer.
- This appliance is for household use only. Do not use outdoors.
- Exercise extreme caution when removing the baskets or disposing of hot grease.

2. Product Overview

The Russell Hobbs SatisFry Snappi Dual Basket Air Fryer is designed for healthier cooking with little to no

oil. It features two independent cooking zones, allowing you to cook different foods at different temperatures and times simultaneously, or combine them into one large cooking zone.



Image: The Russell Hobbs SatisFry Snappi Dual Basket Air Fryer, showcasing its sleek black design, digital control panel, and two pull-out baskets.

Components:



Image: All components of the SatisFry Snappi Air Fryer laid out, including the main unit, two cooking baskets, two crisping plates, and the removable divider for single large basket use.

- **Main Unit:** Houses the heating element and control panel.
- **Cooking Baskets (x2):** Removable, non-stick baskets for holding food.
- **Crisping Plates (x2):** Insert into the baskets to allow air circulation and crisping.
- **Removable Divider:** Used to convert two smaller baskets into one large cooking zone.
- **Digital Touch Control Panel:** For setting time, temperature, and selecting programs.

3. Setup and First Use

Unpacking and Initial Cleaning:

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Wash the cooking baskets and crisping plates in warm, soapy water. Rinse thoroughly and dry completely. These parts are also dishwasher safe.
3. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.

Assembling the Baskets:

The SatisFry Snappi offers flexible cooking options: two independent baskets or one large basket.

Using Two Independent Baskets:

1. Ensure the removable divider is not installed.
2. Place one crisping plate into each cooking basket. Ensure it sits flat at the bottom.
3. Slide both assembled baskets into the main unit until they click securely into place.



Images: Left: A hand sliding one of the cooking baskets into the air fryer. Right: Hands sliding both cooking baskets into the air fryer, demonstrating the dual basket setup.

Using One Large Basket (8.5L Capacity):

1. Remove both cooking baskets from the main unit.
2. Insert the removable divider into the slot between the two basket compartments. Ensure it is firmly seated.
3. Place both crisping plates into the now combined large cooking zone.
4. Slide the combined large basket into the main unit until it clicks securely.



Images: Left: A hand inserting the removable divider into the air fryer to create a single large cooking zone. Right: The divider fully inserted, showing the unified cooking space.



Images: Left: Hands demonstrating the assembly of the baskets with the divider for single large zone use. Right: Hands demonstrating the disassembly of the baskets and divider.

Before First Use:

It is recommended to run the air fryer empty for about 10-15 minutes on a high temperature (e.g., 180°C) to burn off any manufacturing residues. A slight odor may be present, which is normal and will dissipate.

4. Operating Instructions

Control Panel:

The digital touch control panel allows for easy operation. It features a white LED display and various touch icons for functions.



Image: Close-up of the Russell Hobbs SatisFry Snappi control panel, showing the digital display and touch icons for dual basket operation.

- **Power Button:** Turns the appliance on/off.
- **Temperature Control:** Adjusts temperature from 30°C to 200°C in 5°C increments.
- **Time Control:** Adjusts cooking time.
- **Preset Programs (M button):** Cycles through 8 pre-defined cooking programs.
- **Basket 1** / **Basket 2 Selectors:**Activates controls for individual baskets.
- **SYNC Button:** Synchronizes cooking times for both baskets to finish simultaneously.
- **Add Food Reminder:** Indicates when to add food to a basket if cooking in stages.
- **Shake Reminder:** Prompts to shake or turn food halfway through cooking.

Cooking with Preset Programs:

The air fryer comes with 8 convenient preset programs for common foods:

1. Place food in the basket(s).
2. Press the Power button to turn on the appliance.
3. Press the 'M' button repeatedly to cycle through the preset programs (Fries, Fish, Egg, Chicken, Bake, Steak, Dehydrate, Vegetables).
4. Once the desired program is selected, the default time and temperature will display. You can adjust these manually if needed.
5. Press the Start/Pause button to begin cooking.



Image: The Russell Hobbs SatisFry Snappi Air Fryer in a kitchen setting, with one basket containing corn on the cob and chicken wings, and the other basket filled with golden fries, demonstrating its dual cooking capability.

Manual Cooking:

1. Place food in the basket(s).
2. Press the Power button.
3. Use the Temperature control buttons to set the desired temperature.
4. Use the Time control buttons to set the desired cooking time.
5. Press the Start/Pause button to begin cooking.

Using Dual Baskets and SYNC Function:

When using two independent baskets, you can set different programs or manual settings for each. The SYNC function ensures both baskets finish cooking at the same time, even if they started with different cooking durations.

1. Load food into Basket 1 and Basket 2.
2. Select Basket 1 on the control panel. Set its desired cooking program/time/temperature.
3. Select Basket 2 on the control panel. Set its desired cooking program/time/temperature.
4. Press the SYNC button. The air fryer will automatically adjust the start time of the basket with the shorter cooking duration so both finish together.
5. Press Start/Pause to begin.



Image: The Russell Hobbs SatisFry Snappi Air Fryer on a kitchen counter, surrounded by various cooked dishes like muffins, chicken, and vegetables, showcasing the versatility of the appliance.

Add Food Reminder:

For certain recipes or cooking methods, the air fryer may prompt you to add food at a specific point. Follow the on-screen indicator and add the remaining ingredients as instructed.

Shake Reminder:

Some foods, like fries or chicken nuggets, benefit from being shaken or turned halfway through cooking for even crisping. The air fryer will beep and display a "SHAKE" reminder. Carefully remove the basket(s), shake or turn the food, and reinsert the basket(s) to resume cooking.

5. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the life of your air fryer.

Daily Cleaning:

1. Always unplug the air fryer and allow it to cool completely before cleaning.
2. Remove the cooking baskets and crisping plates. Wash them in warm, soapy water using a non-

abrasive sponge. They are also dishwasher safe.

3. Wipe the interior of the main unit with a damp cloth. For stubborn residue, use a mild detergent.
4. Wipe the exterior of the main unit and control panel with a soft, damp cloth.
5. Ensure all parts are thoroughly dry before reassembling or storing.

Deep Cleaning:

- For baked-on food, soak the baskets and crisping plates in warm, soapy water for about 15-20 minutes before cleaning.
- Do not use abrasive cleaning materials or metal scouring pads, as these can damage the non-stick coating.

6. Troubleshooting

If you encounter issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet issue; basket not fully inserted.	Ensure the power cord is securely plugged into a working outlet. Push baskets firmly until they click into place.
Food is not cooked evenly.	Basket overloaded; food not shaken/turned; incorrect temperature/time.	Do not overload baskets. Shake or turn food halfway through cooking. Adjust temperature and time as needed for specific foods.
White smoke coming from the appliance.	Grease residue from previous use; high-fat food.	Clean the baskets and interior thoroughly. For high-fat foods, drain excess fat during cooking.
Food is not crispy.	Too much moisture; not enough oil (if desired); basket overloaded.	Pat food dry before air frying. Lightly coat with oil for extra crispiness. Cook in smaller batches if necessary.
Appliance emits a burning smell.	Food stuck to heating element; new appliance smell.	Unplug and allow to cool. Check for and remove any food debris from the heating element. Initial burning smell is normal for first few uses.

If the problem persists after trying these solutions, please contact Russell Hobbs customer support.

7. Specifications

Feature	Detail
Brand	Russell Hobbs
Model Number	27290-56
Color	Black

Feature	Detail
Capacity	8.5 Litres (total), 4.25 Litres per basket
Power	1800 Watts
Voltage	180 Volts
Material	Plastic and Aluminum
Dimensions (L x W x H)	41.2 x 32.2 x 38.5 cm
Weight	6.88 Kilograms
Temperature Range	30°C to 200°C
Special Features	Temperature Control, Dual Compartment, Dual Zone Functionality, Timer, Programmable, Add Food Reminder, Shake Reminder, Sync Cook Times

8. Warranty and Support

Russell Hobbs products are manufactured to strict quality standards. This product comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.
For technical support, troubleshooting assistance, or to inquire about spare parts, please visit the official Russell Hobbs website or contact their customer service department. Keep your proof of purchase for warranty claims.
Online Resources:

- Official Russell Hobbs Website: www.russellhobbs.com
- Product Support Page (if available): Check the Russell Hobbs website for a dedicated support page for model 27290-56.

Customer Service:
Refer to your product packaging or the Russell Hobbs website for regional customer service contact information (phone numbers, email addresses).