Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

FoMup FM17S

FoMup 17-inch 126-Can Beverage Refrigerator Instruction Manual

Model: FM17S

Introduction Safety Information Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the FoMup 17-inch 126-Can Beverage Refrigerator, Model FM17S. This appliance is designed to provide efficient and quiet cooling for your beverages, offering both freestanding and counter-top installation options. Please read this manual thoroughly before installation and operation to ensure proper use and maintenance.



Image 1.1: Front view of the FoMup 17-inch 126-Can Beverage Refrigerator, showcasing its sleek design and illuminated interior.

2. Important Safety Information

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not touch cold surfaces immediately after the appliance has been plugged in.
- Ensure the appliance is properly grounded.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Unplug the appliance before cleaning or performing any maintenance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. Package Contents

Verify that all items are present and in good condition:

- FoMup 17-inch 126-Can Beverage Refrigerator (Model FM17S)
- Adjustable Wire Shelves (3)
- Keys for Door Lock
- Instruction Manual

4. Setup Instructions

4.1 Unpacking

1. Remove all packaging materials, including foam and adhesive tape.
2. Inspect the appliance for any shipping damage. If damage is found, do not plug in the unit and contact customer service.
3. Clean the interior and exterior of the appliance with a soft, damp cloth before use.

4.2 Placement

This beverage refrigerator can be used as a freestanding unit or placed on a counter-top.

- **Ventilation:** Ensure adequate air circulation around the unit. Allow at least 2-4 inches of space on the sides and back, and 4 inches on top for proper ventilation. Blocking these openings can cause the compressor to overheat.
- **Level Surface:** Place the appliance on a flat, level, and sturdy surface to prevent vibrations and ensure proper door sealing. The adjustable feet can be used to level the unit.
- **Avoid Heat Sources:** Do not place the appliance near direct sunlight, heat sources (e.g., stoves, heaters), or in areas with extreme temperature fluctuations.
- **Electrical Requirements:** Ensure the power outlet meets the appliance's voltage requirements (115 Volts AC). Do not use extension cords.



Image 4.1: The beverage refrigerator displayed in both freestanding and counter-top setups, illustrating versatile placement options.



Image 4.2: Detail of the safety lock and adjustable feet, highlighting features for security and leveling.

4.3 Power Connection

1. After placement, wait at least 24 hours before plugging in the appliance. This allows the refrigerant to settle.
2. Plug the power cord into a dedicated, grounded electrical outlet.
3. The unit will begin to cool. Allow several hours for the interior to reach the desired temperature before loading

beverages.

5. Operating Instructions

5.1 Control Panel

The FoMup beverage refrigerator features a smart LCD touch control panel located on the top of the door frame. Refer to the image below for button identification and functions.



Image 5.1: Smart LCD Touch Control Panel with labeled functions.



Image 5.2: Detailed explanation of each control panel button.

- **Temperature Up (⌃):** Press to increase the set temperature in 1-degree increments.
- **Temperature Down (⌄):** Press to decrease the set temperature in 1-degree decrements.
- **Light Control & Unit Switch (/°C°F):**
  - Press for 1 second to turn the interior LED light on or off.
  - Press for 3 seconds to toggle the temperature display between Celsius (°C) and Fahrenheit (°F).
- **Power ON/OFF ( ):** Press for 3 seconds to turn the appliance on or off.

5.2 Temperature Adjustment

The operating temperature range for this beverage refrigerator is 37°F to 65°F (3°C to 18°C). Use the Temperature Up and Down buttons to set your desired temperature. The digital display will show the current internal temperature.

5.3 Loading Beverages

The refrigerator has a capacity of 126 standard cans. It features 3 adjustable stainless steel wire shelves with guardrails to prevent items from falling. Arrange beverages to allow for proper air circulation.



Image 5.3: Interior view demonstrating the 126-can capacity and adjustable shelves.



Image 5.4: Detail of the adjustable wire shelves designed to secure beverages.

5.4 Door Lock

The appliance is equipped with a door lock for security. Use the provided keys to lock and unlock the door as needed.

6. Maintenance

6.1 Cleaning

Regular cleaning helps maintain the appearance and efficiency of your beverage refrigerator.

1. **Before Cleaning:** Always unplug the appliance from the power outlet.
2. **Interior:** Clean the interior with a soft cloth and a mild, non-abrasive detergent solution. Rinse with clean water and dry thoroughly. Do not use harsh chemicals or abrasive cleaners.
3. **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. For glass surfaces, use a glass cleaner.
4. **Door Seal:** Clean the door gasket regularly to ensure a tight seal. A dirty or damaged gasket can lead to inefficient cooling.
5. **Shelves:** Remove the wire shelves and wash them with mild soap and water. Dry completely before returning them to the unit.

6.2 Defrosting

This appliance features a frost-free system, which automatically prevents ice buildup. Manual defrosting is generally not required. However, if any frost accumulation is observed, unplug the unit and allow it to melt naturally, then wipe away excess water.

6.3 Power Interruption

In case of a power outage, the appliance's temperature memory function will restore the previous temperature setting once power is restored. Minimize door openings during power outages to help maintain internal temperature.

7. Troubleshooting Guide

Before contacting customer service, please refer to the following table for common issues and solutions:

Problem	Possible Cause	Solution
Appliance does not operate.	Not plugged in; circuit breaker tripped; power outage.	Ensure plug is secure; check circuit breaker; verify power supply.
Temperature is not cold enough.	Temperature set too high; door not closed properly; excessive door openings; poor ventilation; too many items loaded.	Lower temperature setting; ensure door is sealed; reduce door openings; check ventilation clearances; do not overload.
Appliance is making excessive noise.	Unit not level; loose parts; normal compressor operation.	Adjust leveling feet; check for loose components; some operational noise from the compressor and fan is normal (below 38 dB).
Interior light not working.	Light switch off; LED bulb failure.	Press the light control button; contact customer service if bulb is faulty.
Door does not close properly.	Unit not level; door gasket dirty/damaged; shelves out of place.	Level the unit; clean or replace gasket; reposition shelves.
Temperature fluctuates.	Normal operation (slight fluctuations of 3-4°F are common); frequent door openings.	Minor fluctuations are expected. Minimize door openings.

8. Product Specifications

Feature	Detail
Brand	FoMup
Model Number	FM17S
Capacity	126 Cans (3.2 Cubic Feet)
Dimensions (D x W x H)	18.89 x 16.92 x 29.76 inches
Item Weight	55 pounds
Temperature Range	37°F - 65°F (3°C - 18°C)
Installation Type	Freestanding/Counter-Top
Annual Energy Consumption	145 Kilowatt Hours Per Year
Voltage	115 Volts (AC)
Defrost System	Frost Free
Shelves	3 Wire Shelves
Door Material	Glass
Special Features	Adjustable Shelves, Digital Temperature Control, Door Lock, Frost Free, Touch Control



Image 8.1: Product dimensions and suggested temperature settings for various beverages.

9. Warranty and Customer Support

FoMup products are manufactured to high-quality standards. For warranty information or technical assistance, please contact FoMup customer service. Keep your purchase receipt as proof of purchase for any warranty claims.
For further assistance, please visit the official FoMup store or contact their customer support directly. Contact information can typically be found on the manufacturer's website or your purchase documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CBVBFDV8

More documents and user manuals: **https://manuals.plus/**