Dyson AM07

Dyson Cool™ Tower Fan AM07 User Manual

Model: AM07 | Brand: Dyson

1. Introduction

The Dyson Cool™ Tower Fan AM07 is designed to amplify surrounding air, providing a smooth, uninterrupted stream of airflow for effective cooling. Its bladeless design ensures safety and ease of cleaning, making it a versatile addition to any living space.

Key Features:

- Air Multiplier technology for powerful, smooth airflow.
- 10 precise airflow settings for customized cooling.
- Curved and magnetized remote control for convenient storage.
- Sleep timer programmable from 15 minutes to 9 hours.
- Smooth 70° oscillation to direct airflow around the room.





Figure 1: Dyson Cool™ Tower Fan AM07 (White/Silver)

2. Setup

The Dyson Cool™ Tower Fan AM07 is designed for easy assembly. Follow these steps for initial setup:

1. Unpack all components from the box. Ensure all parts are present: the main fan unit, the base, and the remote control.

2. Place the main fan unit securely onto the base. It should click into place.
3. Connect the power cord to the fan unit and then plug it into a suitable electrical outlet.
4. The remote control is magnetized and can be stored neatly on top of the fan unit for easy access.

Setup Video:

Your browser does not support the video tag.

Video 1: Demonstrates the simple steps to set up the Dyson Cool™ Tower Fan, including attaching the main unit to the base and connecting the power.

3. Operating Instructions

The Dyson Cool™ Tower Fan AM07 offers intuitive controls for personalized comfort.

Power On/Off:

- Press the power button on the remote control or on the base of the fan to turn the unit on or off.

Adjusting Airflow:

- Use the '+' and '-' buttons on the remote to cycle through 10 precise airflow settings.

Oscillation:

- Press the oscillation button on the remote to activate or deactivate the smooth 70° oscillation feature, directing airflow across the room.

Sleep Timer:

- The sleep timer can be programmed to turn off the fan after pre-set intervals, ranging from 15 minutes to 9 hours. Use the timer button on the remote to set your desired duration.

Product Overview Video:

Your browser does not support the video tag.

Video 2: Provides a general overview of the Dyson Cool™ Tower Fan AM07, highlighting its design and core functionalities.

4. Maintenance

Regular maintenance ensures optimal performance and longevity of your Dyson Cool™ Tower Fan AM07.

Cleaning Instructions:

- Always unplug the fan from the power outlet before cleaning.
- Wipe the surfaces of the fan with a soft, damp cloth. Do not use detergents or polishes.
- For thorough cleaning, refer to the "Hand Wash" care instructions mentioned in the product specifications.

- Ensure the air intake holes on the base are free from dust and debris to maintain efficient airflow.

5. Troubleshooting

If you encounter issues with your Dyson Cool™ Tower Fan AM07, refer to the common problems and solutions below:

Problem	Possible Cause	Solution
Fan not turning on.	No power supply or loose connection.	Ensure the power cord is securely plugged into the fan and the wall outlet. Check the power outlet with another device.
Reduced airflow or unusual noise.	Dust accumulation in air intake or internal components.	Clean the air intake holes on the base. Refer to the Maintenance section for detailed cleaning instructions.
Oscillation not working.	Internal mechanism issue or obstruction.	Ensure the fan is on a stable, flat surface. If the issue persists, contact Dyson customer support.
Remote control not responding.	Low or dead batteries.	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the fan.

For persistent issues not covered here, please contact Dyson customer support.

6. Specifications

Feature	Detail
Brand	Dyson
Model Name	AM07
Item Model Number	464818-01
Color	White/ Silver
Product Dimensions	7.48"D x 7.48"W x 39.65"H
Item Weight	6.25 Pounds
Power Source	Corded Electric
Voltage	120 Volts (AC)
Wattage	1000 Watts
Number of Power Levels	3 (Note: Feature bullets mention 10 precise airflow settings, this might refer to fan speed levels)

Feature	Detail
Special Feature	Adjustable Tilt, Bladeless, Oscillating
Control Method	Remote
Indoor/Outdoor Usage	Indoor
Care Instructions	Hand Wash
Assembly Required	No
UPC	885609031699

7. Warranty and Support

Dyson products are known for their quality and come with manufacturer support.

Manufacturer Warranty:

Specific warranty details are typically provided with your product documentation. Please refer to the warranty card included in your product packaging for terms and conditions.

Protection Plans:

Extended protection plans may be available for purchase. For details on 3-Year, 4-Year, or Complete Protect plans, please refer to the product listing or contact your retailer.

Customer Support:

For technical assistance, troubleshooting, or warranty claims, please contact Dyson customer support directly. Visit the official Dyson website for contact information and support resources.

© 2024 Dyson. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question