Ingco CS18578

Ingco 1200W Electric Circular Saw

Model: CS18578 User Manual

1. Safety Instructions

Always observe basic safety precautions when using electric tools to reduce the risk of fire, electric shock, and personal injury. Read all instructions carefully before operating this circular saw.

General Power Tool Safety

- **Work Area Safety:** Keep the work area clean and well-lit. Cluttered or dark areas invite accidents. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- **Electrical Safety:** Power tool plugs must match the outlet. Never modify the plug in any way. Do not abuse the cord. Never use the cord for carrying, pulling, or unplugging the power tool. Keep cord away from heat, oil, sharp edges, or moving parts.
- **Personal Safety:** Always wear eye protection (safety glasses or goggles) and hearing protection. Use a dust mask if operations create dust. Dress properly; avoid loose clothing or jewelry. Keep hair, clothing, and gloves away from moving parts.

Circular Saw Specific Safety

- **Blade Guard:** Ensure the blade guard is functioning correctly and closes immediately after completing a cut. Never jam or tie the guard open.
- **Proper Grip:** Hold the saw firmly with both hands. Maintain a balanced stance.
- **Material Support:** Always support the workpiece properly to prevent blade pinching and kickback. Do not cut freehand.
- **Blade Selection:** Use only sharp, correctly sized blades for the material being cut.
- **Unplug When Not In Use:** Always unplug the saw from the power source before making any adjustments, changing accessories, or storing the tool.

2. Product Overview

The Ingco 1200W Electric Circular Saw (Model CS18578) is a powerful and versatile tool designed for cutting various materials, primarily wood. It features an adjustable cutting depth and bevel angle for precise and flexible operation.



Figure 2.1: Front view of the Ingco 1200W Electric Circular Saw, showing the blade guard and handle.



Figure 2.2: Rear view of the Ingco 1200W Electric Circular Saw, highlighting the motor housing and secondary handle.

Key Components

- **Main Handle:** For primary grip and control.
- **Auxiliary Handle:** Provides additional stability and control during operation.
- **Blade Guard:** Retracts during cutting and covers the blade when not in use.
- **Depth Adjustment Lever:** Allows setting the desired cutting depth.
- **Bevel Adjustment Lever:** For setting the angle of the cut.
- **Power Switch:** Activates and deactivates the motor.
- **Blade:** The cutting accessory, typically 185mm in diameter.

3. Setup

Before first use, or when changing blades, follow these steps carefully.

Unpacking and Inspection

1. Carefully remove the circular saw and all accessories from the packaging.
2. Inspect the tool for any signs of damage during shipping. Do not operate if damaged.
3. Ensure all listed components are present.

Blade Installation and Removal

WARNING: Always disconnect the saw from the power supply before installing or removing the blade.

1. Press the spindle lock button to secure the blade.
2. Using the provided wrench, loosen the arbor nut by turning it counter-clockwise.
3. Lift the lower blade guard and carefully remove the old blade.
4. Place the new 185mm blade onto the arbor, ensuring the rotation arrow on the blade matches the arrow on the saw's guard.
5. Replace the arbor nut and tighten it clockwise with the wrench while holding the spindle lock button. Do not overtighten.

Adjusting Cutting Depth

The cutting depth can be adjusted to match the thickness of your workpiece.

1. Loosen the depth adjustment lever.
2. Raise or lower the saw base to achieve the desired cutting depth. For optimal performance and safety, the blade should extend approximately 3-6mm below the workpiece.
3. Tighten the depth adjustment lever securely.

Adjusting Bevel Angle

The saw can make bevel cuts up to 45 degrees.

1. Loosen the bevel adjustment lever.
2. Tilt the saw base to the desired angle, aligning the indicator with the angle scale.
3. Tighten the bevel adjustment lever securely.

4. Operating

Follow these guidelines for safe and effective operation of your circular saw.

General Operation

- **Secure Workpiece:** Always clamp the workpiece firmly to a stable surface. Never attempt to hold it by hand.
- **Starting the Saw:** Ensure the blade is clear of the workpiece before starting. Press the power switch to turn on the saw. Allow the blade to reach full speed before beginning the cut.
- **Making the Cut:** Guide the saw smoothly and steadily through the material. Do not force the saw. Let the blade do the work. Maintain a firm grip with both hands.
- **Finishing the Cut:** Continue the cut completely through the workpiece. Once the cut is complete, release the power switch and allow the blade to stop rotating before lifting the saw from the material.

Making Straight Cuts

For accurate straight cuts, use a straight edge guide or a fence.

1. Mark your cut line clearly on the workpiece.
2. Set the cutting depth and bevel angle to 0 degrees.
3. Align the saw's cutting line indicator with your marked line.
4. Start the saw and slowly push it forward, keeping the base plate flat on the workpiece.

Making Bevel Cuts

Bevel cuts are angled cuts through the thickness of the material.

1. Set the desired bevel angle (up to 45 degrees) using the bevel adjustment lever.
2. Adjust the cutting depth as needed for the angled cut.
3. Proceed with the cut as you would a straight cut, ensuring the saw remains stable at the set angle.

5. Maintenance

Regular maintenance ensures the longevity and safe operation of your circular saw.

Cleaning

- After each use, disconnect the saw from the power supply.
- Use a soft brush or compressed air to remove sawdust and debris from the motor vents, blade guard, and base plate.
- Do not use solvents or harsh chemicals, as they may damage plastic parts.

Blade Care

- Keep blades sharp and clean. Dull blades can cause kickback and strain the motor.
- Replace bent or damaged blades immediately.

Storage

- Store the circular saw in a dry, secure location out of reach of children.
- Protect the power cord from damage.

6. Troubleshooting

This section addresses common issues you might encounter with your circular saw.

Problem	Possible Cause	Solution
Saw does not start	No power supply; Faulty switch; Damaged cord	Check power outlet and cord; Consult qualified service personnel for switch/cord issues.
Poor cutting performance / Blade binds	Dull or incorrect blade; Improper cutting depth; Workpiece not secured; Overheating	Replace blade; Adjust depth; Secure workpiece; Allow saw to cool.
Excessive vibration	Damaged blade; Loose blade; Damaged motor	Inspect/replace blade; Tighten blade arbor nut; Consult service personnel.
Motor overheating	Overloading; Blocked ventilation; Dull blade	Reduce load; Clean vents; Replace blade.

7. Specifications

Detailed technical specifications for the Ingco 1200W Electric Circular Saw.




Figure 7.1: Approximate dimensions of the Ingco Circular Saw.

- **Model:** CS18578
- **Brand:** Ingco
- **Voltage:** 220-240V ~ 50/60Hz
- **Input Power:** 1200W
- **No-load Speed:** 5000 rpm
- **Blade Diameter:** 185mm x 20mm
- **Cutting Capacity (90°):** 65mm
- **Cutting Capacity (45°):** 45mm
- **Adjustable Cutting Depth:** Yes
- **Adjustable Bevel Cut:** Yes
- **Weight:** Approximately 209g (product weight, not shipping)
- **Color:** Yellow
- **Handle Material:** Plastic
- **Blade Material:** Alloy Steel
- **Recommended Surface:** Wood

8. Warranty and Support

For warranty information and technical support, please refer to the warranty card included with your product or contact Ingco customer service. Keep your purchase receipt as proof of purchase.

For further assistance or to locate authorized service centers, please visit the official Ingco website or contact your local distributor.

© 2023 Ingco. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question