Naroote Narootezxu5fp6134

Digital Alarm Clock User Manual

Model: Narootezxu5fp6134

Brand: Naroote

Introduction

Thank you for purchasing the Naroote Digital Alarm Clock. This Northern European style digital clock features a large, easy-to-read font, making it ideal for bedrooms and various indoor settings. It is designed for simple operation and provides convenient time, calendar, and temperature display functions. This manual provides detailed instructions for setup, operation, and maintenance to ensure optimal performance of your device.



Image: Front view of the Naroote Digital Alarm Clock, showcasing its large, clear digital display and minimalist design.

Package Contents

- 1 x Digital Clock
- 1 x English User Manual
- 1 x USB Cable

Note: AAA Batteries are not included and must be purchased separately.



Image: The Naroote Digital Alarm Clock shown alongside its included USB cable, illustrating the items typically found in the package.

Specifications

Feature	Description
Brand	Naroote
Model Number	Narootezxu5fp6134
Color	White
Display Type	Digital
Style	Modern
Special Feature	Timer, Alarm Clock
Power Source	Battery Powered, Corded Electric
Room Type	Bedroom
Indoor/Outdoor Usage	Indoor
Frame Material	Plastic
Item Weight	5.2 ounces
Package Dimensions	5.91 x 3.15 x 1.97 inches

Setup

1. Initial Power On

Plug in the power plug (USB cable) for the first time. The device will automatically start and display the time after approximately 8 seconds. This provides continuous power to the clock.



Image: The digital clock displaying "0:00" in a dimly lit environment, representing its state immediately after being powered on for the first time.

2. Battery Installation (Backup Power)

Open the battery cover located on the back of the clock. According to the battery polarity signs (+ and -), install three AAA batteries (not included). Close the battery cover securely. These batteries serve as a backup in case of power outages, ensuring time settings are retained.



Image: Rear view of the digital clock with the battery compartment cover removed, clearly showing the slots for three AAA batteries and the power input port.

Operating Instructions

1. Viewing Time, Calendar, and Temperature

After power on, the LED display will show the current time. To switch and view different items, press the **TIME** button once. The display will cycle through the following order:

1. Time
2. Calendar (Month and Day)
3. Temperature



Image: The digital clock displaying the time (21:42) on a wooden surface, illustrating its primary function.



Image: The digital clock displaying the temperature (23°C), demonstrating its ability to show environmental data.

2. Setting Time and Calendar

To set the time and calendar, ensure the clock is in time display mode. Follow these steps:

1. **Enter Setting Mode:** Long press the **TIME** key for more than 3 seconds. The content of the item being set will flash, indicating you are in setting mode.
2. **Adjust Values:** Use the **+** key or **-** key to adjust the value of the flashing item. Long press the **+** or **-** key for rapid adjustment.
3. **Switch Items:** Press the **TIME** key again to switch to the next setting item.
4. **Setting Sequence:** The setting items will appear in the following order:
   - Time System (12-hour or 24-hour)
   - Hour
   - Minute
   - Month

- Day

5. **Exit Setting Mode:** The setting mode will automatically exit after 15 seconds if no key is pressed.

3. Alarm Clock Settings

The clock supports 2 groups of alarm clock settings. Specific instructions for setting the alarm are typically found by pressing an **ALARM** button or similar, then following a similar adjustment process as setting the time. Refer to the on-screen prompts or the physical buttons on your device for precise alarm setting steps.



Image: The digital clock positioned on a bedside table, displaying the time (21:33), with a blurred image of a person sleeping in the background, highlighting its use as a bedroom alarm clock.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the clock's surface. Avoid using abrasive cleaners or solvents, as they may damage the finish.
- **Placement:** Place the clock on a stable, flat surface away from direct sunlight, excessive heat, or moisture.
- **Battery Replacement:** If using batteries for backup, replace them annually or when the display shows signs of

dimming during power outages to ensure continuous timekeeping.

- **Storage:** If storing the clock for an extended period, remove the AAA batteries to prevent leakage.

Troubleshooting

Problem	Possible Cause / Solution
Clock display is blank or off.	◦ Ensure the USB power cable is securely plugged into both the clock and a working power source. ◦ Check if the power outlet is functional. ◦ If using battery backup, ensure batteries are correctly installed and not depleted.
Time/settings reset after power outage.	◦ The backup batteries (AAA) may be missing or depleted. Install/replace fresh AAA batteries.
Buttons are unresponsive.	◦ Try unplugging the clock from power and removing batteries for a few minutes, then reconnecting. This performs a soft reset. ◦ Ensure no foreign objects are lodged around the buttons.
Display is too dim or too bright.	◦ Check if there's a dedicated brightness adjustment button or setting in the menu (not explicitly mentioned in description, but common for digital clocks).

Warranty and Support

Specific warranty information for this product is not provided in the available documentation. For any product support, warranty claims, or technical assistance, please contact the seller or manufacturer directly through your purchase platform. Keep your purchase receipt or order number handy for faster service.

Manufacturer: Naroote

© 2023 Naroote. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question