Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Maxi Baby Baby High Chair

Maxibaby 4-in-1 Honey Baby High Chair Instruction Manual

Model: Baby High Chair

Introduction

Thank you for choosing the Maxibaby 4-in-1 Honey Baby High Chair. This product is designed to adapt to your child's growth, offering four versatile modes: a traditional high chair, a booster seat, a toddler chair, and a mobile booster seat. Please read this manual carefully before assembly and use to ensure safe and proper operation. Retain this manual for future reference.

Safety Information

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always use the restraint system. Ensure it is correctly fitted and adjusted.
- Never leave the child unattended.
- Always secure the high chair to a dining chair when used as a booster seat. Ensure all attachment straps are securely fastened.
- Do not use the high chair if any part is broken, torn, or missing.
- Keep children away from the product during assembly and disassembly.
- Do not use accessories or replacement parts other than those approved by the manufacturer.
- Ensure the high chair is placed on a flat, stable surface.
- Do not allow children to climb on the product.
- Maximum weight recommendation: 50.7 lbs (23 kg).
- Recommended age: 6 months and up.

Product Components

Before assembly, verify that all parts are present. If any parts are missing or damaged, do not use the product and contact customer support.

- Main Seat Unit with Harness

- Removable Tray
- High Chair Legs (4)
- Footrest
- Booster Base (for booster and mobile booster modes)
- Wheels (4, for mobile booster mode)
- Storage Bag (for portability)



Figure 1: Overview of the 4-in-1 Honey Baby High Chair and its configurations.

Setup and Assembly

Follow these steps for initial assembly. Refer to the images for visual guidance.

1. High Chair Assembly

1. Attach the four high chair legs to the main seat unit. Ensure they click securely into place.

2. Slide the footrest into the designated slots on the front legs until it locks.
3. Attach the removable tray by aligning it with the armrests and pushing it down until it clicks. The tray has multiple positions for adjustment.
4. Ensure the 5-point harness is correctly threaded through the seat and adjusted for your child's comfort and safety.



Figure 2: Visual representation of the four modes of the high chair.

2. Booster Seat Assembly

1. Remove the high chair legs and footrest from the main seat unit.
2. Attach the main seat unit to the booster base. Ensure it is securely fastened.
3. Place the assembled booster seat on a stable adult dining chair.
4. Use the integrated straps on the booster base to securely fasten it to the adult chair, both around the backrest and under the seat. Pull straps tight to eliminate any movement.
5. Attach the removable tray as described in step 1.3.

3. Mobile Booster Seat Assembly

1. Follow steps 2.1 and 2.2 to attach the seat unit to the booster base.
2. Insert the four wheels into the designated slots on the bottom of the booster base. Ensure they are firmly in place and can rotate freely.
3. This mode allows for easy movement of the booster seat within a supervised area. It is not intended as a traditional baby walker for independent mobility.



Figure 3: Mobile Booster Seat configuration with wheels.

4. Toddler Chair Assembly

1. Remove the high chair legs and footrest.
2. The main seat unit, without the high chair legs or booster base, can be used directly on the floor as a toddler chair.
3. The tray can be attached or removed as needed for playtime or activities.

Operating Instructions

Using the 5-Point Harness

The 5-point harness system is crucial for your child's safety. Always ensure it is properly fastened and adjusted.

- Place your child in the seat.
- Bring the shoulder straps over your child's shoulders and connect them to the waist straps.
- Insert the two buckle prongs into the central buckle until they click.
- Adjust the straps to be snug against your child's body without being too tight. There should be no more than one finger's width between the strap and your child.
- To release, press the button on the central buckle.

Tray Adjustment and Removal

The tray can be adjusted to multiple positions or removed entirely.

- To adjust: Locate the release levers or buttons on the underside of the tray, usually near the armrests. Press them and slide the tray forward or backward.
- To remove: Press the release levers/buttons and lift the tray upwards and away from the seat.

Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your high chair and ensure hygiene for your child.

- **Seat Pad:** The upholstered seat is designed for easy cleaning. Wipe clean with a damp cloth and mild soap. Allow to air dry completely. Do not machine wash or tumble dry unless specified on a care label (check product for specific care tags).
- **Tray:** The removable tray can be easily wiped clean with a damp cloth and mild soap. It may also be rinsed under water. Do not use abrasive cleaners.
- **Frame and Plastic Parts:** Wipe down with a damp cloth. Ensure all parts are dry before storage or next use.
- **Storage:** When not in use, the detachable design allows for quick and easy storage. Store in a cool, dry place, away from direct sunlight. The included storage bag can be used for portability and protection.

Troubleshooting

Problem	Possible Cause	Solution
Parts do not fit during assembly.	Incorrect orientation or misalignment.	Review the assembly steps and ensure parts are oriented correctly. Apply firm, even pressure. Do not force parts.
High chair feels unstable.	Legs not fully engaged or placed on an uneven surface.	Ensure all legs are securely clicked into place. Move the high chair to a flat, stable surface.
Harness is difficult to buckle/unbuckle.	Buckle mechanism is dirty or misaligned.	Clean the buckle area. Ensure the prongs are inserted straight into the central buckle.
Tray does not slide smoothly.	Food debris or obstruction in the tracks.	Remove the tray and clean the sliding tracks on both the tray and the armrests.

Specifications

Product Dimensions (High Chair): 30.51 x 22.44 x 34.25 inches

Product Dimensions (Booster Seat): 12.99"D x 19"W x 17"H

Item Model Number: Baby High Chair

Maximum Weight Recommendation: 50.7 lbs (23 Kilograms)

Material Type: Aluminum, PP, ABS, and Polyester Fabric

Item Weight: 11.44 pounds (5.2 Kilograms)

Is Portable: Yes

Color: Pink

Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please contact Maxi Baby customer service. Refer to the product packaging or the official Maxi Baby website for contact details.
Maxi Baby Official Website: Maxi Baby Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CC72SFGK

More documents and user manuals: **https://manuals.plus/**