KITCHMIX WT-340A

KITCHMIX WT-340A 4-Slice Retro Toaster Instruction Manual

Model: WT-340A | Brand: KITCHMIX

Setup
Operation
Maintenance
Troubleshooting
Specifications
Warranty & Support

1. Setup

Before first use, please read all instructions carefully. Keep this manual for future reference.

1.1 Unpacking

- Remove all packaging materials, stickers, and labels from the toaster.
- Check that all parts are present and undamaged.

1.2 Placement

- Place the toaster on a stable, flat, heat-resistant surface.
- Ensure adequate ventilation around the toaster. Do not place it near curtains, walls, or under cabinets.
- Keep the toaster away from water or other liquids.

1.3 Initial Cleaning

- Wipe the exterior of the toaster with a damp cloth.
- Ensure the crumb trays are empty and properly inserted.
- For the first use, operate the toaster without bread on the highest setting (Level 6) in a well-ventilated area to burn off any manufacturing residues. A slight odor or smoke may be present; this is normal.

2. Operating Instructions

This KITCHMIX toaster features dual independent control panels, allowing you to toast different items simultaneously with separate settings.

2.1 Controls Overview

- **Browning Control Dials (1-6):** Adjust the desired toast shade from light (1) to dark (6).
- **Toast Levers:** Push down to start the toasting cycle.
- **CANCEL Button:** Stops the toasting cycle at any time.
- **BAGEL Button:** Toasts the cut side of bagels while gently warming the other side.
- **DEFROST Button:** Defrosts and toasts frozen bread.
- **REHEAT Button:** Warms previously toasted items without further browning.



Image: Toaster control panel with browning dials and function buttons for Cancel, Bagel, and Defrost/Reheat.

2.2 Toasting Bread

1. Insert up to four slices of bread into the 1.5-inch wide slots.
2. Select your desired browning level using the browning control dial (1-6). Start with a medium setting (e.g., 3 or 4) and adjust as needed.
3. Press the toast lever down until it locks into place. The indicator light for the selected function (if any) will illuminate.
4. The toaster will automatically raise the toast when the cycle is complete.



Image: Visual guide demonstrating the steps for toasting: insert bread, press lever, set shade knob, and automatic pop-up.

2.3 Using Special Functions (Bagel, Defrost, Reheat)

- **Bagel:** Insert bagels with the cut side facing inwards. Select your browning level, then press the toast lever down and press the BAGEL button.
- **Defrost:** Insert frozen bread. Select your browning level, then press the toast lever down and press the DEFROST button. This cycle will automatically adjust the toasting time.
- **Reheat:** Insert previously toasted items. Select a low browning level (e.g., 1 or 2), then press the toast lever down

and press the REHEAT button. This function warms without additional browning.



Image: Illustration of 6 browning levels and their approximate toasting times, from Level 1 (70s) to Level 6 (210s).

3. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your toaster.

3.1 Crumb Tray Cleaning

1. Always unplug the toaster and allow it to cool completely before cleaning.
2. Locate the two removable crumb trays at the back of the toaster.
3. Pull out the crumb trays to remove accumulated crumbs.

4. Discard crumbs and wipe the trays with a damp cloth. Dry thoroughly before reinserting.
5. Push the crumb trays back into place until they click securely.



Image: The toaster with its two slide-out crumb trays partially removed, illustrating the easy cleaning feature.

3.2 Exterior Cleaning

- Wipe the exterior of the toaster with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may scratch the surface.
- Never immerse the toaster in water or any other liquid.

4. Troubleshooting

If you encounter issues with your toaster, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Toaster does not turn on.	Not plugged in; power outage; circuit breaker tripped.	Ensure the toaster is securely plugged into a working outlet. Check your home's circuit breaker.
Bread does not toast evenly.	Uneven bread thickness; crumb accumulation; first use.	Ensure bread slices are of uniform thickness. Clean crumb trays regularly. The first few uses may result in uneven toasting.
Bread stuck in slots.	Oversized bread; mechanical issue.	Unplug the toaster. Carefully remove the bread using non-metallic tongs. Do not force the toast lever.
Smoke coming from toaster.	Crumb accumulation; food stuck; first use residue.	Immediately press CANCEL and unplug. Clean crumb trays. Remove any food stuck in slots. Ensure proper ventilation.

5. Specifications

- **Brand:** KITCHMIX
- **Model:** WT-340A
- **Color:** Pink
- **Material:** Stainless Steel
- **Product Dimensions:** 12.2"D x 13.39"W x 7.28"H
- **Wattage:** 1650 watts
- **Voltage:** 110 Volts
- **Number of Slices:** 4
- **Number of Browning Settings:** 6
- **Special Features:** 1.5-inch Extra-wide Slots, Cancel/Defrost/Reheat Functions, Dual Independent Control Panel, Removable Crumb Trays, Retro Style
- **Item Weight:** 5.88 pounds



Image: Product dimensions of the KITCHMIX 4-slice toaster.

6. Warranty and Support

For warranty information or product support, please contact KITCHMIX customer service. Keep your purchase receipt as proof of purchase.

- **Customer Service:** Refer to the contact information provided with your product packaging or visit the official KITCHMIX website.
- **Online Resources:** Check the KITCHMIX website for FAQs, additional product information, and registration.

© 2026 KITCHMIX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question