Tieasy USCX08T75

Tieasy USCX08T75 Wall Mount Range Hood Chimney Cover Instruction Manual

Model: USCX08T75-CC

1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your Tieasy USCX08T75 Wall Mount Range Hood Chimney Cover. Please read this manual thoroughly before installation and use to ensure proper function and safety.

The Tieasy USCX08T75-CC chimney cover is designed to complement your Tieasy USCX08T75 wall mount range hood, providing a sleek finish and covering the exhaust ductwork. It is constructed from durable, black powder-coated metal, resistant to high temperatures, rust, and corrosion.

2. Safety Information

- **Compatibility:** Ensure this chimney cover is compatible with your specific range hood model (Tieasy USCX08T75). It is not designed for other models.
- **Professional Installation Recommended:** While installation is designed to be straightforward, professional assistance is recommended for optimal safety and performance.
- **Sharp Edges:** Handle all components with care to avoid injury from sharp edges. Wear protective gloves during installation.
- **Electrical Safety:** Ensure the range hood's power supply is disconnected before beginning installation or maintenance.

3. Product Specifications

Feature	Detail
Brand	Tieasy
Model Info	USCX08T75-CC
Material Type	Metal

Finish Type	Powder Coated
Item Weight	7.83 pounds
Product Dimensions	13.5"D x 13"W x 15.5"H
Mounting Type	Wall Mount (for compatible range hood)



Figure 1: Detailed dimensions of the Tieasy USCX08T75-CC Chimney Cover. The cover measures approximately 13.5 inches deep, 12.48 inches wide, and 13.77 inches high.

4. Package Contents

Verify that all components are present before beginning installation:

- Upper Chimney Cover Piece
- Lower Chimney Cover Piece
- Mounting Hardware (screws, anchors, brackets)

- Instruction Manual (this document)



Figure 2: The two-piece chimney cover as received.

5. Installation Instructions

This chimney cover is designed for the Tieasy USCX08T75 Wall Mount Range Hood. Ensure your range hood is already installed and securely mounted before proceeding with the chimney cover installation.

5.1. Prepare the Chimney Cover

1. Carefully unpackage both chimney cover pieces.
2. Remove any protective film from the stainless steel surfaces.



Figure 3: Close-up view of the black powder-coated metal finish of the chimney cover.

5.2. Mount the Upper Chimney Bracket

1. Identify the upper mounting bracket provided with your range hood or chimney cover kit.
2. Position the bracket on the wall directly above the range hood, ensuring it is centered and level. The top edge of the upper chimney piece should align with the ceiling or desired height.
3. Mark the drilling points through the bracket holes.
4. Drill pilot holes at the marked locations.
5. Insert wall anchors (if necessary for your wall type).

6. Secure the upper mounting bracket to the wall using the provided screws.

5.3. Install the Chimney Cover Pieces

1. Slide the lower chimney cover piece onto the range hood body.
2. Slide the upper chimney cover piece into the lower piece.
3. Extend the upper chimney piece upwards until it aligns with the upper mounting bracket.
4. Secure the upper chimney piece to the upper mounting bracket using the provided screws.
5. Ensure both chimney pieces are securely interlocked and flush against the wall.



Figure 4: Illustration of the Tieasy USCX08T75 Range Hood with the two-piece chimney cover installed, showing overall dimensions.

6. Operating Instructions

The chimney cover itself does not have operational controls. Its function is purely aesthetic and protective. Refer to your main Tieasy USCX08T75 Wall Mount Range Hood manual for operating instructions regarding fan speeds, lighting, and other features.

7. Maintenance

7.1. Cleaning the Chimney Cover

- Regularly wipe down the exterior surfaces of the chimney cover with a soft cloth and a mild, non-abrasive cleaner.
- Avoid using harsh chemicals, abrasive pads, or steel wool, as these can damage the powder-coated finish.
- Dry thoroughly after cleaning to prevent water spots.

7.2. Filter Maintenance (Refer to Range Hood Manual)

The chimney cover does not contain filters. For instructions on cleaning or replacing the range hood's baffle filters, please consult the instruction manual provided with your main Tieasy USCX08T75 Wall Mount Range Hood unit.

8. Troubleshooting

This section addresses common issues related to the chimney cover. For issues concerning the range hood's electrical functions, fan operation, or lighting, please refer to the main range hood manual.

8.1. Chimney Cover Not Fitting Properly

- **Issue:** The chimney cover pieces do not align or fit snugly.
- **Solution:**
    - Verify that the range hood itself is installed level and plumb.
    - Ensure the upper mounting bracket for the chimney cover is installed correctly and level.
    - Check for any obstructions behind the chimney cover pieces.

8.2. Scratches or Damage to Finish

- **Issue:** Scratches or minor damage to the black powder-coated finish.
- **Solution:**
    - For minor scratches, touch-up paint designed for powder-coated metal may be used (test in an inconspicuous area first).
    - Prevent future damage by using soft cleaning cloths and avoiding abrasive materials.

9. Warranty and Customer Support

For any questions or concerns regarding your Tieasy USCX08T75-CC Chimney Cover, please contact our customer service team. We are dedicated to ensuring your satisfaction.

Information regarding product warranties and service can typically be found in the documentation accompanying your main Tieasy range hood unit or by contacting Tieasy customer support directly.

"Friendly Service: If you have any questions, our customer service team is ready to support you and make sure your experience goes smoothly."

© 2023 Tieasy. All rights reserved.