Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

COSORI CAF-L502-WUS

COSORI Air Fryer Pro LE 5-Qt Instruction Manual

Model: CAF-L502-WUS | Brand: COSORI

Introduction

Welcome to the COSORI Air Fryer Pro LE 5-Qt. This manual provides essential information for safe operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your appliance. Please read all instructions thoroughly before first use and retain this manual for future reference.

Important Safety Information

WARNING: To reduce the risk of fire, electric shock, or injury, read all instructions and warnings carefully before operating.

- Always place the air fryer on a stable, heat-resistant surface.
- Do not immerse the cord, plug, or housing in water or other liquid.
- Keep the appliance and its cord out of reach of children.
- Do not block any ventilation openings.
- Unplug from outlet when not in use and before cleaning.
- Do not use metal utensils or abrasive cleaning materials on non-stick surfaces.
- Ensure proper ventilation during use.

Product Overview

The COSORI Air Fryer Pro LE 5-Qt is designed for versatile cooking with minimal oil. It features a compact design suitable for 1-4 people.

Components

- Main Unit with Digital Touchscreen
- Removable Fry Basket
- Non-stick Crisper Plate
- Power Cord

Product Image



Figure 1: COSORI Air Fryer Pro LE 5-Qt main unit, paper liners, and recipe book.

The image above displays the complete COSORI Air Fryer Pro LE 5-Qt package, including the main appliance, a pack of 20 paper liners for easy cleanup, and a recipe book to inspire your cooking.

Before First Use

Before using your air fryer for the first time, follow these steps to ensure proper function and eliminate any manufacturing odors:

1. **Clean and Dry:** Remove the frying basket and crisper plate. Wash them thoroughly with a damp cloth or sponge using dish soap and water. *Do not use metal kitchen utensils or abrasive cleaning materials as this may damage the non-stick coating.* Ensure all parts are completely dry before reassembly.
2. **Test Run:** Place the empty basket and crisper plate back into the air fryer. Run the appliance at 450°F (230°C) for 30 minutes without any food. This helps to burn off any residual manufacturing oils and odors.
3. **Cool Down:** Allow the air fryer to cool down completely after the test run.
4. **Final Clean:** Repeat step 1 to clean the basket and crisper plate again.

Perform these steps in a well-ventilated area.

Setup

Proper setup ensures safe and efficient operation:

- Place the air fryer on a flat, stable, heat-resistant surface, away from walls or other appliances to allow for adequate airflow.
- Ensure the power cord is not tangled or pinched.
- Plug the power cord into a grounded AC 120V, 60Hz electrical outlet.

Operating Instructions

The COSORI Air Fryer Pro LE offers 7 cooking modes and intuitive controls for various culinary tasks.

Control Panel Overview



Figure 2: Digital touchscreen control panel showing various cooking functions.

The digital touchscreen allows for easy selection of cooking modes, temperature, and time. The image above highlights the clear display and touch-sensitive buttons for functions like Air Fry, Roast, Bake, Dry, Broil, Frozen, and Reheat.

Cooking Modes and Functions

- **Air Fry:** Ideal for crispy results with minimal oil.
- **Roast:** Perfect for meats and vegetables.
- **Bake:** Suitable for cakes, pastries, and more.
- **Dehydrate:** For making dried fruits or jerky.
- **Broil:** For quick browning and crisping.
- **Frozen:** Optimized settings for frozen foods.
- **Reheat:** To warm up leftovers while maintaining texture.

Temperature and Time Adjustment

- Use the **TEMP +/-** buttons to adjust the cooking temperature (95°F–450°F).
- Use the **TIME +/-** buttons to adjust the cooking time (1-24 hours).
- Press the **Play**/**Pause** button to start or pause cooking.

Thoughtful Reminders

- **Shake Reminder:** The air fryer will beep to remind you to shake or flip food halfway through cooking for even results.
- **Preheat:** Use the Preheat function for faster cooking and better texture.
- **Keep Warm:** Maintains food temperature after cooking.



Figure 3: The 5-quart capacity allows for cooking various items like fries, steak, and vegetables.

The 5-quart capacity of the COSORI Air Fryer Pro LE is designed to accommodate meals for 1-4 people, making it ideal for family use. It can handle approximately 2.5 lbs of fries or 2 lbs of steak, as shown in the image above.

Cleaning and Maintenance

Regular cleaning ensures hygiene and extends the life of your air fryer.

Daily Cleaning

- Always unplug the air fryer and allow it to cool completely before cleaning.
- The non-stick basket and crisper plate are **dishwasher safe** for effortless cleanup.
- For manual cleaning, wash with warm, soapy water and a non-abrasive sponge.
- Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners.



Figure 4: The removable basket and crisper plate are dishwasher-safe for convenient cleaning.

As shown in the image, the basket and crisper plate can be easily placed in a dishwasher, simplifying the cleaning process after each use.

Deep Cleaning (Heating Coil)

- After the air fryer has cooled, gently wipe the heating coil inside the main chamber with a damp cloth to remove any food residue.
- Ensure the rubber guards on the crisper plate are not removed, as they protect the non-stick coating from scratches.



Figure 5: The air fryer comes with 20 paper liners to minimize mess and simplify cleanup.

The included 20 air fryer liners, depicted in the image, are designed to catch drips and crumbs, significantly reducing the need for extensive cleaning of the basket after cooking.

Troubleshooting

If you encounter issues with your COSORI Air Fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outage; basket not fully inserted.	Check power cord connection; check circuit breaker; ensure basket is securely closed.
Food is not crispy.	Too much food in basket; insufficient oil; incorrect temperature/time.	Cook in smaller batches; lightly coat food with oil; adjust temperature/time as per recipe.

Problem	Possible Cause	Solution
White smoke from air fryer.	Grease from previous use; high-fat food.	Clean basket and crisper plate thoroughly; drain excess oil from food.
Plastic smell during first few uses.	Manufacturing residue.	This is normal. Perform test run as described in "Before First Use" section. Ensure good ventilation.

Specifications

Detailed technical specifications for your COSORI Air Fryer Pro LE 5-Qt:

- **Model Name:** CAF Pro
- **Model Number:** CAF-L502-WUS
- **Capacity:** 5 Quarts
- **Power Supply:** AC 120V, 60Hz
- **Wattage:** 1500 Watts
- **Temperature Range:** 95°F–450°F (35°C–230°C)
- **Time Range:** 1-24 hours
- **Product Dimensions (D x W x H):** 14.4" x 10.8" x 12.1"
- **Basket Dimensions (D x W x H):** 8.6" x 8.6" x 4.3"
- **Item Weight:** 12 Pounds
- **Material:** Non-stick (BPA-free)
- **Control Method:** Touch
- **Dishwasher Safe Parts:** Yes (Basket, Crisper Plate)
- **Certifications:** ETL-Listed

Warranty and Support

For warranty information or technical support, please visit the official COSORI website or contact their customer service. Keep your purchase receipt for warranty claims.

Visit the COSORI Store for more information

© 2024 COSORI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CCJ8X596

More documents and user manuals: **https://manuals.plus/**