Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fafeicy Fafeicyn0xfqamiph

Fafeicy 7-in-1 Multifunctional Electric Cleaning Brush User Manual

Model: Fafeicyn0xfqamiph

Introduction Package Contents Specifications Safety Information Setup Operation Maintenance Troubleshooting Warranty & Support

1. Introduction

Thank you for choosing the Fafeicy 7-in-1 Multifunctional Electric Cleaning Brush. This cordless handheld power scrubber kit is designed to simplify various cleaning tasks around your home and vehicle. With its powerful motor, interchangeable brush heads, and adjustable handle, it provides an efficient solution for deep cleaning, polishing, and waxing. Please read this manual thoroughly before first use to ensure proper operation and maintenance.

2. Package Contents

Carefully unpack your Fafeicy Electric Cleaning Brush kit and verify that all items listed below are present. If any items are missing or damaged, please contact customer support.



Figure 2.1: All components included in the package, clearly labeled for identification.

1. Host (Main Machine)
2. Sponge Plate
3. Polyester Cloth Disc (Synthetic Fiber Cloth Plate)
4. Fiber Disc (Fiber Plate)
5. Large Flat Brush
6. Fixing Plate
7. Wool Disc (Wool Plate)
8. Pointed Brush Head
9. Small Flat Brush
10. Type C Charging Cable
11. Telescopic Pole (2 sections)
12. User Manual (this document)

3. Specifications

Feature	Specification
Brand	Fafeicy
Model Number	Fafeicyn0xfqamiph
Material	Acrylonitrile Butadiene Styrene (ABS)
Battery Type	Lithium Ion Battery (built-in)
Battery Capacity	2500mAh
Charging Time	2-3 hours
Charging Mode	USB Type-C
Working Time	Up to 90 minutes
Motor Type	390 Strong Magnetic Copper Core Motor
Maximum Power	75W
Special Feature	Cordless, Retractable Handle, 2 Speed Modes
Handle Length	Adjustable from 9.8 inches to 55 inches (24.89cm to 140cm)

4. Safety Information

Please observe the following safety precautions to prevent injury or damage to the device:

- Read all instructions before using the appliance.
- Keep the device away from children and pets.
- Do not immerse the main unit in water. The device is waterproof for splashes but not for submersion.
- Use only the provided Type-C charging cable and a compatible USB power adapter.
- Do not operate the device if the charging cable or plug is damaged.
- Avoid using the brush on delicate surfaces that may scratch easily. Test on an inconspicuous area first.
- Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel.
- Ensure the brush head is securely attached before operation.
- Store the device in a dry place when not in use.

5. Setup

5.1 Initial Charging

Before first use, fully charge the electric cleaning brush. The host unit features 5 display lights that indicate the charging status and battery level.

1. Connect the provided Type-C charging cable to the charging port on the main unit.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a USB port.
3. The display lights will flash during charging. Once fully charged (approximately 2-3 hours), all 5 lights will remain solid.

4. Disconnect the charging cable once charging is complete.



Figure 5.1: Main unit with power button and battery indicator lights.

5.2 Assembling the Handle

The electric cleaning brush features a retractable handle for versatile use. You can use it as a handheld device or extend it for longer reach.

1. To use as a handheld device, simply attach the desired brush head directly to the main unit.

2. To extend the reach, attach the telescopic pole sections to the main unit by rotating them until they lock securely. The handle can be adjusted from 9.8 inches to 55 inches (24.89cm to 140cm).
3. Ensure all connections are firm before operation.



Figure 5.2: Main unit and telescopic poles for adjustable length.

5.3 Attaching Brush Heads

The kit includes various interchangeable brush heads for different cleaning tasks.

1. Select the appropriate brush head for your cleaning task (e.g., sponge plate for delicate surfaces, large flat brush for general scrubbing).
2. Align the brush head with the rotating shaft on the main unit or the end of the telescopic pole.
3. Push and twist the brush head until it clicks securely into place.
4. To remove, twist and pull the brush head off.



Figure 5.3: Selection of interchangeable brush heads.

6. Operation

6.1 Powering On/Off and Speed Adjustment

The device features a power button and multiple speed modes.

1. Press the power button once to turn on the device at the default speed.
2. Press the power button again to switch to the higher speed mode.
3. Press the power button a third time to turn off the device.

6.2 Cleaning Applications

The Fafeicy Electric Cleaning Brush is suitable for a wide range of cleaning tasks:

- **Bathroom Cleaning:** Use the large flat brush or pointed brush head for tiles, grout, bathtubs, and sinks.
- **Kitchen Cleaning:** The small flat brush or fiber disc is effective for stovetops, countertops, and sinks.
- **Floor Cleaning:** Attach the telescopic pole and use the large flat brush for hard floors.
- **Car Surface Cleaning:** The sponge plate or wool disc can be used for polishing and waxing car exteriors.
- **Corner and Crevice Cleaning:** The pointed brush head is ideal for reaching tight spaces and corners.



Figure 6.1: Examples of various cleaning applications with different brush heads.

For optimal results, apply appropriate cleaning solutions to the surface before using the brush. Do not apply excessive pressure; let the brush's rotation do the work.

7. Maintenance

7.1 Cleaning the Device

1. After each use, remove the brush head from the main unit.
2. Rinse the brush heads under running water to remove dirt and debris. For stubborn grime, use a mild soap.
3. Wipe the main unit and telescopic pole with a damp cloth. Do not immerse the main unit in water.
4. Ensure all parts are completely dry before storing.

7.2 Storage

Store the electric cleaning brush and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures. Keep it out of reach of children.

8. Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on	Battery is depleted	Charge the device fully (2-3 hours).
	Power button not pressed correctly	Ensure a firm press on the power button.
Brush head stops rotating or slows down significantly	Battery is low	Recharge the device.
	Excessive pressure applied	Reduce pressure; let the motor do the work.
	Brush head is jammed	Turn off the device, remove any obstructions from the brush head.
Device not charging	Charging cable or adapter faulty	Try a different Type-C cable or USB adapter.
	Charging port obstructed	Check for debris in the charging port.

If you encounter issues not listed here or if the problem persists, please contact customer support.

9. Warranty and Support

Fafeicy products are manufactured with quality and reliability in mind. For specific warranty details, please refer to the warranty card included with your purchase or contact Fafeicy customer support directly. Our customer service team is available to assist you with any questions, concerns, or technical support needs.
For assistance, please visit the official Fafeicy store on Amazon or contact the seller directly through your purchase platform.

© 2023 Fafeicy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CCJNKPWS

More documents and user manuals: **https://manuals.plus/**