ZdalaMit RC-1227

ZdalaMit RC-1227 Replacement Remote Control User Manual

For Denon AV Receivers

1. Introduction

This manual provides comprehensive instructions for the ZdalaMit RC-1227 Replacement Remote Control. It is designed to be fully compatible with various Denon AV Receiver models, offering a straightforward, no-programming setup for immediate use. Please read this manual carefully to ensure proper operation and longevity of your remote control.

2. Package Contents

- 1 x ZdalaMit RC-1227 Replacement Remote Control
- (Batteries are not included)

3. Compatible Denon AV Receiver Models

The RC-1227 remote control is compatible with the following Denon AV Receiver models:

- AVR-S750H
- AVR-X1600H
- AVR-X1500H
- AVR-S740H
- AVR-X1500HOM
- AVR-X1600H DAB
- AVR-X1700H

4. Setup and Battery Installation

This remote control requires two (2) AAA size alkaline batteries (not included). No programming is required; simply insert the batteries, and the remote will be ready for use with your compatible Denon AV

Receiver.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Figure 1: Rear view of the RC-1227 remote control, illustrating the location of the battery compartment. The compartment cover is typically slid open to insert batteries.

5. Operating Instructions

Once batteries are installed, the RC-1227 remote control is ready to operate your Denon AV Receiver. Point the remote control directly at your AV receiver and press the desired function buttons.





Figure 2: Front view of the RC-1227 remote control, displaying all buttons for various functions such as power, input selection, volume, navigation, and quick select options.

Key Functions:

- **POWER:** Turns the AV receiver on or off.
- **ZONE SELECT (MAIN, ZONE 2):** Selects the audio zone to control.
- **INPUT SELECTORS (CBL/SAT, DVD, Blu-ray, GAME, AUX, MEDIA PLAYER, PHONO, TV AUDIO, TUNER, USB, BLUETOOTH, INTERNET RADIO):** Selects the desired input source.
- **VOLUME (+/-):** Adjusts the master volume level.
- **MUTE:** Mutes or unmutes the audio output.
- **NAVIGATION BUTTONS (Up, Down, Left, Right, ENTER):** Used for menu navigation and selection.
- **BACK:** Returns to the previous menu or screen.
- **SETUP:** Accesses the receiver's setup menu.
- **INFO:** Displays information about the current source or settings.
- **OPTION:** Accesses context-sensitive options.
- **QUICK SELECT (1, 2, 3, 4):** Provides quick access to pre-configured settings or favorite inputs.
- **ECO:** Activates or deactivates ECO mode for power saving.
- **CH/PAGE (+/-):** Changes channels or pages in certain modes.
- **TUNER CONTROLS (TUNE-, TUNE+, Play/Pause, Skip):** Controls radio tuning and media playback.

6. Maintenance

- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new AAA alkaline batteries.
- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

7. Troubleshooting

- **Remote not working:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the AV receiver's infrared sensor.
  - Confirm that the remote is pointed directly at the AV receiver.
- **Intermittent operation:**
  - Check battery levels and replace if necessary.
  - Ensure the remote is within effective operating range and line of sight.

8. Specifications

Feature	Detail
Model	RC-1227

Feature	Detail
Brand	ZdalaMit
Compatibility	Denon AV Receivers (AVR-S750H, AVR-X1600H, AVR-X1500H, AVR-S740H, AVR-X1500HOM, AVR-X1600H DAB, AVR-X1700H)
Power Source	2 x AAA Alkaline Batteries (not included)
Dimensions	6 x 2 x 0.5 inches
Item Weight	2 ounces
Color	Black
Special Feature	Pre-Programmed, No Setup Required

9. Warranty and Support

For any questions or support regarding your ZdalaMit RC-1227 Replacement Remote Control, please contact the seller or manufacturer directly. Specific warranty details may vary; please refer to your purchase documentation for more information.

© 2023 ZdalaMit. All rights reserved.