Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iJoy DS20216

iJoy Mickey and Friends Bluetooth Speaker User Manual

Model: DS20216

Introduction

Thank you for purchasing the iJoy Mickey and Friends Bluetooth Speaker. This portable wireless speaker is designed to provide high-quality audio with the convenience of Bluetooth connectivity, an SD card slot, and FM radio functionality. Its splashproof design makes it suitable for various environments. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your speaker.



Image: Front and back view of the iJoy Mickey and Friends Bluetooth Speaker, showcasing its design and compact form factor.

What's in the Box

Please check the package contents to ensure all items are present:

- iJoy Mickey and Friends Bluetooth Speaker
- USB Charging Cable
- Backup AUX Cable

- Owners Manual (this document)



Image: The iJoy Mickey and Friends Bluetooth Speaker shown alongside its retail packaging, indicating the product and its box.

Setup

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the supplied USB charging cable to the speaker's Micro USB port and the other end to a USB power adapter (not included) or a computer's USB port. The LED indicator light will show charging status.

- Charging Time: Approximately 2 hours for a full charge.
- Battery Life: Up to 3 hours of playtime on a full charge.

2. Powering On/Off

Press and hold the Power On/Off button located on the top panel of the speaker until you hear an audible prompt or see the LED indicator light up.



Image: Close-up view of the speaker's top panel, highlighting the power button and other controls.

3. Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing LED).
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "iJoy Speaker" or a similar name from the list.
4. Once paired, the speaker will indicate a successful connection, and the LED will stop flashing.

The speaker is compatible with all Bluetooth-enabled devices, including iPhones, Android smartphones, tablets, and laptops.

4. Connecting via AUX or SD Card

The speaker supports audio playback via an AUX cable and an SD card.

- **AUX Input:** Connect one end of the supplied AUX cable to the speaker's AUX port and the other end to your audio device's headphone jack. The speaker will automatically switch to AUX mode.
- **SD Card:** Insert a compatible SD card into the SD card slot. The speaker will automatically detect and play audio files from the card.



Image: Detailed view of the speaker's connectivity ports, including AUX, SD card slot, USB port, and Micro USB charging port.

Operating the Speaker

Button Controls

The speaker features intuitive button controls on its top panel:

- **Power On/Off:** Press and hold to turn the speaker on or off.
- **Volume +:** Press to increase volume.
- **Volume -:** Press to decrease volume.
- **Play/Pause/Take Call:** Press to play or pause audio. Press to answer an incoming call, press again to end a call.
- **Mode Switch (M):** Press to cycle through available modes: Bluetooth, FM Radio, SD Card, AUX.



Image: Close-up view of the speaker's top panel, illustrating the function of each control button.

FM Radio Function

To use the FM Radio:

1. Press the "M" (Mode Switch) button until you enter FM Radio mode.
2. The speaker will automatically scan and save available radio stations.
3. Use the Volume +/- buttons to navigate between saved stations.

Answering/Rejecting Calls

When connected via Bluetooth to a smartphone:

- **Answer Call:** Press the Play/Pause/Take Call button once.
- **End Call:** Press the Play/Pause/Take Call button once during a call.
- **Reject Call:** Press and hold the Play/Pause/Take Call button for 2 seconds.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The speaker has an IPX4 splashproof rating, meaning it is resistant to splashing water from any direction. Do not submerge the speaker in water or expose it to strong jets of water. Ensure all port covers are securely closed before exposure to moisture.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is depleted.	Charge the speaker fully using the supplied USB cable.
Cannot pair with Bluetooth device.	Speaker is not in pairing mode; Device Bluetooth is off; Speaker is too far from device.	Ensure speaker is in pairing mode (flashing LED). Turn Bluetooth off and on again on your device. Move speaker closer to your device (within 30 feet).
No sound from speaker.	Volume is too low; Incorrect mode selected; Device not playing audio.	Increase speaker and device volume. Press "M" button to switch to correct mode (Bluetooth, AUX, SD). Ensure audio is playing on your connected device.
Poor FM radio reception.	Weak signal; Environmental interference.	Move the speaker to a different location. Extend the AUX cable (if connected) as it can act as an antenna.

Specifications

Model Name	MAF Revolution Speaker
Model Number	DS20216
Speaker Type	Portable Bluetooth Speaker
Connectivity Technology	Bluetooth
Bluetooth Range	Up to 30 feet (9 meters)
Battery Life	Up to 3 hours
Charging Time	Approximately 2 hours
Battery Capacity	800 Milliamp Hours
Power Source	Battery Powered
Input Voltage	5 Volts
Speaker Output Power	3 Watts
Water Resistance Rating	IPX4 (Splashproof)
Product Dimensions (D x W x H)	3" x 3" x 6" (7.62 cm x 7.62 cm x 15.24 cm)
Item Weight	8 Ounces (226.8 grams)
Material	Plastic



Image: The speaker with visual indicators of its dimensions: 6.3 inches tall and 2.9 inches across.

Warranty and Support

This iJoy Mickey and Friends Bluetooth Speaker comes with a**90-day manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.
The warranty does not cover:

- Damage caused by accident, abuse, misuse, flood, fire, earthquake, or other external causes.
- Damage caused by operating the product outside the permitted or intended uses described by iJoy.
- Damage caused by service performed by anyone who is not a representative of iJoy.
- Products or parts that have been modified to alter functionality or capability without the written permission of iJoy.

For warranty claims or technical support, please contact iJoy customer service. Please have your proof of purchase and product model number (DS20216) ready when contacting support.

Contact Information:

Please refer to the contact details provided on the product packaging or the official iJoy website for the most current support information.

© 2024 iJoy. All rights reserved. Mickey and Friends characters are trademarks of Disney.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CCQKWWLL

More documents and user manuals: **https://manuals.plus/**