Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit
395AH7HD,430AM7UD,400AM7DVD,320AM5HD,650GM7UD,416AM7HD,320PM5HD,650PM9HD,480AM7HD,416AM7DVD,500AM7UD,240AM5HD,490AM7H

ZdalaMit Replacement Remote Commander Instruction Manual

Compatible with ATYME TV Models

1. Product Overview

This manual provides detailed instructions for the ZdalaMit Replacement Remote Commander, designed to be fully compatible with a wide range of ATYME TV models. This remote control offers a direct replacement solution, requiring no complex programming for immediate use.



Figure 1: Front view of the ZdalaMit Replacement Remote Commander. This image displays the full layout of the remote control, including the power button, channel and volume controls, navigation pad, number keys, and various function buttons.

2. Setup and Battery Installation

The ZdalaMit Replacement Remote Commander is designed for ease of use, requiring no programming. Simply install the batteries, and the remote will be ready to operate your compatible ATYME TV.

2.1 Battery Requirements

- Requires **2 x AAA size alkaline batteries**.
- Batteries are not included with the remote control.

2.2 Installing Batteries

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely until it clicks into place.

Once batteries are installed, the remote control is ready for immediate use with your ATYME TV.

3. Operating Instructions

This remote commander provides full functionality for your ATYME TV. Below is a general guide to the common buttons and their functions.



Figure 2: Angled view of the ZdalaMit Replacement Remote Commander. This perspective shows the ergonomic shape and the arrangement of buttons, including the power, mute, volume, channel, and input selection keys.

3.1 Key Functions

Button	Function
POWER	Turns the TV on or off.
MUTE	Mutes or unmutes the TV sound.
VOL +/-	Adjusts the volume level up or down.
CH +/-	Changes the TV channel up or down.
INPUT	Selects the input source (HDMI, AV, etc.).
MENU	Opens the TV's main menu.
OK / Navigation Arrows	Navigates through menus and confirms selections.
BACK / EXIT	Returns to the previous screen or exits the current menu.
Number Keys (0-9)	Direct channel input.
Play/Pause/Stop/FF/FR/Prev/Next	Controls for media playback (if supported by TV).
HDMI1, HDMI2, HDMI3	Direct selection of HDMI input sources.

3.2 Compatible ATYME TV Models

This remote control is compatible with the following ATYME TV models:

395AH7HD

430AM7UD

400AM7DVD

320AM5HD

650GM7UD
416AM7HD
320PM5HD
650PM9HD
480AM7HD
416AM7DVD
500AM7UD
240AM5HD
490AM7HD
395AM7DVD
400PM7HD
500PM7HD
320GM5HD
650PM7UD
320AM5DVD
500PM7UD
650AM7UD
550AM7UD
490AM7UD
550PM7UD
550PM8HD
395AM7HD
500AM7HD
400AM7HD

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

4.1 Cleaning

- Wipe the remote control with a soft, dry cloth.
- Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

4.2 Battery Care

- Replace batteries when the remote's responsiveness decreases.
- If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- Dispose of used batteries responsibly according to local regulations.

4.3 Storage

Store the remote control in a cool, dry place, away from direct sunlight, extreme temperatures, and high humidity.

5. Troubleshooting

If you experience issues with your remote control, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Remote is not working.	◦ **Batteries:** Check if batteries are inserted correctly with correct polarity (+/-). Replace old or dead batteries with new AAA alkaline batteries. ◦ **Line of Sight:** Ensure there are no obstructions between the remote control and the TV's infrared sensor. ◦ **Distance:** Make sure you are within the effective range of the TV's IR receiver.
Some buttons are not responding.	◦ **Batteries:** Low battery power can cause intermittent button response. Replace batteries. ◦ **Dirt/Debris:** Clean the remote control, especially around the unresponsive buttons, to ensure no debris is interfering with contact.
Remote works intermittently.	◦ **Batteries:** Batteries may be low. Replace them. ◦ **Interference:** Other electronic devices might be causing interference. Try moving the remote or TV.

If the issue persists after trying these solutions, please refer to the Support section.

6. Specifications

Feature	Detail
Product Dimensions	6 x 2 x 0.5 inches
Item Weight	2 ounces
Battery Type	2 x AAA alkaline batteries (not included)
Compatible Devices	ATYME Televisions (various models listed in Section 3.2)
Color	Black
Special Feature	Ergonomic design

7. Support

For any questions, concerns, or further assistance regarding your ZdalaMit Replacement Remote Commander, please do not hesitate to contact our customer support team. We are committed to providing prompt and helpful service.
Please refer to the contact information provided with your purchase or on the product packaging for the most direct support channels.

© 2023 ZdalaMit. All rights reserved.
Note: ATYME is a registered trademark. This product is a compatible replacement remote control.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CCQVW4L7

More documents and user manuals: **https://manuals.plus/**