Red by Kiss FAN-PT

Red by Kiss Handheld Fan (Model FAN-PT) Instruction Manual

Your guide to optimal use and care.

1. Product Overview

The Red by Kiss Handheld Fan is a portable and rechargeable personal fan designed for convenience and effective cooling. Its compact design and adjustable features make it suitable for various uses, from personal cooling during makeup application to travel and office use.



Image: The Red by Kiss Handheld Fan, illustrating its compact size and dual-use design (handheld or with base).

Key Features:

- **Powerful Airflow:** Features a 30% wider fan size for enhanced cooling.
- **Adjustable Wind Speeds:** Offers three distinct wind speed settings (Low, Medium, High) for personalized comfort.
- **Quick Charging:** Equipped with rapid charging capabilities to minimize downtime.
- **Detachable Base Stand:** Provides versatility for hands-free use on a desk or table.
- **Lightweight and Portable:** Designed for easy carrying and holding, ideal for on-the-go use.

2. Components Included

Upon unboxing your Red by Kiss Handheld Fan, ensure all the following components are present:

- Red by Kiss Handheld Fan unit
- Detachable Base Stand
- USB Charging Cable (Micro-USB)



Image: The fan unit, USB charging cable, and detachable base stand.

3. Setup

3.1. Initial Charging

1. Locate the Micro-USB charging port on the side of the fan handle.
2. Connect the smaller end of the provided USB charging cable to the fan's charging port.
3. Connect the larger end of the USB cable to a compatible USB power source (e.g., computer, wall adapter, power bank).
4. Allow the fan to charge fully before first use. The charging indicator light will typically change or turn off when fully charged.

3.2. Attaching the Detachable Base Stand

1. Align the bottom of the fan handle with the opening on the detachable base stand.
2. Gently push the fan handle into the base until it is securely seated.
3. To remove, pull the fan handle firmly upwards from the base.



Image: The fan's charging port and detachable base, highlighting the quick charging feature.

4. Operating Instructions

4.1. Power On/Off and Speed Adjustment

1. To power on the fan, press the power button located on the handle. The fan will start at the lowest speed setting.
2. To increase the fan speed, press the power button repeatedly. Each press will cycle through the speed settings: Low → Medium → High.
3. To power off the fan, press the power button after the highest speed setting, or press and hold the power button for a few seconds from any speed setting.



Image: The fan highlighting its powerful wind and adjustable wind speeds (Low, Medium, High).

5. Maintenance

5.1. Cleaning

- Ensure the fan is powered off and unplugged before cleaning.
- Use a soft, dry cloth to wipe the exterior of the fan.
- For dust accumulation on the fan blades, use a soft brush or compressed air to gently clean. Do not use water or harsh chemicals directly on the fan.

5.2. Storage

- Store the fan in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, ensure the battery is partially charged (around 50%) to prolong battery life.

6. Troubleshooting

- **Fan not turning on:** Ensure the fan is fully charged. If the issue persists, try charging with a different USB cable or power source.
- **Power button stuck:** Gently press the button multiple times to dislodge any obstruction. Avoid excessive force. If the button remains stuck, contact customer support.
- **Weak airflow:** Check the battery level; a low battery can reduce fan performance. Ensure the fan grille is free from dust or obstructions.
- **Short battery life:** Ensure the fan is fully charged. Battery life can vary based on the speed setting used. Higher speeds consume more power.

7. Specifications

Feature	Specification
Brand	Red by Kiss
Model Name	Beauty Fan (FAN-PT)
Color	Purple
Power Source	Battery Powered
Number of Power Levels	3
Control Method	Touch (Push Button)
Reusability	Rechargeable
Item Weight	7 ounces (0.2 Kilograms)
Product Dimensions	1"D x 7"W x 4"H
Voltage	5 Volts
Wattage	4.5 watts
Number of Blades	4
Indoor/Outdoor Usage	Indoor
Special Feature	Portable

8. Warranty and Support

For warranty information or customer support inquiries, please refer to the product packaging or contact Red by Kiss customer service directly. Specific warranty terms and contact details may vary.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question