Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ULTIMEA U2100

ULTIMEA Nova S40 Sound Bar User Manual

Model: U2100
Brand: ULTIMEA

Introduction

Thank you for choosing the ULTIMEA Nova S40 Sound Bar. This ultra-slim 2.1 channel sound system with a wired subwoofer is designed to enhance your audio experience for TV, PC gaming, and other compatible devices. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new sound bar.

Safety Information

Please read all safety instructions carefully before using this product. Keep this manual for future reference.

- Do not expose this appliance to dripping or splashing liquids.
- Do not place objects filled with liquids, such as vases, on the apparatus.
- Ensure proper ventilation. Do not block any ventilation openings.
- Place the sound bar and subwoofer on a stable, flat surface.
- Use only the power adapter supplied with the unit.
- Unplug the appliance during lightning storms or when unused for long periods.
- Do not attempt to repair or disassemble the unit yourself. Refer all servicing to qualified personnel.

Package Contents

Carefully unpack your ULTIMEA Nova S40 Sound Bar and ensure all items are present:

- ULTIMEA Nova S40 Sound Bar
- Wired Subwoofer
- Remote Control
- HDMI eARC Cable
- Optical Cable
- 3.5mm Audio Cable
- Wall Mount Kit
- Power Adapter
- User Manual (this document)



This image displays the ULTIMEA Nova S40 Sound Bar and its accompanying subwoofer, both packaged and as standalone units, highlighting their sleek design.

Setup

1. Physical Placement

- **Sound Bar:** Place the sound bar directly below your TV, centered for optimal audio alignment. Ensure it is on a stable, flat surface or mounted securely to the wall using the provided kit.
- **Subwoofer:** Position the wired subwoofer near the sound bar, ideally on the floor. Ensure the subwoofer cable can reach the sound bar's "SUB OUT" port.

2. Connecting the Sound Bar

Choose one of the following connection methods:

1. **HDMI (eARC):**

   Connect one end of the HDMI eARC cable to the **HDMI (eARC)** port on the sound bar and the other end to the HDMI eARC/ARC port on your TV. This connection supports high-quality audio and allows TV remote control of the sound bar volume.

2. **Optical (OPT):**

   Connect one end of the Optical cable to the **OPT** port on the sound bar and the other end to the Optical Digital Audio Out port on your TV. Ensure to remove protective caps from the optical cable before connecting.

3. **AUX:**

Connect one end of the 3.5mm Audio cable to the **AUX** port on the sound bar and the other end to the 3.5mm audio output (headphone jack) on your device (e.g., TV, PC, smartphone).

4. **USB:**

   Insert a USB drive into the **USB** port for direct audio playback from compatible files. (Note: Functionality may vary based on file format and USB drive specifications).

5. **Bluetooth 5.3:**

   For wireless connection, select Bluetooth mode on the sound bar. Enable Bluetooth on your device (e.g., smartphone, tablet, laptop) and select "ULTIMEA Nova S40" from the list of available devices to pair.



Detail of the sound bar's rear panel, illustrating the various input ports including AUX, OPT, HDMI (eARC), USB, and DC IN.

3. Power Connection

Connect the power adapter to the **DC IN** port on the sound bar, then plug the adapter into a wall outlet. The subwoofer is wired and connects directly to the sound bar via the **SUB OUT** port.

Operating Instructions

- **Power On/Off:** Press the **Power** button on the remote control or the sound bar to turn the unit on or off.
- **Input Selection:** Press the **Input** button on the remote control or the sound bar to cycle through available input sources (HDMI, Optical, AUX, USB, Bluetooth). The current input will be indicated by an LED light or display.
- **Volume Control:** Use the **Volume Up (+)** and **Volume Down (-)** buttons on the remote control or the sound bar to adjust the master volume.

- **Bluetooth Pairing:** In Bluetooth mode, the sound bar will automatically enter pairing mode. On your device, search for "ULTIMEA Nova S40" and connect. If already paired, it will automatically reconnect when in range.
- **Sound Modes:** The sound bar may feature preset sound modes (e.g., Movie, Music, News). Refer to your remote control for dedicated buttons to switch between these modes for optimized audio.

Maintenance

To ensure the longevity and optimal performance of your ULTIMEA Nova S40 Sound Bar:

- **Cleaning:** Use a soft, dry cloth to wipe the surfaces of the sound bar and subwoofer. Do not use liquid cleaners or aerosol sprays.
- **Storage:** If storing the unit for an extended period, disconnect it from the power outlet and store it in a cool, dry place away from direct sunlight and extreme temperatures.
- **Ventilation:** Ensure that the ventilation openings are not blocked by dust or debris. Regularly check and clean if necessary.

Troubleshooting

If you encounter issues with your sound bar, please refer to the following common problems and solutions:

Problem	Possible Cause / Solution
No sound from the sound bar.	- Ensure the sound bar is powered on. - Check if the correct input source is selected. - Verify all cables (HDMI, Optical, AUX) are securely connected. - Increase the volume on both the sound bar and your TV/device. - Ensure TV audio output is set to external speakers or PCM.
Distorted or poor sound quality.	- Check cable connections for looseness or damage. - Reduce the volume to prevent distortion. - Try a different audio source or input method. - Ensure the subwoofer is properly connected and powered.
Bluetooth pairing fails.	- Ensure the sound bar is in Bluetooth pairing mode. - Turn off Bluetooth on other devices to avoid interference. - Move your device closer to the sound bar. - Forget "ULTIMEA Nova S40" from your device's Bluetooth list and try pairing again.
Remote control not working.	- Check and replace the batteries in the remote control. - Ensure there are no obstructions between the remote and the sound bar's sensor. - Point the remote directly at the sound bar.

Specifications

Feature	Detail
Model Name	U2100
Speaker Type	Soundbar
Surround Sound Channel Configuration	2.1

Feature	Detail
Connectivity Technology	Bluetooth 5.3, HDMI (eARC), Optical, AUX, USB
Audio Output Mode	Dolby Atmos
Speaker Maximum Output Power	200 Watts
Product Dimensions	15.75"D x 6.1"W x 10.63"H
Item Weight	10.25 pounds (4.66 Kilograms)
Included Components	Soundbar, Subwoofer, Remote Control, Cables (HDMI, Optical, 3.5mm Audio), Wall Mount Kit, Power Adapter
Manufacturer	ULTIMEA
Color	Metallic

Warranty and Support

The ULTIMEA Nova S40 Sound Bar comes with a limited warranty. For detailed warranty information, product registration, or technical support, please visit the official ULTIMEA website or contact their customer service. Keep your proof of purchase for warranty claims.

For further assistance, you may also refer to the contact information provided in your product packaging or on the ULTIMEA brand store page on Amazon.

Note: No official seller videos were available for embedding in this manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CD1LJL3C

More documents and user manuals: **https://manuals.plus/**