ZdalaMit ONA18SB001 / 100004120

Replacement Remote Control User Manual

Model: ONA18SB001 / 100004120

Introduction

This manual provides essential information for the operation and maintenance of your new replacement remote control. Designed for seamless compatibility, this remote offers direct control over your Onn 2.0 Channel Soundbar without the need for complex programming.

Compatibility

This replacement remote control is specifically designed to be compatible with the following Onn 2.0 Channel Soundbar models:

- Onn ONA18SB001
- Onn 100004120

No programming or pairing is required for these models; simply insert batteries and begin use.

Product Overview





A black remote control with clearly labeled buttons for power, volume, mute, input selection (AUX, Optical, BT), and media playback controls.

Button Functions

Button	Function

Button	Function
Power ( )	Turns the soundbar on or off.
Mute ( )	Mutes or unmutes the soundbar audio.
VOL-	Decreases the volume level.
VOL+	Increases the volume level.
AUX	Selects the Auxiliary input source.
OPTICAL	Selects the Optical input source.
BT	Selects the Bluetooth input source.
Previous Track ( )	Skips to the beginning of the current track or to the previous track (functionality may vary by soundbar and source).
Play/Pause ( )	Plays or pauses media playback (functionality may vary by soundbar and source).
Next Track ( )	Skips to the next track (functionality may vary by soundbar and source).

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery cover.
3. Insert **1 AAA battery**, ensuring the positive (+) and negative (-) ends align correctly with the markings inside the compartment.
4. Close the battery cover securely.

Note: Always replace all batteries at the same time. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote will not be used for an extended period.

Operating Instructions

Using your replacement remote control is straightforward as it requires no programming. Once batteries are installed, point the remote directly at your Onn 2.0 Channel Soundbar and press the desired function button.

- To turn the soundbar on or off, press the **Power** button.
- To adjust volume, press **VOL+** to increase or **VOL-** to decrease.
- To mute the sound, press the **Mute** button. Press again to unmute.
- To switch input sources (e.g., from TV to Bluetooth), press the corresponding input button: **AUX**, **OPTICAL**, or **BT**.
- For media playback controls (if supported by your soundbar and source), use the **Previous Track**, **Play/Pause**, and **Next Track** buttons.

Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly installed batteries.	Replace batteries with new AAA batteries, ensuring correct polarity.
Remote range is poor.	Weak batteries; Obstruction between remote and soundbar.	Replace batteries. Ensure a clear line of sight to the soundbar's IR receiver.
Specific button not working.	Button malfunction; Soundbar not supporting the function.	Test other buttons. Confirm your soundbar model supports the specific function (e.g., media playback controls).
Remote works intermittently.	Low battery power; Interference.	Replace batteries. Minimize sources of infrared interference.

Specifications

Feature	Detail
Product Dimensions	5.9 x 1.57 x 0.55 inches
Item Weight	0.529 ounces
Batteries Required	1 AAA battery
Brand	ZdalaMit
Special Feature	Ergonomic design
Color	Black
Max Supported Devices	1 (Onn Soundbar)
Compatible Devices	Onn 2.0 Channel Soundbar models ONA18SB001, 100004120

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or sprays.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Remove batteries if the remote is not used for extended periods to prevent leakage.

Warranty and Support

For any queries or support regarding this replacement remote control, please contact the seller or manufacturer directly. Information regarding specific warranty terms may be provided at the point of purchase or by the seller.
Please refer to your original purchase documentation or the seller's contact information for assistance.

© 2024 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question