Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DYNASONIC DYNAPRO-12

DYNASONIC Dynapro 12 Portable Audio System Instruction Manual

Model: DYNAPRO-12

1. Introduction

Thank you for choosing the DYNASONIC Dynapro 12 Portable Audio System. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.



Image 1.1: Front view of the DYNASONIC Dynapro 12 Portable Audio System.

2. Safety Information

To ensure safe operation and prevent damage, observe the following precautions:

- Do not expose the unit to rain or moisture.
- Do not block ventilation openings.
- Avoid placing the unit near heat sources or in direct sunlight.
- Use only attachments/accessories specified by the manufacturer.
- Disconnect the power cord during lightning storms or when unused for long periods.

- Refer all servicing to qualified service personnel.

3. Package Contents

Verify that all items are present in the package:

- DYNASONIC Dynapro 12 Portable Audio System
- Wireless Microphone
- Wired Microphone
- Tablet Stand
- Remote Control
- Charging Cable



Image 3.1: The Dynapro 12 speaker shown with its included accessories.

4. Product Overview

The DYNASONIC Dynapro 12 is a versatile portable audio system designed for various applications. It features a 12-inch speaker, integrated wheels, and an extendable handle for easy transport.


DYNASONIC
Professional Audio

Image 4.1: The Dynapro 12 features an extendable handle and wheels for convenient portability.

5. Setup

5.1 Initial Charging

Before first use, fully charge the internal battery using the provided charging cable. Connect the cable to the power input on the rear panel and plug it into a standard electrical outlet. The charging indicator will illuminate.

5.2 Connecting Devices

The rear panel provides various input options for audio sources and microphones.


GT/VOL
GT IN
MIC IN
USB
TF CARD
TREBLE
MID
BASS
VOLUME
MUSIC INTERVEN
POWER
ON
OFF
ECHO
MIC VOL
ANT
EXT DC 12V IN
DC 15V INPUT
CHAR / FULL
AUX IN
REPLACE ONLY WITH SAME TYPE FUSES!
RECHARGEABLE PRO AUDIO
POWER SUPPLY: 100-240V~,50-60Hz
DYNASONIC
PORTABLE SOUND SYSTEM
DYNA-PRO 12
SPAIN
THERE ARE NO SPARE PARTS INSIDE THIS SPEAKER. IF NECESSARY, SEND IT TO LOCAL SERVICE DEPARTMENTS!
Made in China

Image 5.1: Detailed view of the rear control panel with inputs for USB, SD, microphones, and instruments.

5.3 Attaching the Tablet Stand

The included tablet stand can be mounted on top of the speaker for convenient viewing of mobile devices.

1. Locate the mounting points on the top of the speaker.
2. Securely attach the tablet stand to these points.
3. Place your smartphone or tablet into the stand.



Image 5.2: The Dynapro 12 with a tablet securely placed on the integrated stand.

6. Operating Instructions

6.1 Power On/Off

Press the power button on the rear panel to turn the unit on or off.

6.2 Bluetooth Connectivity

1. Turn on the Dynapro 12.
2. Activate Bluetooth on your mobile device.
3. Search for 'DYNASONIC' in your device's Bluetooth settings.
4. Select 'DYNASONIC' to pair. A confirmation sound will indicate successful pairing.

6.3 USB/SD Playback

1. Insert a USB drive or SD card into the corresponding slot on the rear panel.
2. The system will automatically switch to USB/SD mode and begin playing compatible audio files.
3. Use the control buttons on the rear panel or remote control to navigate tracks and adjust volume.

6.4 FM Radio

1. Press the 'Mode' button on the rear panel or remote control to select FM Radio mode.
2. Press the 'Play/Pause' button to initiate an automatic scan for available stations.
3. Use the 'Previous/Next' buttons to switch between saved stations.

6.5 Microphone Usage

Connect the wired microphone to the designated input. For the wireless microphone, ensure it is powered on and paired according to its specific instructions. Adjust microphone volume and echo effects using the controls on the rear panel.



Image 6.1: The Dynapro 12 can be used with instruments like guitars.

6.6 TWS (True Wireless Stereo) Function

The TWS function allows you to pair two Dynapro 12 speakers for a stereo audio experience.

1. Ensure both Dynapro 12 speakers are powered on and in Bluetooth mode, but not connected to any device.
2. On one speaker (this will be the master), press and hold the TWS button (refer to the rear panel diagram for location).
3. The speakers will attempt to pair with each other. A confirmation sound will indicate successful TWS pairing.
4. Now, connect your mobile device to the master speaker via Bluetooth. Audio will play in stereo through both speakers.



Image 6.2: Visual representation of two Dynapro 12 speakers connected via TWS for stereo sound.



Image 6.3: The Dynapro 12 is suitable for various social gatherings and events.

7. Maintenance

Proper maintenance ensures the longevity of your audio system:

- **Cleaning:** Use a soft, dry cloth to clean the exterior. Do not use abrasive cleaners or solvents.
- **Storage:** Store the unit in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge it regularly, even if not in use for extended periods.

8. Troubleshooting

If you encounter issues, refer to the following table:

Problem	Possible Cause	Solution
No power	Battery discharged; Power cable not connected	Charge the battery; Ensure power cable is securely connected
No sound	Volume too low; Incorrect input mode; Device not paired (Bluetooth)	Increase volume; Select correct input mode; Re-pair Bluetooth device
Bluetooth connection unstable	Device too far; Interference	Move device closer; Avoid obstacles; Turn off other wireless devices
Microphone not working	Microphone off; Volume too low; Incorrect input	Ensure microphone is on; Increase microphone volume; Check microphone input connection

9. Specifications

Detailed technical specifications for the DYNASONIC Dynapro 12:

Feature	Specification
Model Number	DYNAPRO-12
Brand	DYNASONIC

Feature	Specification
Power Output	700 Watts
Speaker Type	Multimedia
Connectivity Technology	Bluetooth, USB
Special Features	TWS Technology, FM Radio, USB/SD Playback, Microphone Inputs
Recommended Use	Smartphone, Tablet
Frequency Response	30 KHz
Product Dimensions (L x W x H)	40 x 61 x 36 cm
Item Weight	8 Kilograms
Battery	1 Lithium-ion (included)
Material	Polyvinyl Chloride (PVC)
Color	Black



Image 9.1: Dimensions of the Dynapro 12 speaker.

10. Warranty and Support

DYNASONIC products are designed for reliability and performance. For warranty information, please refer to the documentation included with your purchase or visit the official DYNASONIC website. For technical support or service inquiries, please contact our customer service team through the contact details provided on the product packaging or website.

© 2023 DYNASONIC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CD7KK6JL

More documents and user manuals: **https://manuals.plus/**