Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fila 38-218-005

Fila Kids Digital Sport Watch 38-218-005 User Manual

Model: 38-218-005

Introduction

This user manual provides comprehensive instructions for the Fila Kids Digital Sport Watch, model 38-218-005. Please read this manual carefully before using your watch to ensure proper operation and to fully utilize its features, including the chronograph, illumination, and perpetual calendar functions.

Product Overview



Image 1: Front view of the Fila Kids Digital Sport Watch 38-218-005. The watch features a white resin case, a digital display, and a white transparent silicone strap with colorful Fila logos. The display shows time, day of the week, and has indicators for PM. Buttons are visible on the sides for various functions.

Watch Components

- **Digital Display:** Shows time, date, and other function indicators.
- **Light Button:** Activates the display illumination. (Typically top-left)
- **Mode Button:** Cycles through different modes (Time, Chronograph, Alarm, etc.). (Typically bottom-left)
- **ST/STP Button:** Start/Stop button for chronograph, or setting adjustment. (Typically top-right)
- **Reset Button:** Resets chronograph, or adjusts setting values. (Typically bottom-right)
- **Resin Case:** Durable white resin case with a stainless steel back.
- **Silicone Strap:** White transparent silicone strap with a pin buckle.

Setup

Setting Time and Date

1. From the normal time display, press the **MODE** button repeatedly until the seconds start flashing. This indicates you are in time setting mode.
2. Press the **RESET** button to zero out the seconds.
3. Press the **MODE** button again to move to the hour setting. The hour digits will flash.
4. Press the **ST/STP** button to adjust the hour. Pay attention to AM/PM indicators if present.
5. Press the **MODE** button to move to the minute setting. The minute digits will flash.
6. Press the **ST/STP** button to adjust the minutes.
7. Continue pressing the **MODE** button to cycle through year, month, and day settings, adjusting each with the **ST/STP** button.
8. Once all settings are complete, press the **MODE** button to return to the normal time display.

Operating Instructions

Basic Time Display

In normal mode, the watch displays the current time (hours, minutes, seconds) and the day of the week. The PM indicator will light up for afternoon hours.

Using the Illumination

Press the **LIGHT** button (typically top-left) to illuminate the digital display. The light will stay on for a few seconds, making it easier to read the time in low-light conditions.

Chronograph (Stopwatch) Function

1. From the normal time display, press the **MODE** button once to enter Chronograph mode. The display will show "00:00:00".
2. Press the **ST/STP** button to start the stopwatch.
3. Press the **ST/STP** button again to pause the stopwatch.
4. To resume, press the **ST/STP** button.
5. To reset the stopwatch to zero, ensure it is paused, then press the **RESET** button.
6. Press the **MODE** button to exit Chronograph mode and return to the normal time display.

Perpetual Calendar

The watch features a perpetual calendar, meaning it automatically adjusts for different month lengths and leap years once the initial date (year, month, day) is set correctly. The day of the week will also update automatically.

Maintenance

Cleaning Your Watch

To clean your watch, wipe it gently with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth. Avoid using chemical cleaners, solvents, or abrasive materials, as these can damage the watch's case, strap, or display.

Water Resistance (3 ATM)

This watch is water resistant up to 3 ATM (30 meters). This means it is suitable for daily use and can withstand splashes or brief immersion in water, such as washing hands or rain. **It is not suitable for showering, swimming, diving, or any activities involving prolonged water immersion or high-pressure water exposure.**

Battery Replacement

The watch is powered by a button cell battery. When the display becomes dim or functions become erratic, it may be time to replace the battery. Battery replacement should ideally be performed by a qualified watch technician to ensure proper sealing and water resistance integrity. Attempting to replace the battery yourself may void the warranty and compromise the watch's water resistance.

Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	Low battery.	Replace the battery.
Time is incorrect.	Time not set correctly or accidental button press.	Refer to the "Setting Time and Date" section to reset the time.
Chronograph not working.	Not in chronograph mode or not reset.	Ensure you are in chronograph mode. Press ST/STP to start/stop, and RESET to clear.
Water inside the watch.	Exceeded water resistance limits.	Immediately take the watch to a qualified technician for inspection and repair to prevent further damage. Do not attempt to dry it yourself.

Specifications

- **Model Number:** 38-218-005
- **Movement:** Digital
- **Case Material:** White Resin and Stainless Steel
- **Case Diameter:** 34 mm
- **Case Thickness:** 14 mm
- **Dial:** Digital, Illuminated

- **Crystal:** Plastic
- **Strap Material:** White Transparent Silicone
- **Clasp Type:** Pin Buckle
- **Water Resistance:** 3 ATM (30 meters)
- **Functions:** Chronograph, Illumination, Perpetual Calendar
- **Product Dimensions:** 21 x 3.5 x 1.3 cm
- **Product Weight:** 70 grams

Warranty and Support

This Fila watch is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including warranty duration and coverage details. Keep your proof of purchase for warranty claims.
For technical support, service, or warranty inquiries, please contact the retailer where you purchased the watch or visit the official Fila Watches website for contact information. When contacting support, please have your watch model number (38-218-005) and proof of purchase readily available.

© 2024 Fila Watches. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CDBQ9SVD

More documents and user manuals: **https://manuals.plus/**