ONGTEED B0CDCJDBCC

ONGTEED Portable AM/FM Radio User Manual

Model: B0CDCJDBCC

Introduction

Thank you for purchasing the ONGTEED Portable AM/FM Radio. This compact and versatile radio is designed to provide clear audio reception for AM and FM bands, along with MP3 playback capabilities via USB and TF card. Its dual power options (rechargeable battery or AA batteries) make it ideal for both home use and on-the-go listening. Please read this manual carefully to ensure proper operation and maintenance of your device.

Safety Information

- Do not expose the radio to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the radio to strong impacts.
- Do not disassemble or attempt to repair the radio yourself. Refer all servicing to qualified personnel.
- Keep the radio away from water and other liquids.
- Dispose of batteries properly according to local regulations.
- When using headphones, keep the volume at a moderate level to prevent hearing damage.

Product Overview

Familiarize yourself with the various parts and controls of your portable radio.



Figure 1: Front View of the Radio. This image displays the main face of the radio, highlighting the tuning dial for AM and FM frequencies, the power indicator light, the large speaker grille, and the function icons at the bottom for Radio, Headphone, USB, and MP3. The extendable antenna is visible on the left side.

Controls and Ports:

- **Tuning Dial:** Used to select AM or FM radio stations.

- **Volume Knob/Power Switch:** Rotates to adjust volume and turns the radio on/off.
- **Band Switch:** Toggles between AM and FM bands.
- **Headphone Jack (3.5mm):** For private listening with headphones.
- **DC 5V IN Port:** For charging the built-in rechargeable battery.
- **USB Port:** For playing MP3 files from a USB flash drive.
- **TF Card Slot:** For playing MP3 files from a TF/Micro SD card.
- **Antenna:** Extendable telescopic antenna for improved FM reception.
- **Battery Compartment:** Holds 2 AA batteries (not included) for alternative power.

Setup

Powering the Radio:

Your radio offers two power options:

1. **Built-in Rechargeable Battery:** The radio comes with a built-in 500mAh rechargeable battery. To charge, connect the supplied USB charging cable to the DC 5V IN port on the radio and the other end to a USB power adapter (not included) or a computer USB port. The power indicator light will illuminate during charging.
2. **AA Batteries:** For portable use without recharging, you can insert two (2) AA batteries (not included) into the battery compartment located on the back of the radio. Ensure correct polarity (+/-) when inserting batteries.



Figure 2: Two Ways for Charging. This image illustrates the two power options for the radio: charging the built-in 500mAh rechargeable battery via a USB cable connected to a power source, and the option to use 2 AA batteries (not shown inserted, but implied by the text).

Operating Instructions

Turning On/Off and Volume Control:

Rotate the volume knob clockwise to turn the radio on and increase the volume. Rotate it counter-clockwise to decrease the volume and turn the radio off.

Radio Operation (AM/FM):

1. Turn on the radio using the volume knob.
2. Select your desired band (AM or FM) using the band switch.
3. For FM reception, extend the telescopic antenna fully for optimal signal. For AM reception, the radio has a built-in AM antenna, so no external antenna adjustment is needed.

4. Rotate the tuning dial to scan for stations. The frequency scale will indicate the current frequency.
5. Adjust the volume to your preferred listening level.



Figure 3: Excellent AM/FM Reception. This image shows the radio positioned near a window with its antenna extended, illustrating how to achieve strong AM and FM reception. A graphic of radio waves emanates from the radio, emphasizing its reception capabilities.



Figure 4: High Quality Speak. This image highlights the radio's sound quality, with musical notes visually representing the audio output from the speaker. A person is shown enjoying the sound, indicating a clear and pleasant listening experience.

Using the Headphone Jack:

To enjoy private listening, plug any standard 3.5mm headphones (not included) into the "PHONE" jack on the side of the radio. The internal speaker will automatically mute when headphones are connected.



Figure 5: 3.5mm Earphone Jack. This image demonstrates the use of the 3.5mm earphone jack for private listening. A person is shown wearing headphones connected to the radio, enjoying audio without disturbing others.

MP3 Playback (USB/TF Card):

The radio supports playing MP3 audio files from a USB flash drive or a TF (Micro SD) card (4-32GB, not included).

1. Insert your USB flash drive into the USB port or your TF card into the TF card slot.
2. The radio should automatically switch to MP3 playback mode. If not, ensure the function switch is set to MP3.
3. Use the track control buttons (if available, typically next/previous) to navigate through your MP3 files.
4. Adjust the volume using the volume knob.



Figure 6: MP3 Audio Player. This image shows the radio with a USB flash drive inserted, demonstrating its capability to play MP3 audio files. The text indicates support for 4-32GB USB flash drives or TF cards.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the radio. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the radio in a cool, dry place. If using AA batteries, remove them to prevent leakage.
- **Battery Care:** Fully charge the built-in battery periodically if not used regularly to maintain its lifespan.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No power/Radio does not turn on.	Battery is depleted or AA batteries are inserted incorrectly/dead.	Charge the built-in battery or replace AA batteries, ensuring correct polarity.
Poor radio reception.	Antenna not extended (FM) or weak signal area.	Fully extend the telescopic antenna for FM. Try moving the radio to a different location.
No sound from speaker/headphones.	Volume too low or headphones not fully plugged in.	Increase volume. Ensure headphones are securely plugged into the jack.
MP3 files not playing.	Incorrect file format, USB/TF card not inserted correctly, or card/drive is corrupted.	Ensure files are in MP3 format. Reinsert USB/TF card. Try a different card/drive.

Specifications

- **Product Dimensions:** 2.7 x 1.3 x 4.9 inches
- **Item Weight:** 3.2 ounces
- **Batteries:** 1 Lithium Ion battery (included, built-in), or 2 AA batteries (not included)
- **Brand:** ONGTEED
- **Color:** White
- **Special Features:** Built-In AM Antenna, Built-in speaker, Lightweight, Rechargeable
- **Connectivity Technology:** USB
- **Tuner Technology:** AM/FM
- **Radio Bands Supported:** AM/FM
- **Included Components:** Owner's Manual, USB Charging Cable

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official ONGTEED website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2024 ONGTEED. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question