Bene Casa BC-99644

Bene Casa 25L Toaster Oven with Double Burner (Model BC-99644) Instruction Manual

Introduction

Thank you for purchasing the Bene Casa 25L Toaster Oven with Double Burner, Model BC-99644. This appliance is designed for versatile cooking, combining the functions of a toaster oven with the convenience of two top burners. Please read this manual thoroughly before operation to ensure safe and efficient use. Keep this manual for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Oversized foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of electric shock.
- A fire may occur if the toaster oven is covered or touching flammable material, including curtains, draperies, walls,

and the like, when in operation.

- Do not place any materials other than manufacturer's recommended accessories in this oven when not in use.
- Do not place any of the following materials in the oven: paper, cardboard, plastic, and similar products.
- Do not cover crumb tray or any part of the oven with metal foil. This will cause overheating of the oven.
- Exercise extreme caution when removing tray or disposing of hot grease.
- Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, creating a risk of electric shock.
- Do not store any materials, other than manufacturer's recommended accessories, in this oven when not in use.

Parts Description

Familiarize yourself with the components of your Bene Casa Toaster Oven:

- **Temperature Control Knob:** Adjusts oven temperature.
- **Function Selector Knob:** Selects cooking mode (e.g., Bake, Broil, Toast).
- **Timer Knob:** Sets cooking time.
- **Power Indicator Light:** Illuminates when the oven is operating.
- **Heating Elements:** Top and bottom elements for even cooking.
- **Oven Rack:** For holding food items.
- **Baking Pan/Tray:** For baking and roasting.
- **Crumb Tray:** Collects crumbs for easy cleaning.
- **Double Burners:** Two electric burners on top for stovetop cooking.
- **Burner Control Knobs:** Individual controls for each top burner.
- **Tempered Glass Door:** Allows viewing of food during cooking.



Image: Front view of the Bene Casa 25L Toaster Oven. A pizza is visible inside the oven cavity on the rack, and a small pot is placed on the left top burner. The control knobs for temperature, function, and timer are visible on the right side of the unit.

Setup and First Use

1. **Unpacking:** Carefully remove the toaster oven from its packaging. Remove all packing materials, including any internal protective inserts.
2. **Placement:** Place the appliance on a stable, heat-resistant, and level surface. Ensure there is at least 4 inches (10 cm) of clearance on all sides and above the oven for proper ventilation. Do not place it near flammable materials.
3. **Cleaning:** Wipe the exterior with a damp cloth. Wash the oven rack, baking pan, and crumb tray in warm, soapy water. Rinse and dry thoroughly. Reinsert the crumb tray at the bottom of the oven.
4. **First Burn-Off:** Before cooking food, operate the oven empty for approximately 15 minutes at the maximum temperature (450°F) on the "Bake" function. This will burn off any manufacturing residues and odors. A slight smoke or odor is normal during this process. Ensure the area is well-ventilated.
5. **Power Connection:** Plug the power cord into a standard 120V AC electrical outlet.

Operating Instructions

Using the Toaster Oven

1. **Prepare Food:** Place food on the oven rack or baking pan.
2. **Insert Food:** Open the tempered glass door and carefully slide the rack with food into the desired position. Close the door.
3. **Select Function:** Turn the **Function Selector Knob** to the desired cooking mode (e.g., Bake, Broil, Toast).
4. **Set Temperature:** Turn the **Temperature Control Knob** to the desired temperature (up to 450°F).
5. **Set Timer:** Turn the **Timer Knob** to the desired cooking time. The power indicator light will illuminate, indicating the oven is operating. For toast, turn the timer past the 10-minute mark and then back to the desired toast shade.
6. **Monitor Cooking:** Observe food through the glass door. The oven will automatically turn off when the timer reaches zero, and a bell will sound.
7. **Remove Food:** Using oven mitts, carefully open the door and remove the cooked food.



Image: Side view of the Bene Casa 25L Toaster Oven with its door open. A whole roasted chicken is visible inside on a baking tray, accompanied by vegetables. The control panel with knobs is visible on the right side.

Using the Double Burners

1. **Place Cookware:** Place appropriate cookware (e.g., pots, pans) on the desired top burner. Ensure cookware is flat-bottomed and suitable for electric stovetops.
2. **Turn On Burner:** Turn the corresponding **Burner Control Knob** to the desired heat setting (Low, Medium, High). The burner will begin to heat up.
3. **Adjust Heat:** Adjust the knob as needed for cooking.

4. **Turn Off:** After use, turn the **Burner Control Knob** back to the "OFF" position. The burner will remain hot for some time after being turned off.

Note: The toaster oven and top burners can be used simultaneously, but this may affect the heating performance of both functions. For optimal results, consider using them independently for demanding tasks.

Care and Maintenance

Regular cleaning and maintenance will ensure the longevity and optimal performance of your appliance.

- **Always unplug the appliance** from the power outlet and allow it to cool completely before cleaning.
- **Crumb Tray:** Slide out the crumb tray from the bottom of the oven. Discard crumbs. Wipe the tray with a damp cloth and dry thoroughly. Reinsert the tray.
- **Oven Rack and Baking Pan:** Wash in warm, soapy water. For stubborn food residue, soak in warm water before cleaning. Rinse and dry completely.
- **Interior:** Wipe the interior walls with a damp cloth and mild detergent. Do not use abrasive cleaners or metal scouring pads, as they can damage the non-stick coating (if applicable) or heating elements.
- **Exterior:** Wipe the exterior surfaces with a damp cloth. Dry thoroughly.
- **Glass Door:** Clean the glass door with a damp cloth and a non-abrasive cleaner.
- **Burners:** The top burners can be wiped clean with a damp cloth once cooled. Do not immerse the entire unit in water.
- **Storage:** Ensure the appliance is clean and dry before storing. Store in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in. Power outlet not working. Timer not set.	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker. Turn the Timer Knob to the desired cooking time.
Oven not heating properly.	Temperature or function knob set incorrectly. Door not fully closed.	Verify that the Function Selector and Temperature Control Knobs are set to the desired settings. Ensure the oven door is completely closed.
Top burners not heating.	Burner control knob not set.	Ensure the individual Burner Control Knob is turned to a heat setting (Low, Medium, High).
Smoke or odor during first use.	Manufacturing residues burning off.	This is normal during the first burn-off. Ensure good ventilation. If smoke persists after initial use, discontinue use and contact customer support.

If the problem persists after trying these solutions, please contact Bene Casa customer support.

Product Specifications

Brand: Bene Casa

Model Number: BC-99644

Capacity: 25 Liters

Product Dimensions (D x W x H): 13" x 16" x 20"

Wattage: 1000 watts

Power Source: AC adapter (120V)

Control Type: Knob

Temperature Range: Up to 450°F

Special Feature: Broiler Option, Double Burners

Included Components: Grill (Oven Rack), Baking Pan, Crumb Tray

Material: Alloy Steel

Door Material: Tempered Glass

Color: Black

Warranty and Support

For warranty information or customer support, please refer to the warranty card included with your product or visit the official Bene Casa website. Please have your model number (BC-99644) and proof of purchase ready when contacting support.

Bene Casa Official Website: Visit Bene Casa Store on Amazon

© 2023 Bene Casa. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question