Ninja TB201

Ninja TB201 Detect Power Blender Pro User Manual

Model: TB201

Introduction

The Ninja Detect Power Blender Pro with BlendSense Technology is designed to simplify your blending experience. This powerful appliance automatically adjusts speed and time to achieve perfectly smooth results, whether you are making smoothies, shakes, frozen drinks, or chopping ingredients for salsa. Its intuitive design and robust motor make it a versatile addition to any kitchen.





Figure 1: Ninja TB201 Detect Power Blender Pro, showcasing its versatility for both blending and chopping ingredients.

Important Safeguards

To reduce the risk of fire, electric shock, or injury, basic safety precautions should always be followed when using any electrical appliance. Please read all instructions before operating your Ninja Detect Power Blender Pro.

- Always ensure the appliance is properly assembled and the lid is securely locked before operation.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils out of the container while blending to prevent serious injury.
- Avoid contact with moving parts.
- Do not blend hot liquids as pressure buildup may result in injury.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.

Getting Started

What's Included

Your Ninja Detect Power Blender Pro package includes the following components:

- 1800 Peak Watt Motor Base
- 72 oz. Pitcher
- Total Crushing & Chopping Blade Assembly
- Pitcher Lid with Pour Spout
- Inspiration Guide with 5 Recipes



Figure 2: Included components of the Ninja Detect Power Blender Pro.

Assembly

Before first use, wash all parts that will come into contact with food in warm, soapy water. Rinse and air dry. The pitcher, lid, and blades are top-rack dishwasher safe.

1. Place the motor base on a clean, dry, level surface.
2. Carefully place the Total Crushing & Chopping Blade Assembly onto the drive gear inside the 72 oz. pitcher. Ensure it is seated properly.
3. Add your ingredients to the pitcher. Do not exceed the MAX LIQUID fill line.
4. Place the lid on the pitcher and press down firmly until it clicks into place. The handle on the lid should align with the handle on the pitcher.
5. Place the assembled pitcher onto the motor base. Rotate the pitcher clockwise until it locks into place with a click. The power light on the motor base will illuminate when correctly assembled.

Operating Instructions

Controls and Functions

The Ninja Detect Power Blender Pro features an intuitive Detect Dial and various modes for optimal blending performance.



Figure 3: The innovative Detect Dial provides precise program indication and real-time feedback.

The Detect Dial illuminates to indicate the current mode and progress. The display shows the selected program and remaining time.

BlendSense Technology

BlendSense is Ninja's smartest technology, designed to automatically adjust blending speed and time for perfectly smooth results. It senses the ingredients, detects whether they are fresh or frozen, and adjusts the blending process accordingly.



Figure 4: How BlendSense Technology intelligently adapts to your ingredients.

Smart Detection Features

- **Ice Detect:** This feature auto-calibrates the blender's power to effectively process ice, ensuring perfectly smooth frozen drinks.



Figure 5: Ice Detect ensures optimal blending for icy beverages.

- **Portion Detect:** The blender actively adjusts the blending time and speed based on the amount of ingredients in the pitcher, optimizing performance for various batch sizes.



Figure 6: Portion Detect adapts blending to ingredient volume.

- **Torque Detect:** This function identifies whether ingredients are fresh or frozen and automatically boosts power as needed to maintain consistent blending performance.




Figure 7: Torque Detect ensures consistent power for various ingredient types.

Preset Programs and Manual Control

- **Single-Touch Preset Programs:** Utilize one-touch Chop programs to process and chop ingredients directly in the 72 oz. pitcher. Ideal for preparing items like salsa, pesto, and more.



Figure 8: One-touch chopping programs simplify food preparation.

- **Variable Speed Control:** For complete manual control, use the variable speed settings (1-10) to achieve your desired texture and consistency. This feature is available when using the Full-Size Pitcher.




Figure 9: Variable speed control allows for customized blending results.

- **Total Crushing & Chopping Blades:** The powerful 1800 peak watt motor combined with the Total Crushing & Chopping Blades can turn ice into snow, making it perfect for smoothies and frozen drinks.



Figure 10: The Total Crushing & Chopping Blades deliver exceptional ice crushing power.

General Blending Tips

- Always add liquids first, then soft ingredients, followed by harder ingredients and ice.
- Do not overfill the pitcher beyond the MAX LIQUID line.
- For best results, use the recommended settings or allow BlendSense Technology to automatically optimize your blend.

Care and Maintenance

Proper care and maintenance will ensure the longevity and optimal performance of your Ninja Detect Power Blender Pro.

Cleaning

All containers, lids, and blade assemblies are top-rack dishwasher safe. For manual cleaning, wash components in warm, soapy water using a non-abrasive cleaning brush to avoid damage to the blades.




Figure 11: Blender components are designed for easy cleaning in a dishwasher.

- Wipe the motor base clean with a damp cloth. Do not immerse the motor base in water.
- Store the blender with the pitcher assembled on the base or with components stored separately in a safe place.

Troubleshooting

If you encounter any issues with your Ninja Detect Power Blender Pro, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; pitcher not assembled correctly; lid not secured.	Ensure power cord is securely plugged into outlet. Verify pitcher is locked onto base and lid is securely closed.

Problem	Possible Cause	Solution
Ingredients are not blending smoothly.	Too many ingredients; not enough liquid; ingredients are too large.	Reduce ingredient quantity. Add more liquid. Cut larger ingredients into smaller pieces. Use Pulse function to break down large chunks.
Motor stops during operation.	Overheating due to prolonged use or overloading.	Unplug the unit and allow it to cool for at least 15 minutes. Remove some ingredients if overloaded.

Specifications

Feature	Detail
Brand	Ninja
Model Number	TB201
Color	Silver
Special Feature	Adjustable Speed Control, Multiple Speeds, Pour Spout, Removable Blade
Capacity	72 Fluid Ounces
Product Dimensions	6.88"D x 8.38"W x 17.5"H
Style	Power Blender
Recommended Uses	Blending, Juices, Pureeing
Power Source	AC/DC
Number of Speeds	2 (plus variable control)
Voltage	120.0 V
Controls Type	Push Button, Dial
Material Type Free	BPA Free
Blade Material	Stainless Steel
Item Weight	8.58 pounds

Warranty and Support

The Ninja TB201 Detect Power Blender Pro comes with a**1 Year Limited Warranty**. For warranty claims, technical support, or replacement parts, please contact Ninja customer service. Refer to the contact information provided in your product packaging or visit the official Ninja website.

For additional resources and product information, you may visit theNinja Store on Amazon.

© 2023 Ninja. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question