Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Pemberly Row PR-4753-2131399

Pemberly Row Modern Rectangular Extendable Dining Table

Model: PR-4753-2131399

Introduction

Thank you for choosing the Pemberly Row Modern Rectangular Extendable Dining Table. This manual provides essential information for the safe assembly, operation, maintenance, and care of your new dining table. Please read these instructions thoroughly before beginning assembly and retain them for future reference.



Image: The Pemberly Row Modern Rectangular Extendable Dining Table shown in its compact configuration, featuring a black finish and a central glass insert.

Safety Information

- **Read all instructions:** Ensure you understand all assembly steps and safety warnings before proceeding.
- **Two-person assembly:** Assembly of this dining table is recommended with two adults to prevent injury and damage.
- **Use correct tools:** Only use the tools specified in the assembly instructions.

- **Level surface:** Assemble the table on a soft, clean, and level surface to prevent scratches or damage.
- **Weight limit:** Do not place excessive weight on the table surface.
- **Children and pets:** Keep children and pets away from the assembly area. Small parts can be a choking hazard.
- **Regular checks:** Periodically check all connections and fasteners to ensure they remain tight.

Setup and Assembly

Follow these steps for proper assembly of your dining table. Ensure all parts are present before you begin.

Parts List:

- Tabletop (1)
- Legs (4)
- Breadboard Leaves (2)
- Hardware pack (screws, washers, Allen wrench)

Assembly Steps:

1. Carefully unpack all components and lay them out on a soft, clean surface to prevent scratching.
2. Attach each of the four legs to the underside of the tabletop using the provided screws and Allen wrench. Ensure all connections are secure but do not overtighten.
3. Once all legs are attached, carefully turn the table upright. It is recommended to have two people for this step.
4. Adjust the levelers on the bottom of each leg to ensure the table is stable and does not wobble.
5. The breadboard leaves can be inserted or removed as needed (refer to the "Operating Instructions" section for details).



Image: An end view of the dining table, illustrating the design of the legs and their attachment points to the tabletop.

Operating Instructions

Extending the Table:

Your Pemberly Row dining table features two removable breadboard leaves, allowing you to extend its length from 76 inches to 100 inches.

1. To extend the table, gently pull the two halves of the tabletop apart from each end. The metal guide system will facilitate this movement.
2. Once separated, insert one or both breadboard leaves into the gap created. Ensure the leaves are properly aligned with the tabletop and seated securely.
3. Push the tabletop halves back together until they are flush with the inserted leaves, creating a continuous surface.

Retracting the Table:

1. To retract the table, pull the tabletop halves apart slightly.
2. Carefully lift and remove the breadboard leaves. Store them in a safe place to prevent damage.
3. Push the two main tabletop halves back together until they meet, forming the compact table configuration.



Image: A top-down view of the dining table, demonstrating its extended configuration with the breadboard leaves in place, revealing the central glass insert and fractal pattern.

Maintenance and Care

Proper care will ensure the longevity and beauty of your Pemberly Row dining table.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Clean spills immediately to prevent staining, especially on wood and glass surfaces.
- **Heat and Moisture:** Use coasters and placemats to protect the tabletop from hot items and moisture.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.
- **Moving:** When moving the table, always lift it rather than dragging it to prevent damage to the legs and floor.
- **Fasteners:** Periodically check and tighten all screws and bolts to maintain structural integrity.



Image: A detailed close-up of the table's surface, highlighting the clear glass insert with its fractal pattern and the texture of the wood grain.

Troubleshooting

Problem	Possible Cause	Solution
Table wobbles	Uneven floor or loose leg connections.	Adjust the levelers on the bottom of the legs. Ensure all leg screws are tightened securely.
Difficulty extending/retracting leaves	Mechanism obstruction or misalignment.	Check for any debris in the metal guide. Ensure leaves are inserted correctly and aligned before pushing tabletop halves together.
Scratches on surface	Sharp objects or abrasive cleaning.	Use placemats and coasters. Avoid dragging objects across the surface. For minor scratches, consult a furniture repair specialist.

Specifications

Feature	Detail
Brand	Pemberly Row

Feature	Detail
Model Number	PR-4753-2131399
Dimensions (Compact)	76" L x 44" W x 30" H
Dimensions (Extended)	100" L x 44" W x 30" H
Material	Wood, Metal, Glass
Finish	Black (Nocturn Black and Coventry Grey)
Weight	145.5 pounds
Extension Type	2 removable breadboard leaves (12" each)
Special Features	Clear glass in top center, metal guide, metal caps on feet, levelers.

Warranty and Support

For warranty information and customer support, please refer to the product description on the original purchase platform or visit the official Pemberly Row store page.
Pemberly Row Store: Visit the Pemberly Row Store on Amazon
Please have your model number (PR-4753-2131399) and purchase details ready when contacting support.

© 2026 Pemberly Row. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CDLZ8ZJJ

More documents and user manuals: **https://manuals.plus/**