Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kircuit ONA13AV504

Kircuit AC/DC Adapter for Onn ONA13AV504 Cassette Recorder Player User Manual

This manual provides essential instructions for the safe and effective use of your Kircuit AC/DC Adapter, designed for the Onn ONA13AV504 Cassette Recorder Player.

1. Introduction

Thank you for choosing the Kircuit AC/DC Adapter. This power supply is specifically designed to provide reliable power to your Onn ONA13AV504 Cassette Recorder Player. It converts standard AC wall power into the DC power required by your device, enabling operation or battery charging. Please read this manual thoroughly before use to ensure proper setup and operation.

2. Safety Information

- **Read all instructions:** Before using the adapter, read and understand all safety and operating instructions.
- **Proper Voltage:** Ensure the wall outlet voltage matches the input voltage range specified on the adapter (100V-240V AC).
- **Indoor Use Only:** This adapter is designed for indoor use. Do not expose it to rain, moisture, or extreme temperatures.
- **Avoid Damage:** Do not use the adapter if the cord or plug is damaged. Do not attempt to open or repair the adapter. Refer all servicing to qualified personnel.
- **Ventilation:** Ensure adequate ventilation around the adapter during use. Do not cover it with cloths or place it in enclosed spaces.
- **Children and Pets:** Keep the adapter out of reach of children and pets.
- **Unplug When Not in Use:** Disconnect the adapter from the power outlet when not in use for extended periods.

3. Product Overview

The Kircuit AC/DC Adapter is a compact and reliable power solution. It features a standard 2-pin AC plug for wall outlets and a DC output connector compatible with the Onn ONA13AV504 Cassette Recorder Player.



Figure 3.1: Front view of the Kircuit AC/DC Adapter, showing the input specifications and the attached DC output cord.

The adapter is designed for portability, making it suitable for use at home, in the office, or while traveling. It incorporates built-in dynamic IC, charger IC, and a power fuse for efficient and safe charging, including overcharge protection.

4. Setup Instructions

1. **Verify Compatibility:** Ensure your device, the Onn ONA13AV504 Cassette Recorder Player, requires the specified voltage and current output of this adapter.
2. **Connect to Device:** Carefully insert the DC output plug of the Kircuit adapter into the power input jack of your Onn ONA13AV504 Cassette Recorder Player. Ensure a snug fit.
3. **Connect to Power Outlet:** Plug the 2-pin AC input plug of the adapter into a standard wall power outlet (100V-240V AC).
4. **Power On:** Once connected, your device should receive power. If your device has a power indicator, confirm it illuminates.



Figure 4.1: The Kircuit AC/DC Adapter connected to a power strip, ready for use.

5. Operating Instructions

Once the Kircuit AC/DC Adapter is properly connected to both the power outlet and your Onn ONA13AV504 Cassette Recorder Player, the device will receive continuous power. You can then operate your cassette recorder player as usual, following its own operational guidelines. If your device has a rechargeable battery, the adapter will also facilitate charging.

- **Continuous Power:** The adapter provides stable power for extended use of your device.
- **Battery Charging:** If your device supports battery charging via its power input, the adapter will charge the battery while connected.
- **Overcharge Protection:** The adapter includes built-in overcharge protection to safeguard your device's battery.

6. Maintenance

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture. Avoid tightly wrapping the cord to prevent damage.
- **Inspection:** Periodically inspect the adapter, cord, and plugs for any signs of damage, such as fraying, cuts, or bent pins. If damage is found, discontinue use and replace the adapter.

7. Troubleshooting

Problem	Possible Cause	Solution
Device not powering on or charging.	• Adapter not properly plugged into outlet. • DC plug not fully inserted into device. • Power outlet is not active. • Adapter or device malfunction.	• Ensure both ends of the adapter are securely connected. • Test the power outlet with another device. • Try a different power outlet. • If issues persist, contact customer support.
Adapter feels unusually hot.	• Poor ventilation. • Overload or internal fault.	• Ensure the adapter is in an open area with good airflow. • Disconnect immediately and discontinue use. Contact customer support.

8. Specifications

Brand	Kircuit
Model Compatibility	Onn ONA13AV504 Cassette Recorder Player
Input Voltage	100V-240V AC, 50/60Hz 0.3A
Output Current	0.3A (Output voltage matches device requirement)
Power Source	Corded Electric
Main Power Connector Type	2 Pin (US Standard)
Cord Length	Approximately 6.5 ft (2 meters)

Special Feature	Travel-friendly design, Overcharge Protection
Manufacturer	Shenzhen Waweis Technology Co., Ltd



Figure 8.1: The Kircuit AC/DC Adapter highlighting its cord length.

9. Warranty and Support

Specific warranty details are typically provided at the point of purchase or with the product packaging. For any technical support, troubleshooting assistance beyond this manual, or warranty inquiries, please refer to the contact information provided by your retailer or the manufacturer, Kircuit.

You may also visit the product page on Amazon for additional information or to contact the seller, LGM DYstore.

© 2023 Kircuit. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CDPWMCFM

More documents and user manuals: **https://manuals.plus/**