Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VASAGLE LSD172W01

VASAGLE Electric Standing Desk LSD172W01 User Manual

Model: LSD172W01

INTRODUCTION

Thank you for choosing the VASAGLE Electric Standing Desk LSD172W01. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read it thoroughly before use and keep it for future reference.



Image: The VASAGLE Electric Standing Desk in a home office environment, showcasing its design and functionality.

Safety Information

To ensure safe operation and prevent damage, please observe the following precautions:

- Do not place the desk directly against a wall to avoid scratching the wall during height adjustment.
- Use the product indoors only. Ensure all electronic accessories do not come into contact with liquids.

- After continuous adjustment for 2 minutes, do not change the position for at least 18 minutes to prevent motor damage.
- To protect the tabletop from impacts and scratches, adjust the integrated sensor to a higher value to detect obstacles during height adjustment.
- Do not disassemble any parts of this product without professional advice.
- The maximum static load capacity of the desk is 80 kg (176 lbs). Do not exceed this limit.
- Do not use power outlets or adapters with excessively high voltage.

Package Contents

Verify that all components are present before assembly:

- 1 x Electric Desk
- 1 x Adapter
- 1 x Control Panel
- 1 x Storage Pouch
- 1 x Double Hook
- 1 x Assembly Kit (includes necessary screws and tools)
- 1 x User Manual (this document)

Setup and Assembly

Assembly requires two people. Follow the illustrated instructions provided in the assembly kit. Ensure all numbered parts are correctly identified and installed.

Key Assembly Features:

- **Robust Construction:** The desk features double bars and steel legs for stability, supporting up to 80 kg.
- **Adjustable Feet or Casters:** The steel feet come with adjustable glides, which can be replaced with four universal casters (sold separately or included in some packages) for mobility.
- **Cable Management:** Includes a shelf for power strips and two cable holes to keep your workspace tidy.



Image: A diagram illustrating the desk dimensions (120 cm width, 60 cm depth, 72-120 cm height) and the robust two-post support frame.



Image: Demonstrates the desk's 80 kg load capacity and the two options for the base: universal casters for mobility or adjustable feet for static stability.

Operating Instructions

Control Panel Functions:

The multifunctional control panel allows for easy height adjustment and includes memory presets and a USB charging port.

- **Height Adjustment:** Use the up and down arrows to adjust the desk height continuously between 72 cm (28.3 inches) and 120 cm (47.2 inches). The adjustment speed is approximately 35 mm/s.
- **Memory Presets (M1, M2, M3, M4):** Save up to four preferred height settings. To save a height, adjust the desk to the desired level, then press and hold one of the memory buttons (M1-M4) until the display flashes or beeps.
- **USB Port:** A convenient USB port is integrated into the control panel for charging your phone or other devices.
- **LED Display:** Shows the current desk height in centimeters.



Image: Detailed view of the control panel, highlighting the USB charging port, height adjustment arrows, four memory preset buttons, and the digital LED height display.



Image: Illustrates the desk's height adjustment range (Min. 72 cm, Max. 120 cm) with a user sitting and another standing. Also highlights low noise operation (<50 dB), 35 mm/s adjustment speed, and a high-quality motor.

Anti-Collision Protection:

For safety, the desk is equipped with an anti-collision mechanism. If the tabletop encounters an obstacle during adjustment, the mechanism will stop and slightly retract the desk to prevent damage.



Image: Visual explanation of the anti-collision feature, showing the desk stopping and reversing when an obstruction is detected. Note: This feature activates only when the tabletop hits a hard obstacle.

Accessories:

- **Storage Pouch:** A flexible fabric organizer pouch can be attached to either the left or right side of the desk, ideal for books, notebooks, pens, and other small items.
- **Double Hook:** A reversible double hook provides additional space to hang headphones, bags, or charging cables.



Image: Close-up of the desk's accessories: a flexible fabric organizer pouch for stationery and a double hook for hanging headphones, bags, or cables.

Maintenance

- **Cleaning:** Wipe the desk surfaces with a dry cloth. Avoid abrasive cleaners or harsh chemicals.
- **Liquid Contact:** Keep all electronic components away from liquids. In case of spills, immediately unplug the desk and wipe thoroughly.

- **Regular Checks:** Periodically check all screws and connections to ensure they are tight.
- **Motor Care:** Adhere to the usage guidelines regarding continuous adjustment to prolong motor life (no more than 2 minutes continuous adjustment, then rest for 18 minutes).

Troubleshooting

If you encounter issues, refer to the following common solutions:

Problem	Possible Cause	Solution
Desk does not move / "RST" on display	Initialization required or power interruption.	Press and hold the down arrow button until the desk reaches its lowest point, then slightly rises and stops, possibly with a beep. This resets the system.
Desk stops during adjustment	Anti-collision sensor activated or motor overheating.	Check for obstacles. If no obstacle, allow the motor to cool down for at least 18 minutes if it has been used continuously for 2 minutes. Adjust the anti-collision sensor sensitivity if needed.
Unstable desk	Uneven floor or loose connections.	Adjust the leveling feet to ensure stability. Check and tighten all assembly screws. Ensure the load does not exceed 80 kg.
USB port not charging	Cable issue or device incompatibility.	Ensure the USB cable is properly connected. Try a different device or cable to rule out compatibility issues.

If problems persist, please contact customer support.

Specifications

Model Number	LSD172W01
Brand	VASAGLE
Dimensions (D x W x H)	60 x 120 x (72-120) cm (23.6" x 47.2" x 28.3"-47.2")
Minimum Height	72 cm (28.3 inches)
Maximum Height	120 cm (47.2 inches)
Materials	Particleboard, Steel, Oxford Fabric
Color	Cloud White
Max. Static Load Capacity	80 kg (176 lbs)
Lift Mechanism	Electric
Adjustment Speed	35 mm/s
Noise Level	< 50 dB
Assembly Required	Yes (2 people recommended)
Care Instructions	Wipe with a dry cloth

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official VASAGLE website. Keep your proof of purchase for any warranty claims.

Online Resources: Visit the VASAGLE Store on Amazon

© 2024 VASAGLE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CF2CB96N

More documents and user manuals: **https://manuals.plus/**