ZdalaMit 100002634

ZdalaMit 100002634 Replacement Remote Control for ONN Soundbar User Manual

Model: 100002634

Introduction

This manual provides instructions for the ZdalaMit 100002634 Replacement Remote Control, designed for use with the ONN Soundbar model 100002634. Please read this manual carefully before using the remote control to ensure proper operation and longevity.

Compatibility: This remote control is compatible with ONN Soundbar model 100002634.

Product Overview





Figure 1: Front view of the ZdalaMit 100002634 Replacement Remote Control.

The ZdalaMit 100002634 is a dedicated replacement remote control. It features a standard layout for soundbar functions, including power, volume, input selection, and sound mode controls.

Package Contents:

- 1 x ZdalaMit 100002634 Replacement Remote Control

Note: Batteries are not included and must be purchased separately.

Setup

Installing Batteries

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two (2) AAA size alkaline batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

No programming is required for this remote control. Once batteries are installed, it is ready for use with your compatible ONN Soundbar 100002634.

Operating Instructions

The remote control provides direct access to various functions of your ONN Soundbar. Below is a description of the main buttons:

Button	Function
Power ( )	Turns the soundbar on or off.
Mute ( )	Mutes or unmutes the soundbar audio.
VOL+	Increases the main volume.
VOL-	Decreases the main volume.
SUB+	Increases the subwoofer volume.
SUB-	Decreases the subwoofer volume.
HDMI	Selects the HDMI input source.
Bluetooth ( )	Selects the Bluetooth input source.
Input Source (⏎)	Cycles through available input sources (e.g., Optical, AUX, USB).
Sound Mode	Cycles through different sound modes (e.g., Movie, Music, News).
EQ (♫)	Adjusts equalizer settings or sound presets.
Playback Controls (Play/Pause, Skip Forward, Skip Back)	Controls media playback when using compatible sources like Bluetooth or USB.

Note: Specific button functions may vary slightly depending on your soundbar's firmware and capabilities.

Maintenance

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops functioning. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these may damage the remote's surface or internal components.

Storage

If the remote control will not be used for an extended period, it is recommended to remove the batteries to prevent leakage and potential damage.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the soundbar's infrared receiver.
  - Make sure you are within the effective range of the soundbar's IR receiver.
- **Specific buttons not working:**
  - This remote is pre-programmed for the ONN Soundbar 100002634. If certain functions are not working, verify that your soundbar model is indeed 100002634.
  - Ensure the soundbar is powered on and not in a standby mode that restricts certain functions.

Specifications

- **Brand:** ZdalaMit
- **Model:** 100002634
- **Compatible Devices:** ONN Soundbar 100002634
- **Power Source:** 2 x AAA Batteries (not included)
- **Dimensions:** 6 x 2 x 0.5 inches (approximately)
- **Item Weight:** 2 ounces (approximately, without batteries)
- **Special Feature:** Pre-programmed
- **Color:** Black

Support

For any questions or further assistance regarding your ZdalaMit 100002634 Replacement Remote Control, please contact the seller or manufacturer. Refer to your purchase documentation for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question