Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JIGATONEDA 2301SF1T1R

JIGATONEDA Wireless Self-Powered Doorbell

Model: 2301SF1T1R

1. Introduction

Thank you for choosing the JIGATONEDA Wireless Self-Powered Doorbell. This system provides a convenient and reliable solution for your home or office. Featuring self-powered technology, it requires no batteries for the transmitter, ensuring a long lifespan and eco-friendly operation. The doorbell is designed to be waterproof and offers an extended wireless range, multiple chime options, and adjustable volume levels to suit your needs.

This manual provides detailed instructions for installation, operation, and maintenance of your doorbell system. Please read it carefully before use and retain it for future reference.

2. Package Contents

Please verify that all components are present in your package:

- 1 x Doorbell Button (Transmitter)
- 1 x Backplate for Transmitter
- 2 x Adhesive Tapes
- 2 x Receivers
- 2 x Screws
- 2 x Anchors
- 1 x User Manual
- 1 x Waterproof Cover for Transmitter



Image: All components included in the JIGATONEDA Wireless Doorbell package.

3. Setup and Installation

The JIGATONEDA Wireless Doorbell is designed for quick and easy installation. No wiring or batteries are required for the push button (transmitter).

3.1 Transmitter (Push Button) Installation

1. **Choose Location:** Select a suitable location for the doorbell button, typically near your entrance. Ensure the surface is clean and dry.
2. **Attach Waterproof Cover:** If desired, attach the waterproof cover to the wall using the provided adhesive tape or screws. This provides additional protection against the elements.
3. **Prepare Transmitter:** Tear off the protective film from one side of the adhesive tape and stick it firmly onto the back of the doorbell button (transmitter).

4. **Mount Transmitter:** Align the doorbell button with the waterproof cover (if used) or directly onto the chosen wall surface. Press firmly for 30 seconds to ensure secure attachment. Alternatively, use the provided screws and anchors for a more permanent installation.



Image: Visual guide for seamless installation of the doorbell transmitter.

3.2 Receiver Installation

Simply plug the receiver into any standard electrical outlet within the wireless range of the transmitter. For optimal performance, avoid plugging it into outlets obstructed by large metal objects or thick walls.



Image: The compact receiver plugged into a wall socket.

3.3 Pairing (If Needed)

The doorbell system is typically pre-paired at the factory. If re-pairing is necessary or if you add additional transmitters/receivers:

1. Plug in the receiver.
2. Press and hold the volume button on the receiver for 3-5 seconds until the LED indicator flashes.
3. Immediately press the doorbell button (transmitter). The receiver will chime, indicating successful pairing.

Your browser does not support the video tag.

Video: Demonstrates the installation process and basic operation of the JIGATONEDA Wireless Doorbell.

4. Operating Instructions

Your JIGATONEDA Wireless Doorbell offers various customizable settings.

4.1 Chime Selection

The receiver offers 50 unique melodies. To change the chime:

- Press the **Chime Selection** button (usually a music note icon) on the receiver to cycle through the available melodies.
- Once you hear your desired chime, stop pressing. The receiver will save this selection.



Image: The receiver with controls for selecting from 50 chimes and adjusting volume.

4.2 Volume Adjustment

There are 4 adjustable volume levels, ranging from 0 dB (mute) to 110 dB.

- Press the **Volume** button (usually a speaker icon) on the receiver to cycle through the volume levels.
- Each press will adjust the volume.

4.3 Mute Mode and LED Indicator

The doorbell features a mute mode (0 dB) and an LED flash indicator.

- To activate mute mode, press the **Volume** button until the volume reaches 0 dB. The LED indicator will still flash when the doorbell is pressed, providing a visual alert.
- The LED indicator also flashes with each chime, providing a visual cue for visitors.



Image: The receiver illustrating various working modes, including mute with LED flash.

4.4 Memory Function

The doorbell system retains your last selected chime and volume settings even after a power outage, thanks to its built-in memory function.

5. Maintenance

To ensure the longevity and optimal performance of your JIGATONEDA Wireless Doorbell, follow these simple

maintenance guidelines:

- **Cleaning:** Wipe the doorbell button and receiver with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these can damage the finish or internal components.
- **Waterproof Protection:** The doorbell button is designed to be waterproof. However, for extreme weather conditions, ensure the waterproof cover is properly installed and free from damage.
- **Avoid Obstructions:** Periodically check that there are no new obstructions (e.g., large metal objects, new walls) between the transmitter and receiver that could interfere with the wireless signal.



Image: The waterproof design of the doorbell transmitter, ready for various weather conditions.

6. Troubleshooting

If you encounter any issues with your doorbell system, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Doorbell does not ring	Receiver not powered on	Ensure the receiver is securely plugged into a working electrical outlet.
	Out of wireless range	Move the receiver closer to the transmitter. The maximum range is 1000ft (300m) in open areas.
	Transmitter and receiver not paired	Follow the pairing instructions in Section 3.3.
Weak or intermittent signal	Obstructions between units	Thick walls, metal objects, or other electronic devices can interfere. Try relocating the receiver or transmitter.
	Distance too great	Reduce the distance between the transmitter and receiver.
LED flashes but no sound	Mute mode activated	Press the **Volume** button on the receiver to increase the volume level.

If the problem persists after trying these solutions, please contact customer support.

7. Specifications

Feature	Description
Brand	JIGATONEDA
Model Number	2301SF1T1R
Product Dimensions	8.61 x 6.81 x 3.71 cm (Transmitter); 195.04 g (Total Weight)
Color	White
Power Source (Transmitter)	Self-powered (No batteries required)
Power Source (Receiver)	AC Plug-in
Wireless Range	Up to 1000 ft (300 m) in open areas
Chimes/Melodies	50 unique melodies
Volume Levels	4 adjustable levels (0 dB to 110 dB)
Waterproof Rating (Transmitter)	Yes, with included waterproof cover
Operating Temperature	-4°F (-20°C) to 140°F (60°C)
Special Features	LED indicator, Memory function

8. Warranty and Support

JIGATONEDA offers a **3-year warranty** for this product, covering manufacturing defects and malfunctions under normal use. Additionally, **24-hour customer service** is available to assist you with any questions or issues.

If you require assistance, please contact our customer support team through the retailer's platform or visit the official JIGATONEDA website for contact information. Please have your model number (2301SF1T1R) and purchase details ready when contacting support.

© 2026 JIGATONEDA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CFF45GXT

More documents and user manuals: **https://manuals.plus/**