Mayer MMIWD4008

Mayer 4L Instant Heating Water Dispenser with Filter

USER MANUAL

1. Introduction

Thank you for choosing the Mayer 4L Instant Heating Water Dispenser with Filter (Model: MMIWD4008). This appliance is designed to provide instant hot water with convenience and efficiency, featuring a built-in UK Aqua Optima (Strix) filter for enhanced water quality. Please read this manual thoroughly before operation to ensure safe and optimal use of your new water dispenser.



Figure 1: Mayer 4L Instant Heating Water Dispenser with included filter cartridge.

2. Safety Precautions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using electrical appliances. This section outlines critical safety information.

- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children. The child lock feature should always be engaged when not in use.
- Do not operate the appliance if the power cord or plug is damaged, or if the appliance malfunctions or has been damaged in any manner.
- Place the appliance on a stable, flat, heat-resistant surface, away from direct sunlight and heat sources.
- Do not fill the water tank beyond the 'MAX' level.
- Always unplug the appliance before cleaning or when not in use for extended periods.
- Be cautious of hot steam and hot water during operation and dispensing.
- Only use the appliance for its intended purpose of heating and dispensing water.

3. Product Components

Familiarize yourself with the main parts of your Mayer Instant Heating Water Dispenser:

1. **Control Panel:** Sensor touch panel with LED display for temperature, volume, and status indicators.
2. **Water Outlet:** Where hot water is dispensed.
3. **Detachable Water Tank:** 4-liter capacity for water storage, includes filter housing.
4. **UK Aqua Optima (Strix) Filter:** Filters water to remove impurities.
5. **Detachable Drip Tray:** Collects any spills or drips for easy cleaning.
6. **Power Cord:** For connecting to an electrical outlet.



Figure 2: Front view highlighting the control panel and water outlet.



Figure 3: Side view illustrating the detachable water tank and its capacity markings.

4. Setup

Follow these steps to set up your water dispenser for first use:

1. **Unpacking:** Carefully remove all packaging materials. Retain packaging for future storage or transport.
2. **Placement:** Place the appliance on a dry, stable, and level surface. Ensure there is adequate space around the unit for ventilation.
3. **Install Drip Tray:** Slide the detachable drip tray into its designated slot at the base of the dispenser.
4. **Install Filter:** Open the lid of the water tank. Insert the UK Aqua Optima (Strix) filter cartridge into its housing within the water tank. Ensure it is securely seated.
5. **Fill Water Tank:** Fill the detachable water tank with clean, potable water up to the 'MAX' line. Avoid overfilling.
6. **Initial Rinse:** For first use, it is recommended to dispense at least 500ml of water at 1000C to rinse the internal components. Discard this water.

5. Operating Instructions

The Mayer Instant Heating Water Dispenser features a user-friendly sensor touch control panel.

1. **Power On:** Plug the power cord into a suitable electrical outlet. The LED display will illuminate.
2. **Child Lock:** The child lock feature is automatically engaged after a period of inactivity. To unlock, touch and hold the 'Lock' icon until it disengages. Always re-engage the child lock when not actively dispensing.
3. **Select Temperature:** Touch the 'Temp' icon to cycle through the 7 preset water temperatures: Room Temperature, 450C, 550C, 650C, 750C, 850C, and 1000C. The selected temperature will be displayed.
4. **Select Volume:** Touch the 'Volume' icon to choose from 5 preset cup sizes: 100ml, 200ml, 300ml, 400ml. For continuous flow, select the 'Continuous Flow' option.
5. **Dispense Water:** Once temperature and volume are selected (and child lock is disengaged), touch the 'Dispense' icon to start dispensing water. The water will heat and dispense in approximately 10 seconds.
6. **Stop Dispensing:** To stop dispensing water at any time, touch the 'Stop' icon. This is particularly useful during continuous flow.
7. **Low Water Level Reminder:** The display will show an indicator when the water level in the tank is low, prompting you to refill.

6. Maintenance

Regular cleaning and maintenance will prolong the life of your water dispenser and ensure optimal performance.

- **Cleaning the Unit:** Unplug the appliance and allow it to cool completely. Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Cleaning the Drip Tray:** The drip tray is detachable for easy cleaning. Empty and rinse it regularly with warm, soapy water. Dry thoroughly before reattaching.
- **Descaling:** The dispenser has a 'Descale' reminder indicator. When this appears, it's time to descale the unit. Follow the descaling instructions provided in a separate guide or contact customer support for recommended descaling solutions and procedures. Regular descaling prevents mineral buildup and maintains heating efficiency.

- **Filter Replacement:** The UK Aqua Optima (Strix) filter should be replaced periodically based on usage and water quality, typically every 1-2 months. Refer to the filter packaging for specific replacement guidelines. A fresh filter ensures optimal taste and reduces contaminants.
- **Water Tank Cleaning:** Periodically remove the water tank and clean it with mild soap and water. Rinse thoroughly to remove all soap residue.

7. Troubleshooting

If you encounter issues with your water dispenser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No water dispenses.	Water tank empty; Child lock engaged; Power issue.	Refill water tank; Disengage child lock; Check power connection.
Water tastes sour or unusual.	Filter needs replacement; Initial use residue; Unit needs cleaning/descaling.	Replace filter cartridge; Perform initial rinse; Clean and descale the unit.
Water is not hot enough.	Incorrect temperature setting; Limescale buildup.	Verify selected temperature; Perform descaling procedure.
Low water level indicator is on.	Water tank is low.	Refill the water tank to the 'MAX' line.
Dispenser leaks.	Water tank or drip tray not properly installed.	Ensure water tank and drip tray are correctly seated.

If the problem persists after attempting these solutions, please contact customer support.

8. Specifications

Detailed technical specifications for the Mayer 4L Instant Heating Water Dispenser:

Model: MMIWD4008

Capacity: 4 Liters

Voltage: 220 Volts

Material: Stainless Steel

Dimensions (L x W x H): 19L x 14W x 26H centimetres

Special Features: UK Aqua Optima (Strix) filter, Child lock, Low water level/descale reminder, Detachable drip tray, Instant heating technology.

Preset Temperatures: Room Temperature, 450C, 550C, 650C, 750C, 850C, 1000C

Preset Volumes: 100ml, 200ml, 300ml, 400ml, Continuous Flow



Figure 4: Product dimensions for placement reference.

9. Warranty and Support

Your Mayer 4L Instant Heating Water Dispenser is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including warranty period and coverage details. For technical assistance, troubleshooting beyond this manual, or to inquire about replacement parts (such as filters), please contact Mayer customer support through their official website or the contact information provided in your product packaging.

For further assistance, you may visit the official Mayer website or contact their customer service hotline.

© 2024 Mayer. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question