Kenmore 2214672

Kenmore 24" Built-In Stainless Steel Tub Dishwasher User Manual

Model: 2214672

Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Kenmore 24" Built-In Stainless Steel Tub Dishwasher. Please read this manual thoroughly before using your appliance and retain it for future reference.



Image: Front view of the Kenmore 24-inch white built-in dishwasher, showcasing its sleek design.

Safety Information

Always follow basic safety precautions when using this appliance to reduce the risk of fire, electric shock, or injury to persons.

- Read all instructions before using the dishwasher.
- Connect to properly grounded outlet only.
- Do not operate a damaged dishwasher.
- Keep children away from the dishwasher, especially when it is operating.
- Use only detergents and rinse aids recommended for dishwashers.
- Do not touch the heating element during or immediately after use.
- The Leak Detect System monitors water flow and will automatically drain the tub if a problem is sensed.

Setup and Installation

Unpacking

Carefully remove all packaging materials and inspect the dishwasher for any shipping damage. Retain packaging for potential future transport.

Placement

Ensure the installation area meets the required dimensions and has proper water and electrical connections. The dishwasher is designed for built-in installation.



Image: Side view of the dishwasher with measurements, showing a height of 33 7/8 inches and a width of 23 9/16 inches.

Connections

Connect the water supply, drain hose, and electrical supply according to local codes and the detailed installation instructions provided in the separate installation guide. Ensure all connections are secure to prevent leaks.

Operating Instructions

Control Panel Overview

The control panel is located on the top edge of the dishwasher door, providing easy access to cycles and options.



Image: The control panel features touch controls for various wash cycles like Normal, Smart Wash, Heavy Duty, Pots & Pans, Light Wash, Delicate, Express, and Quick Rinse, along with options such as Half Load, Extra Dry, Sani Rinse, High Temp, Accela Wash, and Quiet Wash.

Loading the Dishwasher

Proper loading ensures optimal cleaning performance. Place larger items in the lower rack and smaller items, including glasses and cups, in the upper rack. Utensils can be placed in the cutlery basket or the 3rd rack.



Image: The dishwasher interior, showing a typical load of dishes arranged for washing.



Image: The EasyFlex 3rd Rack, providing dedicated space for silverware and small utensils, enhancing loading flexibility.



Image: The removable cutlery basket, offering an alternative for organizing silverware during the wash cycle.

Adding Detergent and Rinse Aid

Use the dispenser located on the inside of the door for both detergent and rinse aid. Follow the manufacturer's recommendations for dosage.



Image: The dispenser for detergent and rinse aid, located on the inner door panel, ready for filling.

Wash Cycles and Options

Select the appropriate wash cycle and options based on the soil level and type of dishes.

- **SmartWash Cycle:** Automatically detects the amount of soil in the water and adjusts temperature, water amount, and duration for optimal cleaning.
- **UltraWash Plus System:** Utilizes 3 spray arms and continuous water filtration to ensure thorough cleaning.



Image: Visual representation of the UltraWash Plus system, showing pressurized spray arms cleaning dishes.

- **AccelaWash Option:** Delivers clean dishes in less time by using slightly more water and energy.
- **TurboDry:** Uses hot water and a fan to promote condensation drying, resulting in spot-free dishes.
- **MoreSpace Plus Adjustable Rack:** Allows you to lift, lower, or remove the upper rack to accommodate large or oddly shaped items.



Image: Detail of the MoreSpace Plus Adjustable Rack, demonstrating its ability to be repositioned for various dish sizes.

- **Quiet Wash Option:** Provides additional noise reduction by increasing wash temperature and cycle duration. The dishwasher operates at 45 dBA for ultra-quiet cycles.

Official Product Video

Video: An overview of the Kenmore 24" Built-In Dishwashers, highlighting key features such as SmartWash, UltraWash Plus, TurboDry, and adjustable racks. This video provides a visual demonstration of the dishwasher's functionality and design.

Maintenance

Regular maintenance helps ensure the longevity and performance of your dishwasher.

Cleaning the Filter

Periodically check and clean the filter located at the bottom of the dishwasher tub to remove food particles and debris. Refer to the detailed instructions in the full manual for filter removal and cleaning.



Image: The lower spray arm and filter assembly at the base of the dishwasher tub, indicating the area for routine cleaning.

Cleaning the Spray Arms

Ensure the spray arm nozzles are not clogged. Remove the spray arms and rinse them under running water if necessary.

Exterior Cleaning

Wipe the exterior surfaces with a soft, damp cloth. For stainless steel finishes, use a stainless steel cleaner to maintain its appearance.

Troubleshooting

Before calling for service, review the following common issues and their potential solutions.

Problem	Possible Cause / Solution
Dishes not clean	Check filter for clogs. Ensure spray arms are not blocked. Use proper detergent amount. Load dishes correctly, avoiding overcrowding.
Dishes not drying	Ensure rinse aid dispenser is full. Select Extra Dry or TurboDry option. Check water temperature.
Dishwasher not starting	Check if the door is fully closed and latched. Ensure power supply is connected. Check circuit breaker.

Problem	Possible Cause / Solution
Unusual noises	Check for items obstructing spray arms. Ensure dishes are stable and not rattling.
Water leakage	Check door seal for damage or debris. Ensure hoses are properly connected. The Leak Detect System will alert you if a significant leak is detected.

Specifications

Feature	Detail
Brand	Kenmore
Model Number	2214672
Installation Type	Built-In
Finish Type	Stainless steel
Color	White
Item Weight	90.4 pounds
Product Dimensions	24.61"D x 23.55"W x 33.88"H
Voltage	115 Volts
Noise Level	45 dB
Capacity	15 Place Settings
Controls Type	Touch
Certification	Energy Star
Included Components	Cutlery Basket
UPC	843086110771

Warranty and Support

Your Kenmore dishwasher comes with a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including coverage duration and limitations.

For technical assistance, troubleshooting beyond this manual, or to schedule service, please contact Kenmore Customer Support. You can find contact information on the Kenmore website or in your product registration materials.

Always provide your model number (2214672) and serial number when contacting support to ensure efficient service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question