ALLIMITY PALCO20-LED07E, PALCO24-LED07E

ALLIMITY Replacement Remote Control User Manual

Model: PALCO20-LED07E, PALCO24-LED07E and compatible models

1. Introduction

Thank you for choosing the ALLIMITY Replacement Remote Control. This remote is designed to provide seamless control for your compatible TREVI and Telesystem televisions, replicating all functions of your original remote without the need for complex programming.

Compatible Models:

- PALCO20-LED07E
- PALCO24-LED07E
- LTV2022HD
- LTV2202SAT
- LTV1901HD
- LTV2801HD
- LTV5001HD
- LTV3204SAT
- LTV3206SAT
- LTV4004SAT
- LTV2201HD
- GFT-17

2. Setup

This remote control requires no programming. Simply insert the batteries, and it will be ready for immediate use with your compatible television model.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two new AAA alkaline batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.

4. Close the battery compartment cover by sliding it back into place until it clicks securely.





Figure 1: Back view of the remote control with the battery compartment.

This image displays the rear of the ALLIMITY remote control, highlighting the rectangular battery cover located at the bottom. The cover is designed to slide open for battery insertion.

3. Operating Instructions

The ALLIMITY replacement remote control is designed to function identically to your original remote, providing access to all standard television functions.

3.1 Button Functions Overview





Figure 2: Front view of the remote control with all buttons labeled.

This image shows the full front view of the ALLIMITY remote control, displaying its complete button layout, including power, mute, number keys, navigation, volume, channel, and special function buttons.

- **POWER:** Turns the TV on or off.
- **MUTE:** Mutes or unmutes the TV sound.
- **Number Buttons (0-9):** Selects channels directly.
- **DTV/ATV:** Switches between digital and analog TV modes.
- **P.MODE:** Cycles through picture modes (e.g., Standard, Dynamic, Movie).
- **S.MODE:** Cycles through sound modes (e.g., Standard, Music, Movie).
- **SLEEP:** Sets the sleep timer.
- **MENU:** Opens the main menu.
- **SOURCE:** Selects input sources (e.g., HDMI, AV).
- **Navigation Buttons (Up, Down, Left, Right):** Navigates through menus and options.
- **ENTER:** Confirms selections in menus.
- **EXIT:** Exits the current menu or function.
- **DISPLAY:** Shows channel information or current status.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes channels.

- **MTS:** Multi-channel Television Sound (SAP/Stereo).
- **RECLIST:** Accesses the recording list (if supported by TV).
- **REC:** Starts recording (if supported by TV).
- **FREEZE:** Freezes the current image on screen.
- **FAV/LIST:** Accesses favorite channels or channel list.
- **GUIDE:** Opens the Electronic Program Guide (EPG).
- **ASPECT:** Changes the screen aspect ratio.
- **CANCEL:** Cancels an operation.
- **SUB.PG:** Sub-page function for Teletext.
- **INDEX:** Index page for Teletext.
- **TIMESHIFT:** Activates time shift function (if supported by TV).
- **TV/RADIO:** Switches between TV and Radio modes.
- **SUBTITLE:** Toggles subtitles on/off.
- **REVEAL:** Reveals hidden text in Teletext.
- **SIZE:** Changes Teletext display size.
- **HOLD:** Holds Teletext page.
- **TEXT:** Opens/closes Teletext.
- **Color Buttons (RED, GREEN, YELLOW, CYAN):** Used for specific functions in menus or interactive services.

4. Maintenance

Proper care and maintenance will ensure the longevity and optimal performance of your remote control.

4.1 Cleaning

- Wipe the remote control with a soft, dry cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not spray cleaner directly onto the remote.
- Avoid using harsh chemicals, solvents, or abrasive cleaning pads, as these can damage the remote's surface or internal components.

4.2 Battery Care

- Replace batteries when the remote's response becomes sluggish or stops working.
- Always replace both batteries at the same time with new ones of the same type (AAA alkaline).
- If the remote control will not be used for an extended period (e.g., one month or more), remove the batteries to prevent leakage and potential damage.
- Dispose of used batteries responsibly according to local regulations.

5. Troubleshooting

If you encounter issues with your remote control, please refer to the following common problems and solutions before seeking further assistance.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Remote is not working or unresponsive.	Dead or incorrectly inserted batteries.	Check battery polarity (+/-). Replace batteries with new AAA alkaline batteries.
Remote has limited range or intermittent response.	Weak batteries; Obstruction between remote and TV; Infrared sensor on TV is blocked.	Replace batteries. Ensure a clear line of sight between the remote and the TV's infrared sensor. Remove any obstructions.
Certain buttons do not work.	Button stuck or damaged; TV model incompatibility for specific advanced functions.	Gently press the button multiple times to dislodge any debris. Ensure your TV model supports the specific function.
Remote works for some TVs but not mine.	TV model is not compatible.	Verify your TV model is listed in the compatible models section of this manual.

6. Specifications

Feature	Detail
Brand	ALLIMITY
Model Numbers	PALCO20-LED07E, PALCO24-LED07E
Compatible Devices	TREVI and Telesystem TVs (PALCO20-LED07E, PALCO24-LED07E, LTV2022HD, LTV2202SAT, LTV1901HD, LTV2801HD, LTV5001HD, LTV3204SAT, LTV3206SAT, LTV4004SAT, LTV2201HD, GFT-17)
Connectivity Technology	Infrared (IR)
Special Feature	No programming required
Battery Type	Alkaline (AAA, not included)
Dimensions (L x W x H)	20 x 5 x 1.5 cm (approx. 7.87 x 1.97 x 0.59 inches)
Item Weight	70 grams (approx. 2.47 ounces)
Maximum Range	10 meters (approx. 33 feet)
Number of Buttons	25

7. Support

For further assistance or inquiries, please refer to the seller's contact information on the product's purchase page. Ensure you have your product model number and purchase details ready.

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question