Sterwins 3081570

Sterwins High-Pressure Hose 3081570 User Manual

Model: 3081570

Introduction

This manual provides essential information for the safe and effective use of your Sterwins High-Pressure Hose Model 3081570. This hose is designed for use with Sterwins pressure washer models HPCS2-8 and Hpcs2.8. Please read these instructions carefully before installation and operation to ensure proper function and to prevent injury or damage.

Safety Instructions

WARNING: Failure to follow these safety instructions could result in serious injury or property damage.

- Always ensure the pressure washer is turned off and depressurized before connecting or disconnecting the high-pressure hose.
- Never point the spray gun at people, animals, or electrical equipment.
- Inspect the hose for any signs of damage (cuts, abrasions, bulges) before each use. Do not use a damaged hose.
- Ensure all connections are secure and leak-free before operating the pressure washer.
- Do not attempt to repair a damaged high-pressure hose. Replace it with an original Sterwins part.
- Keep children and pets away from the work area during operation.
- Wear appropriate personal protective equipment (PPE), including eye protection, during pressure washing.

Setup

Follow these steps to properly connect the high-pressure hose to your Sterwins pressure washer and spray gun.

1. **Prepare the Pressure Washer:** Ensure the pressure washer is unplugged (if electric) or the engine is off (if gas-powered) and the water supply is turned off. Squeeze the trigger on the spray gun to release any residual pressure in the system.
2. **Connect to Pressure Washer Outlet:** Locate the high-pressure outlet on your Sterwins pressure washer. This is typically a threaded connection. Screw one end of the high-pressure hose onto this outlet. Hand-tighten firmly, then

use a wrench to ensure a secure, leak-free connection. Do not overtighten.

3. **Connect to Spray Gun:** Locate the inlet on your spray gun. Screw the other end of the high-pressure hose onto the spray gun inlet. Hand-tighten firmly.



Image: Close-up view of the high-pressure hose connector, showing the threaded metal fitting and rubber grip. This is the end that connects to either the pressure washer or the spray gun.

4. **Check Connections:** Visually inspect all connections to ensure they are tight and there are no visible gaps.
5. **Uncoil the Hose:** Fully uncoil the high-pressure hose to prevent kinks, which can restrict water flow and damage the hose.

Operating Instructions

Once the hose is securely connected, you can begin operating your pressure washer.

1. **Turn on Water Supply:** Open the water faucet completely to ensure a steady flow of water to the pressure washer.
2. **Purge Air from System:** With the pressure washer still off, squeeze the trigger on the spray gun for about 30

seconds to allow water to flow through the hose and expel any trapped air. This prevents air pockets from damaging the pump.

3. **Start Pressure Washer:** Follow your pressure washer's specific instructions to start the unit.
4. **Begin Cleaning:** Point the spray gun at the desired cleaning surface and squeeze the trigger to begin spraying. Always maintain a safe distance from the surface and adjust the nozzle as needed.
5. **Shut Down:** When finished, turn off the pressure washer, then turn off the water supply. Squeeze the spray gun trigger to release all remaining pressure from the system before disconnecting the hose.

Maintenance

Proper maintenance extends the life of your high-pressure hose.

- **Inspection:** Regularly inspect the hose for cuts, abrasions, kinks, or bulges. Check connections for wear or leaks.
- **Cleaning:** After each use, rinse the hose with clean water to remove any chemical residues or dirt.
- **Storage:** Coil the hose neatly without kinks and store it in a cool, dry place, away from direct sunlight and extreme temperatures. Do not store the hose under heavy objects.
- **Winterization:** If storing in freezing temperatures, ensure all water is drained from the hose to prevent ice damage.

Troubleshooting

Problem	Possible Cause	Solution
Water leak at connection	Loose connection, worn O-ring, damaged threads	Tighten connection. Inspect and replace O-ring if worn. If threads are damaged, replace the hose.
No water flow or low pressure	Kinked hose, blocked inlet filter (on pressure washer), insufficient water supply	Unkink hose. Check pressure washer manual for filter cleaning. Ensure water supply is fully open.
Hose appears damaged (bulges, cuts)	Wear and tear, improper handling, excessive pressure	Immediately cease use and replace the hose with an original Sterwins part.

Specifications

Model: 3081570

Brand: Sterwins

Material: Synthetic Rubber

Maximum Pressure: 20 Bars

Compatibility: Sterwins pressure washer models HPCS2-8, Hpcs2.8

Color: Multicolour

Country of Origin: France

Warranty and Support

For warranty information, technical support, or to purchase replacement parts, please contact Sterwins customer service or refer to the documentation provided with your original pressure washer unit. Always use genuine Sterwins replacement

parts to ensure compatibility and maintain product performance.
For further assistance, visit the official Sterwins website or contact your local authorized dealer.

© 2026 Sterwins. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question