Nettech 1225-4669

Nettech Replacement Remote Control User Manual

For 2019-2025 Sony Bravia Smart TVs with Voice Control

Brand: Nettech | Model: 1225-4669

1. Introduction

This manual provides instructions for the Nettech Replacement Remote Control, designed for use with compatible Sony Bravia Smart TVs. This remote offers full functionality, including voice control and dedicated streaming service hotkeys, to enhance your television viewing experience.





Image 1.1: The Nettech Replacement Remote Control for Sony TVs.

2. Compatibility

This remote control is compatible with a wide range of 2019-2025 Sony Bravia Smart TVs that support voice control, including:

- Bravia XR Series 4K/HD LED/OLED TVs
- Bravia XBR Series 8K/4K HDR LED/OLED TVs
- KD Series 4K/HD OLED/LED/Full Array LED TVs
- All other 2019-2024 Sony Google/Android TVs that support Voice Control

Important Notice:

- For TVs that do not support voice control or were released before 2018, the voice search functionality may not work.
- Some streaming hotkeys may not function if your original remote did not feature those specific hotkeys.

It serves as a replacement for various Sony voice remote controls, such as RMF-TX520U/500U, RMF-

TX800U/810U/811U/820U, RMF-TX900U/910U/920U, RMF-TX300/310U, RMF-TX600U/611U/621U, and others.



Image 2.1: Visual representation of compatible Sony TV remote models and series.

3. Setup

3.1 Battery Installation

The remote control requires two AAA batteries (not included). To install:

1. Slide open the battery compartment cover on the back of the remote.
2. Insert two AAA batteries, ensuring correct polarity (+ and -).
3. Close the battery compartment cover securely.

3.2 Pairing Instructions for Voice Control

To utilize the voice search feature, the remote must be paired with your Sony TV via Bluetooth. Follow these steps:

1. Turn on your Sony TV.
2. Navigate to your TV's **Settings** menu.
3. Select **Remotes & Accessories** (or **Bluetooth**).
4. Choose **Remote Control**.
5. Select **Connect via Bluetooth**.
6. Choose **Connect a new remote**.
7. On the Nettech remote, press and hold the "VOL -" button while simultaneously pressing the "Mic" button for 3-5 seconds.
8. The TV should detect and pair with the remote. Follow any on-screen prompts to complete the pairing process.



Image 3.1: Visual guide for pairing the remote control.

4. Operating Instructions

4.1 Basic Functions

The remote features standard TV controls:

- **Power Button:** Turns the TV on or off.
- **Number Buttons (0-9):** For direct channel input.
- **Volume Up/Down (VOL +/-):** Adjusts the TV volume.
- **Channel Up/Down (CH +/-):** Changes TV channels.
- **Mute:** Mutes or unmutes the TV audio.
- **Navigation Pad (Up, Down, Left, Right, Enter):** For menu navigation and selection.
- **Back:** Returns to the previous screen or menu.
- **Home:** Accesses the TV's home screen.
- **Input:** Selects input sources (HDMI, AV, etc.).

4.2 Voice Control

After successful pairing, press the **Mic** button and speak your command clearly into the remote. Examples include:

- "Open Netflix"

- "Search for action movies"
- "Switch to HDMI 1"
- "What's the weather like?"

Image 4.1: Demonstrating voice control functionality with the remote.

4.3 Dedicated Hotkeys

The remote includes one-click access buttons for popular streaming services:

- **Netflix**
- **YouTube**
- **Video** (often Amazon Prime Video)
- **Disney Plus**

Image 4.2: The remote's dedicated hotkeys for quick access to streaming platforms.

5. Maintenance

To ensure optimal performance and longevity of your remote control:

- Keep the remote clean by wiping it with a soft, dry cloth.
- Avoid exposing the remote to extreme temperatures, moisture, or direct sunlight.
- If the remote will not be used for an extended period, remove the batteries to prevent leakage.
- Replace batteries when the remote's response becomes sluggish or inconsistent.

6. Troubleshooting

6.1 Pairing Failure

If the remote fails to pair with your TV:

1. Ensure new batteries are correctly installed.
2. Verify that you are signed in to a Google TV account on your Sony TV.
3. Repeat the pairing steps outlined in Section 3.2.
4. Ensure no other Bluetooth devices are interfering with the pairing process.

6.2 Voice Control Not Working

If voice control is unresponsive after pairing:

- Confirm that your Sony TV model supports voice control and is from the 2019-2025 range.
- Ensure the remote is within a reasonable range of the TV.
- Check for any obstructions between the remote and the TV.
- Re-pair the remote following the instructions in Section 3.2.

6.3 Buttons Unresponsive

If specific buttons or the entire remote are not responding:

- Replace the batteries with fresh ones.
- Clean the remote's surface and buttons to remove any debris.
- If the issue persists, contact customer support for further assistance.

7. Specifications

Feature	Detail
Product Dimensions	8 x 2 x 0.68 inches
Item Weight	3.84 ounces
Item Model Number	1225-4669
Batteries Required	2 AAA batteries
Special Feature	Voice Search
Max Number of Supported Devices	5
Compatible Devices	Television
Connectivity Technology	Bluetooth

8. Warranty and Support

Nettech offers a **1-year full warranty** to ensure your satisfaction. For product support or warranty claims, please navigate to your order in your purchase history, click "View order details," and then "Ask Product Question."

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question