Kiwi KAF-5536

Kiwi KAF-5536 Digital Air Fryer User Manual

Model: KAF-5536 | Brand: Kiwi

Introduction

Thank you for choosing the Kiwi KAF-5536 Digital Oil-Free Air Fryer. This appliance is designed to cook your favorite foods with little to no oil, providing a healthier alternative to traditional frying. Please read this manual thoroughly before using the appliance to ensure safe and optimal operation. Keep this manual for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.

Product Overview

Familiarize yourself with the components of your Kiwi KAF-5536 Digital Air Fryer.



Figure 1: The Kiwi KAF-5536 Digital Air Fryer in operation, showing a cooked chicken inside the basket and side dishes of fries and salmon, highlighting its cooking versatility.



Figure 2: Internal diagram illustrating the rapid air circulation system for fast and energy-efficient cooking, along with the oil-collecting base design for healthier results.



Figure 3: Detailed view of the digital control panel, featuring a clear LED display for time and temperature, and intuitive icons for various cooking presets and manual adjustments.



Figure 4: The removable non-stick basket and crisper plate, designed for easy food placement, cooking, and cleaning. The crisper plate ensures even air circulation around food.

Components:

- **Main Unit:** Houses the heating element and fan.
- **Digital Control Panel:** For setting time, temperature, and selecting presets.
- **Removable Basket:** Where food is placed for cooking.
- **Crisper Plate:** Sits inside the basket, allowing air to circulate around food and excess oil to drain.
- **Handle:** For safely pulling out the basket.
- **Air Outlet Vent:** Located at the back of the unit.

Setup and First Use

1. **Unpacking:** Carefully remove all packaging materials from the air fryer.
2. **Cleaning:** Before first use, clean the basket and crisper plate with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of free space around the back and sides of the appliance to allow for proper ventilation.
4. **Pre-heating (Optional):** For best results, pre-heat the air fryer for 3-5 minutes at your desired cooking temperature before adding food. This helps achieve a crispier texture.
5. **Initial Burn-off:** It is normal for the appliance to emit a slight odor and some smoke during its first few uses. This is due to protective substances on the heating elements burning off. Ensure good ventilation during this period.

Operating Instructions

General Operation:

1. Plug the power cord into a grounded wall outlet.
2. Pull the basket out of the air fryer.
3. Place the crisper plate inside the basket.
4. Place ingredients into the basket. Do not overfill the basket.
5. Slide the basket back into the air fryer.
6. Press the Power button () to turn on the appliance.
7. Use the temperature (**°C**) and time (**min**) controls to set your desired cooking parameters, or select a preset program.
8. Press the Start/Pause button ( ) to begin cooking.
9. Some ingredients may require shaking halfway through the cooking time. Pull out the basket, shake the ingredients, and then slide the basket back in. The air fryer will resume cooking automatically.
10. When the cooking time is complete, the air fryer will beep. Carefully pull out the basket and transfer the cooked food to a plate.
11. Unplug the appliance after use.

Digital Control Panel Functions:

- **Power Button ( ):** Turns the appliance on/off.
- **Mode/Menu Button (M):** Cycles through preset cooking programs.

- **Temperature Control (+/-):** Adjusts cooking temperature (e.g., 80°C - 200°C).
- **Time Control (+/-):** Adjusts cooking time (e.g., 1 - 60 minutes).
- **Start/Pause Button ( ):** Starts or pauses the cooking cycle.
- **Preset Icons:** Various icons representing common foods (e.g., fries, chicken, fish, cake) for quick selection of recommended time and temperature settings.

Cooking Tips:

- Smaller ingredients usually require a shorter cooking time than larger ingredients.
- A larger amount of ingredients only requires a slightly longer cooking time.
- Shaking smaller ingredients halfway through the cooking time optimizes the end result and can help prevent unevenly fried ingredients.
- For crispy results, add a small amount of oil (1 tablespoon) to fresh potatoes before air frying.
- You can also use the air fryer to reheat food. Set the temperature to 150°C for 10 minutes.

Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your air fryer.

1. **Before Cleaning:** Always unplug the air fryer from the power outlet and allow it to cool down completely before cleaning.
2. **Basket and Crisper Plate:** These parts are dishwasher safe. Alternatively, you can wash them with hot water, dish soap, and a non-abrasive sponge. For stubborn residue, soak them in hot water for about 10 minutes.
3. **Inside of the Appliance:** Wipe the inside of the appliance with a hot water and non-abrasive sponge. Clean the heating element with a cleaning brush to remove any food residue.
4. **Outside of the Appliance:** Wipe the exterior with a damp cloth. Do not use harsh abrasive cleaners or scouring pads.
5. **Storage:** Ensure all parts are clean and dry before storing the appliance. Store it in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not work.	The appliance is not plugged in.	Plug the main plug into a grounded wall socket.
	The basket is not placed in the appliance correctly.	Slide the basket into the appliance correctly.
Ingredients fried in the air fryer are not cooked evenly.	The amount of ingredients in the basket is too large.	Put smaller batches of ingredients in the basket. Smaller batches are fried more evenly.
	The temperature is set too low.	Set the temperature to a higher setting.
Fresh fries are not crispy.	You did not add oil to the fries.	Add 1/2 tablespoon of oil to the fries before frying.
White smoke comes out of the appliance.	Fat residues from previous use are burning.	Clean the basket and crisper plate thoroughly after each use.

Specifications

Feature	Detail
Model Name	KAF-5536
Brand	Kiwi
Power	1400 Watts
Capacity	5 Liters
Control Type	Digital Touch Control
Special Feature	Temperature Control

Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official Kiwi website. Keep your purchase receipt as proof of purchase for any warranty claims.
For technical assistance or service inquiries, please contact Kiwi customer service through the contact details provided on their official website or product packaging.

© 2023 Kiwi. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question