Gotofine P7

Gotofine Automatic Foaming Soap Dispenser Model P7 User Manual

Brand: Gotofine | **Model:** P7

1. Introduction

Thank you for choosing the Gotofine Automatic Foaming Soap Dispenser. This device is designed to provide a convenient and hygienic handwashing experience with its touchless operation and adjustable foam volume. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your dispenser.

2. Product Overview

Familiarize yourself with the components and features of your Gotofine Automatic Foaming Soap Dispenser.



Figure 2.1: Control Panel and Indicators

This image displays the top of the dispenser, highlighting the touch control switch, continuous foam button, foam level indicator, and battery indicator.



Figure 2.2: Dispenser Dimensions and Features

This image illustrates the dispenser's dimensions (3 inches wide, 7.7 inches high) and highlights features such as the smart infrared sensor, 0.25s response time, 380ml/12.8oz liquid capacity, and IPX5 waterproof rating.

Key Components:

- **Smart Infrared Sensor:** Detects hand movement for touchless operation.
- **Touch Control Switch:** Power on/off and foam volume adjustment.
- **Continuous Foam Button:** Activates a continuous stream of foam.
- **Foam Level Indicator:** Displays the selected foam volume level.
- **Battery Indicator:** Shows current battery status.
- **Transparent Liquid Reservoir:** Allows easy monitoring of soap levels.
- **USB-C Charging Port:** For convenient recharging.

3. Setup Instructions

3.1 Charging the Dispenser

1. Locate the USB-C charging port on the side of the dispenser.
2. Open the rubber plug covering the charging port.
3. Connect the provided USB-C cable to the dispenser and a suitable power source (e.g., USB adapter, computer USB port).
4. The battery indicator lights will illuminate during charging. A full charge typically lasts approximately 90 days (around 5000 uses).
5. Once fully charged, disconnect the cable and securely close the rubber plug to maintain IPX5 waterproofing.



Figure 3.1: USB-C Charging Port

Ensure the rubber plug is securely closed after charging to maintain water resistance.

3.2 Filling the Soap Dispenser

1. Gently twist the top section of the dispenser counter-clockwise to separate it from the liquid reservoir.
2. **For Foam Soap:** Pour foam soap directly into the transparent liquid reservoir.
3. **For Ordinary Liquid Soap:** Dilute the liquid soap with water at a ratio of 1:4 to 1:6 (1 part soap to 4-6 parts water). Stir gently to mix, avoiding excessive bubbles, then pour into the reservoir.
4. Do not overfill. The transparent gauge allows you to monitor the liquid level.
5. Reattach the top section by aligning it and twisting clockwise until secure.



Figure 3.2: Soap Filling Guide

Use foam soap directly or dilute liquid soap with water (1:4-6 ratio) before filling.

3.3 Placement Options

The dispenser offers versatile placement options:

- **Countertop:** Place the dispenser directly on any flat, stable surface in your bathroom or kitchen.
- **Wall-Mount:** For space-saving convenience, use the provided adhesive hook to mount the dispenser on a wall. Ensure the surface is clean and dry before applying the adhesive.



Figure 3.3: Countertop and Wall-Mount Options

Choose the placement method that best suits your space and needs.

4. Operating Instructions

4.1 Power On/Off

- To turn on, press and hold the power button (located on the top panel) for 3 seconds. The indicator lights will flash.

- To turn off, press and hold the power button for 3 seconds. The indicator lights will turn off.

4.2 Adjusting Foam Volume

The dispenser offers 4 adjustable foam volume levels:

1. With the dispenser powered on, short press the power button to cycle through the 4 foam volume levels.
2. Each press will change the foam output duration: 0.3s, 0.8s, 1.5s, and 2s.
3. The foam level indicator lights on the top panel will show the currently selected level.



Figure 4.1: 4-Level Adjustable Foam Volume
Customize the foam output to your preference by tapping the power button.

4.3 Touchless Dispensing

To dispense foam, simply place your hand under the nozzle. The intelligent infrared sensor will detect your hand and release the selected amount of foamed soap within 0.25 seconds.



Figure 4.2: Touchless Operation

Place your hand under the sensor for automatic foam dispensing.

4.4 Continuous Foam Feature

For tasks requiring a larger quantity of foam, such as cleaning dishes or stovetops:

- Press the dedicated continuous foam button (located on the top panel).
- The dispenser will generate a continuous stream of foam until the button is released.



Figure 4.3: Continuous Foam Application
Ideal for cleaning multiple items or larger surfaces.

5. Maintenance

5.1 Cleaning

- Wipe the exterior of the dispenser with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- The dispenser is IPX5 waterproof, meaning it can withstand splashes of water. However, avoid submerging it in water.
- Regularly clean the nozzle to prevent soap buildup, which can affect dispensing performance.

5.2 Refilling

Refer to Section 3.2 for detailed instructions on refilling the soap reservoir. Ensure you use appropriate foam soap or properly diluted liquid soap to prevent clogging and ensure proper foam consistency.

6. Troubleshooting

If you encounter any issues with your dispenser, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Dispenser not turning on.	Low battery or not powered on.	Charge the dispenser fully. Press and hold the power button for 3 seconds to turn on.
No foam dispensed.	Empty soap reservoir, clogged nozzle, or incorrect soap type/dilution.	Refill the reservoir. Clean the nozzle. Ensure proper soap type and dilution ratio.
Weak or inconsistent foam.	Incorrect soap dilution, low battery, or air in the pump.	Adjust soap dilution. Charge the dispenser. Run the dispenser a few times to clear air.
Sensor not responding.	Obstruction near sensor or sensor dirty.	Ensure no objects are blocking the sensor. Clean the sensor area with a soft cloth.

7. Specifications

Feature	Detail
Brand	Gotofine
Model Number	P7
Color	White
Material	Plastic
Product Dimensions	4.4"L x 3"W x 7.9"H
Liquid Volume	420 Milliliters (12.8 oz)
Waterproof Rating	IPX5
Battery	Built-in Lithium-ion (USB Rechargeable)
Dispensing Time	0.25 seconds (sensor response)
Foam Volume Levels	4 (0.3s, 0.8s, 1.5s, 2s)
Material Type Free	Latex Free, Nickel Free, DEHP Free, Cadmium Free, BPA Free, Phthalate Free, Mercury Free, PVC Free, Lead Free

8. Official Product Video

Your browser does not support the video tag.

Video 8.1: Automatic Foaming Soap Dispenser Overview

This video provides a visual demonstration of the Gotofine Automatic Foaming Soap Dispenser's features, including wall-mounting, dish soap application, continuous foam, hand soap dispensing, adjustable foam levels, Type-C charging, and soap compatibility.

9. Warranty and Support

For warranty information, technical support, or any inquiries regarding your Gotofine Automatic Foaming Soap Dispenser, please refer to the contact information provided with your product packaging or visit the official Gotofine website. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question