**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### Rollei Movieline UHD5m Waterproof

# Rollei Movieline UHD5m Waterproof 4K Camcorder User Manual

Model: Movieline UHD5m Waterproof (Model 40195)

## 1. Introduction

This manual provides detailed instructions for the safe and effective operation of your Rollei Movieline UHD5m Waterproof 4K Camcorder. Please read this manual thoroughly before using the device and retain it for future reference.

The Rollei Movieline UHD5m Waterproof Camcorder is designed for capturing high-quality video and photos in various environments, including underwater up to 5 meters. It features 4K video recording, 12-megapixel still image capture, and multiple shooting modes.

## 2. Safety Information

- **Waterproof Integrity:** Ensure the battery compartment cover is securely closed and locked before submerging the camera in water. Failure to do so will compromise the waterproof seal and may damage the device.
- **Depth Limit:** The camera is waterproof up to 5 meters (IPX8 certified). Do not exceed this depth.
- **Temperature:** Avoid exposing the camera to extreme temperatures.
- **Cleaning:** After use in saltwater, rinse the camera with fresh water and dry thoroughly. Do not use chemical cleaners.
- **Battery Safety:** Use only specified batteries. Do not disassemble, crush, or expose batteries to high temperatures.
- **Lens Care:** Avoid touching the lens directly. Clean with a soft, lint-free cloth.

## 3. Package Contents

Verify that all items are present in the package:

- Rollei Movieline UHD5m Waterproof Camcorder
- Rechargeable Lithium-polymer Battery
- Wrist Strap

- USB-C Cable
- MiniHDMI to HDMI Cable
- Protective Pouch
- Cleaning Cloths (2)
- User Manual (this document)




Image 3.1: Contents of the Rollei Movieline UHD5m Waterproof Camcorder package, including the camera, battery, cables, wrist strap, protective pouch, and cleaning cloths.

# 4. Product Overview

## 4.1 Camera Components




Image 4.1: Front view of the camcorder with the LCD screen open, showing the 4K Ultra HD lens and the display.




Image 4.2: Side view of the camcorder, displaying the control buttons for Power, Mode/OK, Menu, and navigation arrows. The wrist strap is also visible.




Image 4.3: Rear view of the camcorder, highlighting the battery compartment lock mechanism with 'LOCK' and 'UNLOCK' indicators. This mechanism must be securely closed for waterproof performance.




Image 4.4: Top view of the camcorder, showing the lens and the "WATERPROOF 5m/16.4ft" marking, indicating its water resistance capabilities.

### 4.2 Controls and Ports

- **Power Button:** Turns the camera on or off.
- **Mode/OK Button:** Switches between video, photo, and playback modes. Confirms selections in menus.
- **Menu Button:** Accesses the camera's settings menu.
- **Navigation Buttons (Up/Down/Left/Right):** Used to navigate through menus and adjust settings.
- **Record/Shutter Button:** Starts/stops video recording or takes a photo.
- **Zoom Lever:** Controls optical and digital zoom.
- **LCD Screen:** Displays live view, recorded content, and menu interface.
- **Battery Compartment:** Houses the rechargeable battery. Features a locking mechanism for waterproof sealing.
- **Memory Card Slot:** For inserting a microSD card (not included).
- **USB-C Port:** For charging and data transfer.
- **MiniHDMI Port:** For connecting to an external display.

# 5. Setup

### 5.1 Charging the Battery

1. Open the battery compartment by sliding the lock mechanism to "UNLOCK" and opening the cover.
2. Insert the Lithium-polymer battery into the compartment, ensuring correct polarity.
3. Close the battery compartment cover and slide the lock mechanism to "LOCK". Ensure it is securely sealed.
4. Connect the USB-C cable to the camera's USB-C port and the other end to a USB power adapter (not included) or a computer.
5. The charging indicator light will illuminate. Charging is complete when the light turns off or changes color (refer to camera display for status).

### 5.2 Inserting a Memory Card

A microSD card (Class 10 or higher, up to 128GB recommended) is required for recording. It is not included in the package.

1. Ensure the camera is powered off.
2. Locate the memory card slot (usually near the battery compartment or on the side).
3. Insert the microSD card with the contacts facing the correct direction until it clicks into place.
4. To remove, gently push the card until it springs out.

### 5.3 Initial Power On and Basic Settings

1. Press and hold the Power button to turn on the camera.
2. Upon first use, you may be prompted to set the language, date, and time. Use the navigation buttons to select and the Mode/OK button to confirm.
3. Access the Menu button to adjust other settings such as video resolution, photo quality, white balance, and exposure.

## 6. Operating Instructions

### 6.1 Power On/Off

- To power on: Press and hold the Power button.
- To power off: Press and hold the Power button again.

### 6.2 Switching Modes

Press the Mode/OK button repeatedly to cycle through Video Recording Mode, Photo Mode, and Playback Mode.

### 6.3 Recording Video

1. Switch to Video Recording Mode.
2. Press the Record/Shutter button to start recording. A red indicator will typically appear on the screen.
3. Press the Record/Shutter button again to stop recording.
4. To adjust video resolution (e.g., 4K), access the Menu in Video Recording Mode.

### 6.4 Taking Photos

1. Switch to Photo Mode.
2. Frame your shot using the LCD screen.
3. Press the Record/Shutter button to take a photo.
4. To adjust photo quality (e.g., 12MP), access the Menu in Photo Mode.

### 6.5 Using Zoom

Use the zoom lever to adjust the focal length. The camera supports both optical and digital zoom up to 18x.

### 6.6 Special Shooting Modes

The camera offers various modes accessible via the Menu:

- **Underwater Mode:** Optimizes color balance and exposure for underwater environments. Ensure the camera is properly sealed before use.
- **Time-lapse:** Captures a series of photos over time and stitches them into a video.
- **Slow Motion:** Records video at a higher frame rate for slow-motion playback.
- **Loop Recording:** Records video continuously, overwriting the oldest files when the memory card is full.

### 6.7 Playback and File Transfer

#### 6.7.1 On-Camera Playback

1. Switch to Playback Mode.
2. Use the navigation buttons to browse through your recorded videos and photos.
3. Press Mode/OK to play a video or view a photo.

#### 6.7.2 Connecting to a Computer

1. Connect the camera to your computer using the USB-C cable.
2. The camera will appear as a removable disk drive. You can then transfer files to your computer.

#### 6.7.3 Connecting to a TV/Monitor

1. Connect the camera to a TV or monitor using the MiniHDMI to HDMI cable.
2. Switch the TV/monitor input to the corresponding HDMI port.
3. The camera's display will be mirrored on the external screen.

## 7. Maintenance

- **Cleaning the Camera Body:** Wipe the camera body with a soft, damp cloth. For stubborn dirt, use a mild soap solution and rinse thoroughly with fresh water, ensuring all ports are sealed.
- **Cleaning the Lens:** Use a lens cleaning cloth or a soft, lint-free cloth specifically designed for optical surfaces. Do not use abrasive materials or solvents.
- **Cleaning the LCD Screen:** Gently wipe the screen with a soft, dry, lint-free cloth.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight and extreme temperatures. Remove the battery if storing for extended periods.
- **Waterproof Seals:** Regularly inspect the rubber seals around the battery compartment and ports for any signs of damage or debris. Clean them gently if necessary.

## 8. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|

| Problem | Possible Cause | Solution |
|---|---|---|
| Camera does not power on. | Battery is depleted or incorrectly inserted. | Charge the battery. Ensure the battery is inserted correctly. |
| Cannot record video/take photos. | No memory card, memory card full, or memory card error. | Insert a memory card. Delete unnecessary files or replace the card. Format the card (this will erase all data). |
| Poor image/video quality. | Lens is dirty, low light conditions, incorrect settings. | Clean the lens. Ensure adequate lighting. Adjust resolution, white balance, or exposure settings. |
| Camera is not waterproof. | Battery compartment not securely closed. Damaged seals. | Ensure the battery compartment is fully locked. Inspect seals for damage; if damaged, contact support. |
| Computer does not recognize camera. | Incorrect cable, driver issue, or camera not in correct mode. | Use the provided USB-C cable. Try a different USB port. Ensure camera is powered on and in data transfer mode (if prompted). |

# 9. Specifications

| Feature | Detail |
|---|---|
| Model Name | Movieline UHD5m Waterproof |
| Model Number | 40195 |
| Brand | Rollei |
| Water Resistance | IPX8 Certified, up to 5 meters |
| Video Resolution | 4K UHD (3840 Pixels effective) |
| Image Resolution | 12 Megapixels effective |
| Photo Sensor Technology | CMOS |
| Lens Type | Fixed Focus |
| Max Aperture | f/2.6 |
| Max Focal Length | 1 mm |
| Optical Zoom | 18x |
| Digital Zoom | 18x |
| Screen Size | 3 Inches |
| Video Format | MP4 |
| Audio Format | AAC |
| Image Format | JPEG |

| Feature | Detail |
|---|---|
| Connectivity | HDMI, USB-C |
| Battery Type | 1 Lithium-polymer (included) |
| Average Battery Life | 115 minutes |
| Dimensions (L x W x H) | 13.5 x 6.5 x 6.7 cm |
| Weight | 400 Grams |
| Image Stabilization | Yes (Anti-shake feature) |
| Memory Card Support | MicroSD (Class 10 or higher, up to 128GB recommended) |
| Processor | NTK96580 |

# 10. Warranty and Support

Rollei provides a warranty for this product. Spare parts availability is guaranteed for 2 years from the date of purchase.

For technical support, warranty claims, or service inquiries, please refer to the contact information provided on the official Rollei website or your purchase documentation.

Please visit the official Rollei website for the most up-to-date support information and resources:www.rollei.com


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B0CGVVWNRX**

More documents and user manuals: **https://manuals.plus/**