Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JYX D17

JYX Mini Karaoke Machine User Manual

Model: D17

1. Introduction

Welcome to your new JYX Mini Karaoke Machine! This portable system is designed to provide exceptional audio and entertainment for all ages, perfect for home parties, outdoor gatherings, and educational settings. With its compact design, vibrant LED lights, and versatile connectivity, you can enjoy your favorite tunes and sing along anywhere.



The JYX Mini Karaoke Machine with its wireless microphone, featuring a beige speaker unit with a colorful LED light ring and a matching beige and gold microphone.

2. What's Included

Package Contents

- Wireless Mic
- AUX Cable
- Charging Cable
- User Manual
- Speaker



An illustration showing the contents of the JYX Mini Karaoke Machine package, including the speaker, wireless microphone, charging cable, audio cable, and user manual.

3. Setup Guide

Charging the Device

Connect the provided charging cable to the speaker's Type-C port and a suitable USB power adapter (not included). The LED indicator will show charging status. A full charge typically takes 2-3 hours.



The JYX Mini Karaoke Machine speaker connected to a charging cable, illustrating the Type-C charging port.

Powering On

Press and hold the power button on the speaker for approximately 3 seconds to turn it on. The LED lights will illuminate, and a voice prompt will indicate the device is ready.

Microphone Pairing

The wireless microphone is designed for automatic pairing with the speaker. Simply turn on the microphone, and it will connect to the speaker within a few seconds. No manual pairing is required.

Initial Bluetooth Connection

Turn on the karaoke machine. Activate Bluetooth on your mobile device (smartphone, tablet, PC). Search for**"JYX-D17"** in the Bluetooth device list and select it to connect. A voice prompt will confirm successful connection, and you can now play audio from your device through the speaker.



A smartphone screen displaying Bluetooth settings, showing the JYX-D17 device ready for connection, alongside the karaoke machine and other compatible devices like laptops and tablets.

4. Operating Instructions

Playing Music

Once connected via Bluetooth, you can play music from any application on your device. The karaoke machine also supports Micro TF cards and AUX input for alternative music sources. Insert a Micro TF card into the designated slot or connect an external audio device using the AUX cable.



An exploded view of the JYX Mini Karaoke Machine speaker, highlighting its internal components such as the DSP chip, HiFi sound drivers, and showing 360-degree surround sound capabilities.

Using the Microphone

The wireless microphone allows you to sing along to your favorite songs. Adjust the microphone volume using the **+/-** buttons located on the microphone itself. Ensure the microphone is within range of the speaker for optimal performance.

Voice Modulation Effects

The microphone features 4 entertaining voice effects to add fun to your karaoke sessions:**Original, KTV, Monster, and Female voice**. Press the dedicated button on the microphone to cycle through these effects and transform your voice.



An illustration depicting the various voice modulation effects available on the JYX Mini Karaoke Machine, including Monster, Female, Baby, Original, and Karaoke voices.

LED Party Lights

The speaker features vibrant LED lights that automatically change colors, enhancing the party atmosphere. These lights are synchronized with the music to create a dynamic visual experience.

5. Maintenance

Cleaning

Wipe the device with a soft, dry cloth. Do not use abrasive cleaners, solvents, or strong chemicals, as these may damage the surface or internal components.

Storage

Store the karaoke machine in a cool, dry place away from direct sunlight, high humidity, and extreme temperatures. Keep it away from dust and liquids.

Battery Care

To prolong battery life, fully charge the device before first use and at least once every three months if not in regular use. Avoid completely draining the battery frequently, as this can reduce its overall lifespan.

6. Troubleshooting

Common Issues and Solutions

Problem	Solution
No Sound	Check volume levels on both the karaoke machine and your connected device. Ensure Bluetooth is connected or the AUX/TF card is properly inserted.
Microphone Not Connecting	Ensure the microphone is charged and powered on. Restart both the speaker and microphone. If issues persist, try re-pairing by turning both off and on again.
Short Battery Life	Ensure the device is fully charged before use. Battery performance may vary based on usage and volume levels. Reduce volume or LED light usage to extend playtime.
Static/Distortion	Move closer to the speaker if using the wireless microphone. Ensure no strong electromagnetic interference sources (e.g., Wi-Fi routers, other Bluetooth devices) are nearby.

7. Specifications

Technical Details

Feature	Detail
Model Number	D17
Brand	JYX
Item Weight	1.52 pounds (0.69 Kilograms)
Product Dimensions	3.94 x 3.54 x 4.33 inches
Power Source	Battery Powered
Connectivity	Bluetooth 5.0, AUX, Micro TF Card
Audio Input	Wireless Microphones, AUX input
Speaker Count	3
Battery Life	6-8 hours playtime
Charging Time	2-3 hours
Voltage	5 Volts

8. Warranty and Support

Warranty Information

This JYX Mini Karaoke Machine comes with a 1-year warranty from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, technical assistance, or issues not covered in this manual, please do not hesitate to contact our dedicated customer support team. JYX is committed to providing professional and timely assistance.

Email: service@jyxspeaker.com

JYX also offers lifetime technical support to ensure you have the best experience with your product.



An illustration detailing JYX customer support features, including fast delivery, 360 days warranty service, US local after-sales center, and lifetime technical support, with an email address for inquiries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CGWTSGY2

More documents and user manuals: **https://manuals.plus/**