Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JYX D17G-T

JYX Mini Karaoke Machine User Manual

Model: D17G-T | Brand: JYX

1. Introduction

Thank you for choosing the JYX Mini Karaoke Machine. This portable Bluetooth speaker with wireless microphones is designed to provide high-quality audio and entertainment for various occasions. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. What's in the Box

- JYX Mini Karaoke Machine (Speaker Unit)
- Wireless Microphones (x2)
- Charging Cable
- Audio Cable
- User Specification Manual (this document)



Figure 2.1: Package Contents. The image displays the compact speaker unit, two wireless microphones, a charging cable, and an audio cable.

3. Product Overview

The JYX Mini Karaoke Machine features a compact design with intuitive controls and vibrant LED lighting. It includes two wireless microphones for duet performances.



Figure 3.1: JYX Mini Karaoke Machine. The main speaker unit is shown with its integrated handle and colorful LED light ring, alongside two wireless microphones.



Figure 3.2: Front View. This image provides a clear view of the speaker's front grille and the design of the microphones.



Figure 3.3: Back View. This image shows the rear panel of the speaker, including various ports and controls.

4. Setup

4.1 Charging the Device

Before first use, fully charge the karaoke machine and microphones. The built-in rechargeable battery provides 6-8 hours of playtime and takes approximately 2-3 hours to fully charge.

- Connect the charging cable to the speaker's charging port and a USB power adapter (not included).
- Connect the microphones to their respective charging ports using the provided cables.

4.2 Power On/Off

Press and hold the power button on the speaker unit to turn it on or off. Similarly, press and hold the power button on each microphone to activate or deactivate them.

4.3 Connecting to Audio Sources

The JYX Mini Karaoke Machine offers multiple connectivity options:

- **Bluetooth 5.0:** For quick pairing and stable transmission with mobile phones, iPads, tablets, and PCs.
- **Micro TF Card:** Insert a Micro TF card into the designated slot for direct music playback.
- **AUX-in:** Use the provided audio cable to connect devices via the AUX-in port.



Figure 4.1: Multiple Connection Methods. This image illustrates the various ways to connect audio sources, including Bluetooth, AUX-IN, and TF Card, compatible with cellphones, computers, and iPads.

5. Operating Instructions

5.1 Microphone Operation

Each wireless microphone has controls for power, volume, and voice effects.

- **Power Button:** Press and hold to turn on/off.
- **Volume Control:** Use the +/- buttons to adjust microphone volume.
- **Voice Change:** The microphones feature 4 kinds of magic sound: Original, KTV, Monster, and Female voice.
- **Vocal Removal:** Double-click the designated button on the microphone to remove or restore music vocals freely.



Figure 5.1: Wireless Microphone Features. This image details the controls on the microphones, including volume adjustment, voice effects, and vocal removal capabilities.



Figure 5.2: Funny Voice Changer. Visual representation of the various voice effects available on the microphones.

5.2 Speaker Controls

The speaker unit has controls for music playback and LED lights.

- **Volume Control:** Use the +/- buttons on the speaker to adjust the overall music volume.
- **Play/Pause:** Press the play/pause button to control music playback.
- **LED Lights:** The speaker is equipped with dynamic dancing lights that change into 7 colors. Press and hold the 'M' (Mode) button to cycle through the light colors. When not using the lights, you can switch them off.



Figure 5.3: Dynamic LED Lights. The speaker unit displays its vibrant, multi-color LED light ring, enhancing the party atmosphere.

6. Maintenance

- Keep the device dry. Do not expose it to water or excessive moisture.
- Clean the speaker and microphones with a soft, dry cloth. Avoid using harsh chemicals or abrasive cleaners.
- Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- When not in use for extended periods, charge the battery periodically to maintain its lifespan.

7. Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Low battery.	Charge the device fully.

Problem	Possible Cause	Solution
No sound from speaker.	Volume too low; Incorrect input mode; Device not connected.	Increase volume; Switch input mode (Bluetooth/AUX/TF); Reconnect device.
Microphone not working.	Microphone off; Low microphone battery; Microphone not paired.	Turn on microphone; Charge microphone; Re-pair microphone with speaker.
Bluetooth connection unstable.	Device too far; Interference.	Move devices closer; Avoid obstacles or other wireless devices.
Short battery life.	Battery not fully charged; Old battery.	Ensure full charge (2-3 hours); Contact customer service if issue persists.

8. Specifications

- **Model Number:** D17G-T
- **Item Weight:** 1.23 pounds
- **Product Dimensions:** 3.54 x 4.33 x 3.94 inches
- **Batteries:** 1 A battery (included)
- **Color:** Gray-2Mic
- **Connector Type:** 3.5 mm Jack
- **Speaker Count:** 1
- **Power Source:** Battery Powered
- **Special Feature:** Portable, Lightweight, Light Up Speaker, Rechargeable
- **Included Components:** Microphone, Battery
- **Recommended Uses:** Home Parties, Outdoor Events, Family Gatherings, Birthdays, Conferences, Classes, Children's Gifts

9. Warranty and Support

JYX offers a **1-year warranty** for this product. Our dedicated customer service team is available 24 hours a day to assist you with any questions or issues you may encounter.
For technical support or warranty claims, please contact us at:service@jyxspeaker.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CGWX1WNM

More documents and user manuals: **https://manuals.plus/**