SPPRANDOM 4K Ultra HD Waterproof Camcorder

SPPRANDOM 4K Ultra HD Waterproof Camcorder User Manual

MODEL: 4K ULTRA HD WATERPROOF CAMCORDER

Introduction

Thank you for choosing the SPPRANDOM 4K Ultra HD Waterproof Camcorder. This device is designed to capture high-quality video and photos in various environments, including underwater. Please read this manual carefully to ensure proper operation and to maximize your enjoyment of the product.

Package Contents

- SPPRANDOM 4K Ultra HD Waterproof Camcorder
- Battery
- USB Cable
- User Manual
- 64GB SD Card (included)

Setup

1. Charging the Battery

Before first use, fully charge the camcorder's 3400mAh battery. Connect the camcorder to a power source using the provided USB cable. The charging indicator light will show the charging status.

2. Inserting the SD Card

This camcorder supports SD cards up to 128GB (a 64GB SD card is included). Locate the SD card slot, typically behind a protective cover. Insert the SD card with the metal contacts facing the correct direction until it clicks into place. **Important:** Format the SD card through the camcorder's menu system before its first use to ensure compatibility and optimal performance.

3. Powering On/Off

Press and hold the Power button to turn the camcorder on or off. The screen will illuminate upon successful power-on.



Image: The SPPRANDOM 4K Ultra HD Waterproof Camcorder, showing its compact design.

Operating the Camcorder

1. Basic Controls

- **Record Button:** Press once to start recording video, press again to stop.
- **Photo Button:** Press to capture a still image.
- **Zoom Controls:** Use the T (Telephoto) and W (Wide-angle) buttons to adjust the 18X digital zoom.
- **Menu Button:** Access the camcorder's settings and options.
- **Mode Button:** Switch between video recording, photo capture, and playback modes.

2. Waterproof Usage

The camcorder is waterproof up to 16.4 feet (5 meters). Ensure all port covers and the battery compartment are securely sealed before submerging the device in water. After use in saltwater, rinse the camcorder with fresh water and dry thoroughly.

3. Video and Photo Quality

Capture videos in 4K Ultra HD at 30 frames per second (FPS) and photos up to 56 megapixels. The camcorder features stabilization to reduce blur and shakiness in your recordings.

Maintenance

1. Cleaning

Wipe the camcorder body with a soft, dry cloth. For the lens, use a specialized lens cleaning cloth and solution. Do not use harsh chemicals or abrasive materials.

2. Storage

Store the camcorder in a cool, dry place away from direct sunlight and extreme temperatures. If storing for extended periods, remove the battery.

3. Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Charge the battery regularly, even if the camcorder is not in use.

Troubleshooting

- **Camcorder does not power on:** Ensure the battery is fully charged and correctly inserted.
- **SD card error:** Reformat the SD card via the menu. If the issue persists, try a different compatible SD card.
- **Blurry or unstable video:** Ensure the lens is clean. Utilize the camcorder's stabilization features.
- **Poor battery life:** Ensure the battery is fully charged. Battery performance can degrade over time.

Specifications

Video Resolution	4K Ultra HD (30FPS)
Photo Resolution	56 Megapixels
Digital Zoom	18X
Waterproof Depth	Up to 16.4 feet (5 meters)
Battery Capacity	3400mAh
Screen Size	3 Inches
Video Capture Format	MP4
Included Components	Battery, USB Cable, User Manual, 64GB SD Card
Dimensions	7.5 x 6 x 2 inches

Warranty and Support

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package

for specific terms and conditions. For technical support or service inquiries, please contact SPPRANDOM customer service. Contact details are typically found on the product packaging or the official brand website.

© 2023 SPPRANDOM. All rights reserved.