Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

truke B0CH1FCL71

User Manual

TRUKE INFINITYBOX 50W BLUETOOTH PARTY SPEAKER

Model: B0CH1FCL71

1. SETUP

1.1 Unboxing

Carefully remove all components from the packaging. Ensure the following items are present:

- 1 U Bluetooth Speaker

1.2 Initial Charging

Before first use, fully charge the speaker. Connect the provided Type-C charging cable to the speaker's charging port and a compatible power source. The built-in 4 LED battery indicators will provide clear feedback on the charging status.



Image: Truke InfinityBox speaker highlighting the Fast Type-C Charging and Battery Indicators.

1.3 Powering On/Off

To power on the speaker, long press the Power button (marked with a circle symbol) located on the integrated control panel. To power off, long press the same button again.



Image: Truke InfinityBox speaker displaying its integrated control panel with the power button highlighted.

2. Operating Instructions

2.1 Bluetooth Pairing

The speaker utilizes Bluetooth 5.3 for a stable and seamless connection. Upon powering on, the speaker will automatically enter pairing mode. Search for "truke InfinityBox" on your device's Bluetooth settings and select it to connect. A confirmation sound will indicate successful pairing.

2.2 Audio Playback

The speaker supports multiple playback options:

- **Bluetooth:** Stream audio wirelessly from your smartphone, tablet, or other Bluetooth-enabled devices.
- **AUX:** Connect external audio devices using a 3.5mm auxiliary cable (not included).

- **TF/USB:** Insert a TF card or USB drive with supported audio formats (MP3, WAV, AAC, WMA, FLAC) for direct playback.
- **FM Radio:** Switch to FM radio mode to listen to local radio stations.



Image: Truke InfinityBox speaker illustrating its versatile playback options including FM, AUX, and Bluetooth connectivity.

2.3 TWS Function (True Wireless Stereo)

For an enhanced stereo sound experience, you can pair two truke InfinityBox speakers together. Power on both speakers. On one speaker, short press the TWS button (indicated by two interlocking arrows). The speakers will automatically connect to each other, creating a true wireless stereo setup.



Image: Two Truke InfinityBox speakers demonstrating the TWS function for a combined 100W powerful sound.

2.4 Integrated Controls

The speaker features intuitive controls for easy management:

- **Power Button (Circle Symbol):** Long press to Power On/Off.
- **RGB Mode Button (Sun Symbol):** Short press to switch between different RGB lighting modes.
- **Volume Up (+) Button:** Short press to increase volume. Long press for next track.
- **Play/Pause Button (Play/Pause Symbol):** Short press to play or pause music.
- **Volume Down (-) Button:** Short press to decrease volume. Long press for previous track.
- **Mode Button (M):** Short press to switch between Bluetooth, FM Radio, AUX, and TF/USB modes.
- **TWS Button (Interlocking Arrows):** Short press to activate TWS pairing.
- **Battery Indicator (Three Dots):** Displays current battery level.



Image: A comprehensive diagram detailing the functions of each integrated control button on the Truke InfinityBox speaker.

2.5 Dynamic RGB Lighting

The speaker features dynamic RGB lighting that can sync with your music or be set to a static mode. Use the RGB Mode button to cycle through the available lighting effects. You also have the option to turn off the LEDs for a more subdued setting.



Image: Truke InfinityBox speaker showcasing its dynamic RGB lighting feature, enhancing the party ambiance.

3. Maintenance

3.1 Cleaning

To clean the speaker, use a soft, dry, lint-free cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish. Avoid exposing the speaker to excessive moisture.

3.2 Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is partially charged before storage to maintain battery health.

4. Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on	Low battery; Power button not pressed correctly	Charge the speaker fully; Long press the power button for 3-5 seconds.
No sound	Volume too low; Incorrect input mode; Device not connected	Increase volume on speaker and connected device; Press 'M' button to cycle through input modes; Re-pair Bluetooth device or check AUX/USB connection.
Bluetooth pairing fails	Speaker not in pairing mode; Device too far; Interference	Ensure speaker is in pairing mode (blinking indicator); Move device closer to speaker; Turn off other Bluetooth devices nearby.
Distorted sound	Volume too high; Low battery; Poor signal	Reduce volume; Charge the speaker; Move connected device closer or reduce interference.

5. Specifications

Feature	Detail
Brand	truke
Model Name	truke_BW-5000_Black
Product Dimensions	35 x 14 x 19 cm
Item Weight	2.2 kg
Speaker Type	Bluetooth Party Speaker
Connectivity Technology	Bluetooth 5.3
Speakers Nominal Output Power	50 Watts
Speaker Surround Sound Channel Configuration	2.2
Audio Output Mode	Stereo
Supported Audio Formats	MP3, WAV, AAC, WMA, FLAC
Power Source	Battery Powered
Battery Average Life	Up to 12 Hours (without RGB LEDs), Up to 9 Hours (with RGB LEDs)
Battery Cell Composition	Lithium Polymer
Charging Type	Type-C
Special Features	Integrated Controls, Fast Type-C Charging & Battery Indicators, TWS Function, Multiple playback options (Bluetooth, AUX, TF/USB, FM radio), Dynamic RGB Lighting

6. Warranty and Support

The truke InfinityBox 50W Bluetooth Party Speaker comes with a **12-month warranty**, assuring quality and customer satisfaction. truke maintains a vast service network of 350+ service points to ensure convenient and accessible support. For warranty claims or technical assistance, please refer to the contact information provided on the official truke website or your purchase documentation.

© 2025 truke. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CH1FCL71

More documents and user manuals: **https://manuals.plus/**