Mabe EM7622BAPS2

Mabe EM7622BAPS2 76 cm Floor Stove User Manual

Model: EM7622BAPS2 | Brand: Mabe

Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your Mabe EM7622BAPS2 76 cm Floor Stove. Please read all instructions carefully before using the appliance to ensure proper function and to prevent injury or damage.



Figure 1: Front view of the Mabe EM7622BAPS2 Floor Stove.

Important Safety Instructions

Always follow basic safety precautions when using this appliance to reduce the risk of fire, electric shock, or injury to persons.

- Read all instructions before using the appliance.
- Ensure proper installation and grounding by a qualified technician.
- Do not store flammable materials in or near the stove.
- Never use the appliance for space heating.
- Always supervise children when they are near the appliance.
- Use dry potholders; moist or damp potholders on hot surfaces may result in burns from steam.
- Do not touch heating elements or interior surfaces of the oven during or immediately after use.

Setup and Installation

The Mabe EM7622BAPS2 is a freestanding floor stove. Proper installation is crucial for safety and performance. It is recommended that installation be performed by a certified professional.

Unpacking

1. Carefully remove all packaging materials, including tape and protective films.
2. Inspect the stove for any shipping damage. Report any damage immediately to the retailer.
3. Ensure all components are present: stove unit, wire grates, burner caps, and user manual.

Placement

- Place the stove on a level, stable surface.
- Maintain adequate clearance from combustible materials as per local codes.
- Ensure proper ventilation in the kitchen area.

Gas and Electrical Connections

All gas and electrical connections must comply with local codes and be performed by a qualified technician.

- **Gas Connection:** Connect the stove to the gas supply using a flexible metal connector. Check for leaks using a soap solution.
- **Electrical Connection:** Plug the stove into a properly grounded electrical outlet.



Figure 2: Rear view illustrating connection points for the Mabe EM7622BAPS2.

Operating Instructions

Cooktop Operation

The cooktop features durable wire grates and multiple burners for versatile cooking.



Figure 3: Top view of the cooktop with burners and grates.

1. Place cookware on the appropriate burner grate.
2. Push in and turn the corresponding burner knob to the "LITE" position.
3. Once the burner ignites, adjust the flame to the desired intensity.
4. To turn off, turn the knob to the "OFF" position.

Oven Operation

The oven is equipped with **Perfect Cook Technology**, which ensures improved heat distribution for evenly cooked food, both inside and out. The **Termocontrol** feature offers 5 temperature ranges to suit various recipes.



Figure 4: Oven interior with racks.

1. Open the oven door and place food on the oven rack.
2. Close the oven door.
3. Turn the oven control knob to the desired temperature setting. The oven will begin to preheat.
4. The oven features 5 temperature ranges for precise cooking.
5. Monitor food through the oven window.
6. When cooking is complete, turn the oven control knob to the "OFF" position.



Figure 5: Oven in use, showcasing even baking with Perfect Cook Technology.

Care and Maintenance

Regular cleaning and maintenance will extend the life of your Mabe stove and ensure optimal performance.

Cooktop Cleaning

- Allow burners and grates to cool completely before cleaning.
- Remove grates and burner caps. Wash with warm, soapy water.
- Wipe the cooktop surface with a damp cloth and mild detergent.
- Do not use abrasive cleaners or scouring pads, as they can scratch the surface.

Oven Cleaning

The oven interior features a smooth finish that minimizes food adhesion, making cleaning easier.

- Ensure the oven is cool before cleaning.
- Remove oven racks. Wash with warm, soapy water.
- Wipe the interior surfaces with a damp cloth and a mild oven cleaner (if necessary, follow cleaner instructions).
- Avoid harsh chemicals on the oven door gasket.

Exterior Cleaning

- Wipe exterior surfaces with a soft cloth and mild soapy water.
- For stainless steel parts, use a specialized stainless steel cleaner.

Troubleshooting Guide

Before calling for service, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Burner does not ignite.	Gas supply off; burner ports clogged; igniter wet.	Check gas valve; clean burner ports; dry igniter.
Oven not heating.	Power supply issue; oven control knob not set correctly.	Check circuit breaker; ensure knob is set to a temperature.
Uneven cooking in oven.	Food placed too close to elements; oven not preheated.	Adjust rack position; allow oven to fully preheat.
Gas odor.	Gas leak.	**Immediately turn off gas supply, open windows, and call a qualified technician. Do not operate electrical switches.**

Product Specifications

Feature	Detail
Brand	Mabe
Model Number	EM7622BAPS2
Type	Floor Stove
Size	76 cm
Color	Plata Mercury (Silver Mercury)
Material	Stainless Steel
Installation Method	Freestanding
Product Dimensions (L x W x H)	29.92 x 29.92 x 37.01 cm
Weight	37 kg
Oven Technology	Perfect Cook, Termocontrol (5 temperature ranges)

Feature	Detail
Cooktop Grates	Wire Grates

Warranty and Support

For warranty information, please refer to the documentation included with your purchase or contact Mabe customer service. Mabe offers dedicated service for installation, repair, and maintenance.
To schedule service, please contact:

Telephone: 461 471 7000

WhatsApp: 55 41635939



Figure 6: Mabe Service contact information.

You can also visit the official Mabe store on Amazon for more product information: Mabe Official Store.

© 2023 Mabe. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question