Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Schleich 42658-23

Instruction Manual: Schleich Farm World - Feeding the Forest Animals Playset

Brand: Schleich | Model: 42658-23

Product Overview

The Schleich Farm World Feeding the Forest Animals Playset is a 39-piece toy set designed to inspire imaginative play centered around caring for forest animals. This detailed playset allows children to create their own farm world scenarios, fostering creativity and understanding of animal care.



Image: The complete Schleich Farm World Feeding the Forest Animals Playset, showing the product packaging and the assembled playset with all included figures and accessories.

Contents

This 39-piece set includes the following components:

- Building with seesaw/ramp
- Doe figure
- Baby deer figure
- Hedgehog figure
- Red squirrel figure
- Carrots (multiple pieces)
- Apples (multiple pieces)
- Hay bales (multiple pieces)
- Other assorted accessories for feeding and play



Image: A close-up view of the assembled feeding station with the doe, fawn, hedgehog, and squirrel figures, along with various food accessories like carrots, apples, and hay.

Assembly Instructions

The Feeding the Forest Animals Playset is designed for easy assembly. Most components snap together or are ready for immediate play. Follow these general steps:

1. Unpack all components from the packaging and verify all pieces are present against the contents list.
2. Assemble the main building structure. The roof (red piece) typically snaps onto the yellow feeder base.
3. Attach the green seesaw/ramp piece to the designated slot on the side of the feeder building.
4. Place the food accessories (carrots, apples, hay) into the feeding troughs or around the playset as desired.
5. Position the animal figures (doe, fawn, hedgehog, squirrel) around the feeder to begin play.



Image: A top-down perspective of the assembled feeder, showcasing the various food items placed within the troughs and the animal figures positioned nearby, ready for interactive play.

Playing with Your Playset

This playset encourages open-ended imaginative play. Children can:

- Feed the deer, fawn, hedgehog, and squirrel with the included food accessories.
- Use the seesaw/ramp for the smaller animals to climb or play on.
- Create stories about the forest animals and their daily routines.
- Integrate the playset with other Schleich Farm World or Wild Life figures for expanded play scenarios.



Image: A child's hand gently placing the squirrel figure onto the green ramp of the feeding station, demonstrating interactive play with the set.

Care and Maintenance

To ensure the longevity of your Schleich playset, follow these care instructions:

- **Cleaning:** Wipe figures and playset components with a damp cloth. Use mild soap if necessary, then rinse thoroughly and air dry. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the playset in a clean, dry place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Handling:** While durable, avoid excessive force or bending of figures and components to prevent damage.

Safety Information

Please read and adhere to the following safety guidelines:

- **Recommended Age:** This playset is suitable for children aged 36 months (3 years) to 8 years.
- **Choking Hazard:** The set contains small parts and small balls. Not suitable for children under 3 years due to choking hazards. Adult supervision is recommended for younger children.
- **Material Safety:** All Schleich toys meet the highest national and international safety standards.

Troubleshooting

If you encounter any issues with your playset, please consider the following:

- **Missing Parts:** Carefully check all packaging materials. If parts are still missing, please contact Schleich customer support.
- **Assembly Difficulties:** Refer to the "Assembly Instructions" section. Ensure components are aligned correctly before applying gentle pressure to snap them into place. Do not force parts.
- **Damaged Parts:** If any part of the playset is damaged upon arrival, do not use it. Contact customer support for assistance.

Specifications

Product Dimensions	7.48 x 3.35 x 5.91 inches
Item Weight	0.011 ounces
Item Model Number	42658-23
Manufacturer Recommended Age	36 months - 8 years
Release Date	January 1, 2024
Manufacturer	Schleich

Warranty and Support

Schleich is committed to providing high-quality, durable toys. For any questions regarding your product, missing parts, or potential defects, please contact Schleich customer support directly. Information on how to reach customer support can typically be found on the product packaging or the official Schleich website.
Visit the official Schleich website for more information: www.schleich-s.com

© 2024 Schleich. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CH1JDC52

More documents and user manuals: **https://manuals.plus/**