Yomeie M22-C

Yomeie Rechargeable Fabric Shaver M22-C Gray Instruction Manual

Model: M22-C | Brand: Yomeie

1. Product Overview

The Yomeie Rechargeable Fabric Shaver M22-C is designed to efficiently remove lint, pills, and fuzz from various fabrics, restoring garments and upholstery to a fresh, clean appearance. It features ultra-sharp blades, a powerful motor, and a user-friendly design for effective fabric care.



Image: Fabric before and after using the Yomeie Fabric Shaver, demonstrating effective lint removal.

2. Package Contents

Please verify that all items are present in the package:

- Yomeie Rechargeable Fabric Shaver (M22-C)
- USB Charging Cable
- Extra Replacement Blades (2 sets)
- Cleaning Brush
- Instruction Manual (this document)



Image: The Yomeie Fabric Shaver, USB charging cable, and two sets of replacement blades.

3. Setup and Charging

3.1 Initial Charge

Before first use, fully charge the fabric shaver. The device has a built-in rechargeable lithium battery.

1. Ensure the shaver is turned **OFF**.
2. Connect the provided USB charging cable to the charging port on the shaver.
3. Connect the other end of the USB cable to a 5V DC USB power adapter (not included), power bank, or computer USB port.
4. The charging indicator light will illuminate. Allow the device to charge completely.



Image: The fabric shaver being charged via a USB cable connected to a laptop.

3.2 Battery Life

A full charge provides approximately 45-60 minutes of continuous operation.

4. Operating Instructions

4.1 Preparing the Fabric

For optimal results and to prevent damage, lay the garment or fabric flat on a hard, smooth surface. Stretch the fabric taut to ensure a smooth surface for shaving.



Image: Demonstrating the comfortable grip and ease of use while operating the shaver on a garment.

4.2 Using the Fabric Shaver

1. Ensure the metal mesh cover is securely attached. The safety switch prevents operation if the cover is loose.
2. Slide the power switch to the **ON** position. The blades will begin to rotate.
3. Gently press the shaver head onto the fabric surface. Move the shaver in small, circular motions or back and forth over the pilled areas.

4. Avoid excessive pressure, especially on delicate fabrics, to prevent damage.
5. Periodically check the lint collection container and empty it when full.
6. Once finished, slide the power switch to the **OFF** position.

4.3 Suitable Fabrics

The Yomeie Fabric Shaver is suitable for various fabric types, including:

- Woolen coats and sweaters
- Polyester garments
- Furniture upholstery (sofas, chairs)
- Blankets and quilts
- Scarves and skirts



Image: The fabric shaver is suitable for various fabrics including polyester, wool, and sweaters.

5. Maintenance and Cleaning

5.1 Emptying the Lint Container

For consistent performance, regularly empty the transparent lint collection container.

1. Ensure the shaver is turned **OFF**.
2. Gently detach the transparent lint container from the main body of the shaver.
3. Discard the collected lint and fuzz.
4. Reattach the lint container securely until it clicks into place.



Image: The transparent lint container being removed from the shaver for emptying.

5.2 Cleaning the Blades and Mesh Cover

To maintain cutting efficiency, clean the blades and mesh cover after each use.

1. Ensure the shaver is turned **OFF** and unplugged.
2. Carefully twist and remove the metal mesh cover.
3. Use the provided cleaning brush to remove any trapped lint or debris from the blades and inside the mesh cover.
4. Avoid touching the blades directly with your fingers.

5. Reattach the mesh cover securely.



Image: Cleaning the shaver blades with the provided brush.

5.3 Replacing Blades

If the shaver's performance decreases, the blades may need replacement. Two extra sets of blades are included.

1. Ensure the shaver is turned **OFF** and unplugged.
2. Remove the metal mesh cover and the old blade assembly.
3. Carefully place a new blade assembly onto the spindle, ensuring it sits correctly.
4. Reattach the metal mesh cover securely.

6. Safety Precautions

- Keep out of reach of children.
- Do not use on wet fabrics.
- Do not press too hard on delicate fabrics to avoid damage.
- Always turn off the device before cleaning or replacing blades.
- Ensure the mesh cover is securely in place before operating to activate the safety switch.
- Do not disassemble the main body of the shaver beyond routine cleaning.

7. Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is low or depleted. Mesh cover is not securely attached.	Charge the shaver fully. Ensure the mesh cover is twisted on tightly.
Poor lint removal performance.	Lint container is full. Blades are dull or clogged. Fabric is not stretched taut.	Empty the lint container. Clean the blades or replace them. Lay fabric flat and stretch it.
Shaver stops during use.	Battery is depleted. Mesh cover became loose.	Recharge the shaver. Re-secure the mesh cover.

8. Specifications

Brand: Yomeie

Model: M22-C

Material: Plastic, Stainless Steel

Color: Gray

Operation Mode: Automatic

Motor Speed: Up to 8000 RPM

Power Source: Rechargeable Lithium Battery (USB 5V DC charging)

Run Time: 45-60 minutes (approx.)

Item Weight: 5.4 ounces

Package Dimensions: 6.02 x 3.03 x 2.64 inches

UPC: 787505891592

9. Warranty and Support

Yomeie products are manufactured to high-quality standards. For information regarding warranty coverage, product support, or replacement parts, please refer to the contact information provided with your purchase or visit the official Yomeie website.
For further assistance, please contact Yomeie customer service.

© 2023 Yomeie. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question