Acer VZ2594G

Acer Veriton Z2 VZ2594G All-in-One PC User Manual

Model: VZ2594G (Part No. DQ.VX2EB.009)

Introduction

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Acer Veriton Z2 VZ2594G All-in-One PC. Please read this guide thoroughly before using your device to ensure proper function and safety. Keep this manual for future reference.

Safety Precautions:

- Always disconnect the power cord from the electrical outlet before cleaning.
- Do not expose the device to rain or moisture.
- Avoid placing the device near heat sources or in direct sunlight.
- Use only Acer-approved power adapters and accessories.

Setup

Follow these steps to set up your Acer Veriton Z2 VZ2594G All-in-One PC.

1. Unpacking

1. Carefully remove the PC and all accessories from the packaging.
2. Verify that all components are present: All-in-One PC, power adapter, power cord, wired keyboard, and wired mouse.

2. Connecting Peripherals

Connect the included keyboard and mouse to the available USB ports on the back or side of the PC.

3. Connecting Power

1. Connect the power adapter to the DC-in port on the PC.
2. Plug the power cord into the power adapter, then into a grounded electrical outlet.

4. Initial Power-On

1. Press the power button, usually located on the side or bottom bezel of the display.
2. The PC will boot up and guide you through the Windows 11 Pro initial setup process. Follow the on-screen instructions to configure your language, region, network, and user account.



Image: Acer Veriton Z2 VZ2594G All-in-One PC. This image shows the front view of the all-in-one computer, highlighting its integrated display and compact design.

Operating

This section covers basic operation of your Acer Veriton Z2 VZ2594G.

1. Windows 11 Pro Navigation

Your PC comes pre-installed with Windows 11 Pro. Familiarize yourself with the Start Menu, Taskbar, and File Explorer for efficient navigation.

2. Network Connectivity

- **Wi-Fi:** Click the network icon in the Taskbar, select your desired Wi-Fi network, enter the password, and click Connect. The PC supports 802.11a/b/g/n/ac/ax standards.
- **Bluetooth:** To connect Bluetooth devices (e.g., headphones, speakers), go to*Settings > Bluetooth & devices*, turn on Bluetooth, and pair your device. The PC features Bluetooth 5.0.
- **Ethernet (GigE):** For a wired connection, plug an Ethernet cable into the RJ-45 port on the back of the PC.

3. Display Settings

The PC features a 23.8-inch Full HD (1920 x 1080) LED display. You can adjust display settings by right-clicking on the desktop and selecting *Display settings*. Here you can change resolution, scale, and refresh rate (up to 75 Hz).

4. Using External Displays

The PC includes one HDMI port. To connect an external monitor, plug an HDMI cable from the PC to the monitor. Press **Windows key + P** to select display modes (Duplicate, Extend, Second screen only).

Maintenance

Regular maintenance helps ensure the longevity and optimal performance of your PC.

1. Cleaning

- **Screen:** Use a soft, lint-free cloth lightly dampened with water or a screen cleaner. Do not spray liquid directly onto the screen.
- **Chassis:** Wipe the exterior surfaces with a soft, dry cloth. Avoid abrasive cleaners.
- **Vents:** Periodically use compressed air to clear dust from the ventilation openings to prevent overheating.

2. Software Updates

Keep your Windows 11 Pro operating system and drivers updated. Go to *Settings > Windows Update* to check for and install available updates. Regular updates improve security and performance.

3. Data Backup

Regularly back up your important files to an external drive or cloud storage service to prevent data loss.

Troubleshooting

This section addresses common issues you might encounter with your PC.

1. No Power

- Ensure the power cord is securely connected to the PC, power adapter, and electrical outlet.
- Test the electrical outlet with another device to confirm it is working.
- Try a different power cord or adapter if available.

2. No Display

- Check if the PC is powered on (power indicator light).
- If an external monitor is connected, ensure it is powered on and set to the correct input source.
- Restart the PC.

3. Network Connectivity Issues

- **Wi-Fi:** Restart your router and modem. Ensure Wi-Fi is enabled on the PC. Run the Windows Network Troubleshooter (*Settings > Network & internet > Advanced network settings > Network troubleshooter*).
- **Bluetooth:** Ensure Bluetooth is enabled and your device is in pairing mode. Try removing and re-pairing the device.
- **Ethernet:** Check the Ethernet cable connection. Verify your router/modem is functioning correctly.

4. System Slowdown

- Close unnecessary applications running in the background.
- Check for and install Windows updates.
- Run a disk cleanup and defragmentation (for HDD, not necessary for SSD).
- Scan for malware or viruses.

Specifications

Key technical specifications for the Acer Veriton Z2 VZ2594G All-in-One PC.

Feature	Specification
Brand	Acer
Model Series	VZ2594G
Part Number	DQ.VX2EB.009
Operating System	Windows 11 Pro
Processor	Intel Core i5-1235U (1.3 GHz)
RAM	16 GB
Storage	512 GB SSD
Graphics	Intel UHD Graphics (Integrated)
Display Size	23.8 Inches
Display Resolution	1920 x 1080 (Full HD) @ 75 Hz
Wireless Connectivity	802.11a/b/g/n/ac/ax, Bluetooth 5.0
Wired Connectivity	Gigabit Ethernet (GigE)
Ports	HDMI (1 port), USB ports (quantity not specified, typically multiple)
Keyboard Description	Wired QWERTY Keyboard

Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product or visit the official Acer website. Acer provides technical support for its products.
If you encounter issues that cannot be resolved using this manual, please contact Acer customer support through their official website or designated support channels. Have your product model and serial number ready when contacting support.

- **Online Support:** Visit www.acer.com/support
- **Phone Support:** Refer to your region's Acer website for local contact numbers.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question