Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZXSYYDS B0CH69YTRM

ZXSYYDS Fully Automatic Cordless Robotic Pool Cleaner User Manual

Model: B0CH69YTRM

Introduction Safety Information Package Contents Product Overview Setup Operation Maintenance Troubleshooting Specifications Support

1. Introduction

This manual provides detailed instructions for the safe and efficient operation, setup, and maintenance of your ZXSYYDS Fully Automatic Cordless Robotic Pool Cleaner. This intelligent cleaning robot is designed to filter and clean the bottom of your pool without the need for external power cords, offering convenience and effective cleaning performance.

2. Safety Information

Please read all safety warnings and instructions carefully before using this product to prevent injury or damage. Keep this manual for future reference.

- Always ensure the charger is disconnected from the power outlet before handling the cleaner.
- Do not operate the cleaner if the charging port cover is not securely closed.
- Keep children and pets away from the pool area when the cleaner is in operation or charging.
- Use only the provided power adapter for charging.
- Do not attempt to open or repair the cleaner's internal components. Refer to qualified service personnel.
- Avoid using the cleaner in water temperatures outside the recommended range (typically 10°C - 35°C / 50°F - 95°F).
- Ensure the pool is free of large debris that could obstruct the cleaner's movement or damage its components.
- Do not use the cleaner if any part is damaged.

3. Package Contents

Verify that all items listed below are included in your package:

- 1 × Cordless Pool Cleaner
- 1 × Power Adapter
- 1 × User Manual

4. Product Overview and Features

The ZXSYYDS Robotic Pool Cleaner is designed for efficient and hassle-free pool maintenance. Key features include:

- **Cordless Operation:** Eliminates tangled wires and the risk of electrical shorts, providing freedom of movement.
- **High-Density Filtration:** Equipped with a 160 µm (micrometer) fine filter to effectively capture leaves, dirt, and sand.
- **Intelligent Navigation:** Features a built-in smart program for regular cleaning paths and automatic stopping at the pool edge or corner when work is complete or battery is low.
- **Long Battery Life:** Integrated 2600mAh battery provides approximately 90 minutes of cleaning time on a full charge.
- **Dual Suction Doors:** Two large suction doors work with a bottom brush for comprehensive cleaning.



Image 1: A detailed view of the robotic pool cleaner.



Image 2: Overview of the robotic pool cleaner highlighting its efficient cleaning features. Note: The filter density in this image states 200μm and working time 120+ mins, while product specifications state 160μm and approximately 90 mins. Please refer to the specifications section for the most accurate information.



Image 3: Dimensions of the robotic pool cleaner, showing its compact size.



Image 4: Illustration of the hassle-free cordless operation, emphasizing the absence of tangled cords and messy hoses.



Image 5: Examples of applicable pool environments for the cleaner.

5. Setup

5.1 Initial Charging

1. Before first use, fully charge the pool cleaner.
2. Locate the charging port on the cleaner and ensure it is dry and clean.
3. Connect the power adapter to the cleaner's charging port, then plug the adapter into a standard electrical outlet.
4. The charging indicator light will illuminate (refer to product for specific light behavior, e.g., red for charging, green for fully charged).
5. Charging typically takes 3-4 hours. Do not overcharge.
6. Once fully charged, disconnect the power adapter and securely close the charging port cover to maintain its waterproof seal.

5.2 Preparing the Pool

- Ensure the pool water level is appropriate for operation.
- Remove any large objects, toys, or debris from the pool that could obstruct the cleaner.

6. Operating Instructions

6.1 Starting the Cleaner

1. Ensure the cleaner is fully charged and the charging port cover is sealed.
2. Turn the knob or press the power button (refer to your specific model for exact control) to activate the cleaner.
3. Gently lower the cleaner into the pool. It will begin its cleaning cycle automatically.
4. The cleaner is designed for flat-bottomed swimming pools, fiber swimming pools, PVC swimming pools, outdoor swimming pools, hot spring baths, hydrotherapy pools, and landscape pools.

6.2 Cleaning Cycle

The cleaner will operate for approximately 90 minutes on a full charge. It will navigate the pool bottom, collecting debris. When the cleaning cycle is complete or the battery is low, the cleaner will automatically move to the edge or corner of the pool for easy retrieval.

6.3 Retrieving the Cleaner

Once the cleaner has stopped at the pool edge, use a pool hook (not included, but often available as an accessory) to gently lift the cleaner out of the water. Allow excess water to drain before removing it completely.

Your browser does not support the video tag.

Video 1: Demonstration of a hook accessory for robotic pool cleaners. This type of hook can be used to retrieve your ZXSYYDS cleaner from the pool.

7. Maintenance

7.1 Cleaning the Filter

1. After each cleaning cycle, or when the cleaner's performance decreases, the filter should be cleaned.
2. Open the cleaner's filter compartment (refer to your specific model for access instructions).
3. Remove the filter basket/cartridge.
4. Rinse the filter thoroughly with a garden hose to remove all trapped debris.
5. Ensure the filter is completely clean before reinserting it.
6. Close the filter compartment securely.

7.2 Storage

- When not in use, store the cleaner in a cool, dry place, away from direct sunlight and extreme temperatures.
- Ensure the cleaner is clean and dry before storing for extended periods.
- Charge the battery periodically during long storage to maintain battery health.

8. Troubleshooting

If you encounter issues with your pool cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Cleaner does not start.	Battery is low or depleted. Power button/knob not activated.	Charge the cleaner fully. Ensure the power button/knob is correctly engaged.
Poor cleaning performance.	Filter is clogged. Large debris obstructing suction.	Clean the filter basket/cartridge. Remove large debris from the pool manually.
Cleaner stops prematurely.	Battery is low. Obstruction detected.	Recharge the cleaner. Check for and remove any obstructions.
Cleaner does not move correctly.	Wheels or brushes are obstructed. Water depth is too shallow/deep.	Inspect and clear any obstructions from wheels/brushes. Ensure water depth is within specified limits (max 2.5 meters).

If the problem persists after attempting these solutions, please contact customer support.

9. Specifications

Technical specifications for the ZXSYYDS Automatic Pool Cleaner:

- **Product Name:** Automatic Pool Cleaner
- **Maximum Cleaning Area:** 60 m²
- **Control Method:** Automatic
- **Filtration Density:** 160 µm
- **Working Cycle:** Approximately 90 minutes
- **Maximum Water Depth:** 2.5 meters
- **Power:** 30W
- **Rated Input Voltage of Charger:** 110-240V
- **Rated Working Voltage:** 12V
- **Charging Time:** 3-4 hours
- **Protection Class:** IPX8
- **Number of Water Inlet and Sewage Suction Ports:**2
- **Size:** 14.4 × 12.2 × 6.5 inches
- **Item Weight:** 10.56 pounds
- **Power Source:** Battery Powered
- **Special Feature:** Cordless

10. Warranty and Support

For warranty information, please refer to the documentation provided with your purchase or contact the retailer. If you have any questions, require technical assistance, or need to report an issue, please contact ZXSYYDS customer support through the platform where you purchased the product. Please have your model number (B0CH69YTRM) and purchase date available when contacting support.

© 2026 ZXSYYDS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CH69YTRM

More documents and user manuals: **https://manuals.plus/**