ZdalaMit RC-518M

ZdalaMit RC-518M Replacement Remote Control User Manual

For Onkyo A/V Receivers HT-R410, HT-R420, HT-R510, TX-SR501, TX-SR501E

Introduction

This manual provides essential instructions for the proper setup, operation, and maintenance of your ZdalaMit RC-518M Replacement Remote Control. Please read this guide thoroughly to ensure optimal performance and longevity of your remote.

Product Overview

The ZdalaMit RC-518M is a direct replacement remote control designed for specific Onkyo A/V Receiver models. It offers full functionality without the need for complex programming.

Compatible Onkyo A/V Receiver Models:

- HT-R410
- HT-R420
- HT-R510
- TX-SR501
- TX-SR501E




Image: Comparison of the ZdalaMit RC-518M replacement remote (left) and the original Onkyo remote (right), highlighting their similar design and functionality.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AAA size alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Note: Batteries are not included with the remote control. Always use new alkaline batteries for best performance.



Image: Angled view of the ZdalaMit RC-518M remote control, illustrating its form factor and button arrangement.

Operating Instructions

Basic Operation

The ZdalaMit RC-518M remote control is designed for immediate use with compatible Onkyo A/V Receivers. **No programming is required.** Once batteries are installed, the remote is ready to operate your device.

1. Point the remote control directly at your Onkyo A/V Receiver.
2. Press the desired function button (e.g., Power, Volume Up/Down, Input Select) to control your receiver.
3. Ensure there are no obstructions between the remote control and the receiver's infrared sensor.





Image: Front view of the ZdalaMit RC-518M remote control, detailing the layout and labeling of all operational buttons.

Maintenance

Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Follow the battery installation steps outlined in the Setup section. Always replace both batteries at the same time with new ones.

Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

Troubleshooting

- **Remote is not responding:**
  - Ensure batteries are correctly installed with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Check for any obstructions between the remote's infrared emitter and the receiver's sensor.
  - Ensure you are within a reasonable operating range and pointing the remote directly at the receiver.
- **Remote is not controlling the Onkyo A/V Receiver:**
  - This remote control **does not require programming**. If it is not working, verify that your Onkyo A/V Receiver model is listed in the "Product Overview" section as compatible.
  - Confirm that the receiver is powered on.
  - If the issue persists after checking batteries and compatibility, the remote may be faulty.

Specifications

Model Number	RC-518M
Brand	ZdalaMit
Compatible Devices	Onkyo A/V Receivers (HT-R410, HT-R420, HT-R510, TX-SR501, TX-SR501E)
Power Source	2 x AAA Alkaline Batteries (not included)
Product Dimensions	6 x 2 x 0.5 inches
Item Weight	2 ounces
Color	Black
Special Feature	Ergonomic

Support

Should you have any questions or require further assistance with your ZdalaMit RC-518M Replacement Remote Control, please do not hesitate to contact the seller or manufacturer through your purchase platform. Provide your order details for quicker support.