Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Oraimo OSV-225A-GMUS

Oraimo Cordless Vacuum Cleaner User Manual

MODEL: OSV-225A-GMUS

1. Introduction

Thank you for choosing the Oraimo Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new vacuum cleaner. Please read it thoroughly before first use and retain it for future reference.

2. Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using an electrical appliance.

- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without dust cup and/or filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Store the appliance indoors.
- **Important:** Ensure the HEPA filter is always installed correctly before operation. Using the vacuum without a HEPA filter can damage the motor and reduce its lifespan.

3. Package Contents

Verify that all components are present in the package:

- Main Motor Unit with Dustbin and LED Display
- Detachable Battery Pack
- Extension Wand
- Motorized Floor Brush with Tangle Defender
- Crevice Tool
- 2-in-1 Brush Tool
- Wall Mount Bracket
- Power Adapter/Charger
- HEPA Filters (4 included for approximately 1 year of use)
- User Manual



Image: The Oraimo Cordless Vacuum Cleaner main unit, extension wand, floor brush, and various accessories including extra HEPA filters.

4. Product Overview

Familiarize yourself with the main components of your Oraimo Cordless Vacuum Cleaner:

- **Main Motor Unit:** Contains the motor, dustbin, and control panel with LED display.
- **LED Display:** Shows battery level, current suction mode, and error indicators.
- **Detachable Battery:** Provides power for cordless operation.
- **Extension Wand:** Connects the main unit to the floor brush or other attachments for extended reach.
- **Motorized Floor Brush:** Features an anti-entangle design and LED lights for improved visibility.
- **Attachments:** Crevice tool for narrow spaces, 2-in-1 brush tool for upholstery and delicate surfaces.



Image: Close-up of the Oraimo Cordless Vacuum Cleaner's LED display, showing battery indicator and suction level icons.

5. Setup

Follow these steps to assemble and prepare your vacuum cleaner for first use:

1. **Attach the Extension Wand:** Insert the top end of the extension wand into the main motor unit until it clicks securely.
2. **Attach the Floor Brush:** Insert the bottom end of the extension wand into the motorized floor brush until it clicks securely. Alternatively, attach desired accessories directly to the main motor unit for handheld use.
3. **Install the Battery:** Slide the detachable battery pack into the slot on the main motor unit until it locks into place.
4. **Initial Charging:** Before first use, fully charge the battery. Connect the power adapter to the charging port on the battery or the main unit, then plug it into a wall outlet. The LED display will indicate charging status. A full charge takes approximately 2.5 hours.
5. **Self-Standing Feature:** The vacuum is designed to stand upright on its own for convenient storage. Ensure it is placed on a flat, stable surface.



Image: The Oraimo Cordless Vacuum Cleaner standing upright on its own, demonstrating its self-standing feature.



Image: A close-up of the Oraimo Cordless Vacuum Cleaner's detachable battery being inserted into the main unit.

6. Operating Instructions

Learn how to effectively use your Oraimo Cordless Vacuum Cleaner:

1. **Power On/Off:** Press the power button on the main unit to turn the vacuum on. Press it again to turn off.
2. **Adjust Suction Power:** The vacuum features 3 power suction levels. Press the mode button on the main unit to cycle through Eco, Standard, and Max modes. The LED display will show the selected suction level. Max mode provides up to 24 Kpa suction for stubborn dirt.
3. **LED Display:** The large LED display shows the current battery level and selected suction mode. It also provides alerts for blockages or missing HEPA filter.
4. **Using the Floor Brush:** The motorized floor brush is suitable for various floor types, including hard floors and low-pile carpets. Its anti-entangle design helps prevent hair from wrapping around the brush roll. The integrated LED lights illuminate the cleaning path.
5. **Using Attachments:** For cleaning tight spaces, upholstery, or delicate surfaces, detach the extension wand and

attach the crevice tool or 2-in-1 brush tool directly to the main motor unit.



Image: The Oraimo Cordless Vacuum Cleaner actively cleaning a floor, illustrating its strong suction power picking up debris.



Image: A close-up view of the Oraimo Cordless Vacuum Cleaner's floor brush, highlighting its tangle defender feature with hair being prevented from wrapping around the brush roll.

7. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

- **Emptying the Dustbin:** Empty the dustbin after each use or when the MAX fill line is reached. Press the dustbin release button to detach it from the main unit, then open the bottom flap to dispose of debris.
- **Cleaning Filters:** The vacuum uses HEPA filters. It is recommended to clean the filters regularly by tapping out dust or rinsing with water. Ensure filters are completely dry before re-installing. The product includes 4 HEPA filters, sufficient for approximately one year of use with regular replacement.
- **Cleaning the Brush Roll:** Periodically check the motorized floor brush for tangled hair or debris. The tangle defender brush is designed to minimize entanglement, but occasional cleaning may still be necessary. Use scissors to cut away any stubborn hair and remove it.
- **Battery Care:** Store the battery in a cool, dry place. Avoid exposing it to extreme temperatures. If the vacuum will not be used for an extended period, charge the battery partially before storage.



Image: A clean HEPA filter, illustrating the type of filter used in the Oraimo Cordless Vacuum Cleaner.

8. Troubleshooting

The LED display provides alerts to help diagnose common issues:

Indicator on LED Display	Problem	Solution
Floor Brush Blockage	The motorized floor brush is obstructed.	Turn off the vacuum and remove any hair, debris, or foreign objects from the brush roll.
Air Duct Blockage	The air duct or main unit is blocked.	Check the extension wand, dustbin inlet, and main unit for blockages and clear them.
No HEPA	The HEPA filter is missing or incorrectly installed.	Ensure the HEPA filter is properly inserted into the dustbin assembly. Do not operate without the HEPA filter.
No Power / Not Charging	Battery is depleted or charging issue.	Ensure the battery is fully charged. Check if the power adapter is correctly connected to both the vacuum and the power outlet.
Reduced Suction	Dustbin is full, filters are clogged, or there's a blockage.	Empty the dustbin. Clean or replace the HEPA filters. Check for and clear any blockages in the floor brush, wand, or air duct.



Image: A user observing the Oraimo Cordless Vacuum Cleaner's LED display showing troubleshooting indicators for floor brush blockage, air duct blockage, and missing HEPA filter.



Image: The Oraimo Cordless Vacuum Cleaner displaying a 'No HEPA' reminder, emphasizing the importance of filter installation.

9. Specifications

Feature	Detail
Brand	Oraimo
Model Number	OSV-225A-GMUS
Special Feature	Larger LED display with error reminder
Filter Type	HEPA Filter
Cordless	Yes
Dustbin Capacity	500 Milliliters
Wattage	270 watts
Max Suction Power	24 Kpa
Charging Time	2.5 Hours
Form Factor	Stick
Battery Type	Lithium-Ion (2500 mAh * 6)
Noise Level	65 dB
Max Battery Life	45 minutes (Eco mode)
Number of Speeds	3
Product Dimensions	17.52 x 10.63 x 7.68 inches
Item Weight	3.74 pounds

10. Warranty and Support

The Oraimo Cordless Vacuum Cleaner Model OSV-225A-GMUS comes with a**2-year warranty**. For warranty claims, technical support, or any questions regarding your product, please contact Oraimo customer service through the official website or your purchase platform. Please have your model number (OSV-225A-GMUS) and proof of purchase ready.



Image: An overview of the Oraimo vacuum's features, including a prominent mention of a 2-year warranty.

© 2024 Oraimo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CH8T1GWP

More documents and user manuals: **https://manuals.plus/**