Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DEPFALL IZDUAULY

DEPFALL 40L Towel Warmer Bucket Instruction Manual

Model: IZDUAULY

1. Important Safety Instructions

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Electrical Safety:** Ensure the appliance is connected to a grounded outlet with the correct voltage (100-120V). Do not operate with a damaged cord or plug. Keep the power cord away from heated surfaces.
- **Water and Moisture:** Do not immerse the appliance in water or other liquids. Do not use near water, such as bathtubs, showers, or swimming pools, to avoid electrical hazards. Avoid using in environments with high humidity to prevent condensation damage to components.
- **Heat Safety:** The internal temperature can reach up to 235°F (113°C). Always exercise caution when removing items. The outer walls of the bucket are designed to remain safe to touch due to the PTC air heater, but internal components are hot.
- **UV Lamp:** The UV lamp is designed for sanitization. Avoid direct eye or skin exposure to UV light. Do not operate the UV lamp with the lid open for extended periods.
- **Material Compatibility:** Do not heat chemical fiber towels, chemical fiber clothing, or other materials that are not heat resistant. Only use with appropriate fabrics.
- **Children and Pets:** Keep the appliance out of reach of children and pets. Close supervision is necessary when the appliance is used by or near children.
- **Ventilation:** Ensure adequate ventilation around the appliance. Do not block the air outlet.
- **Fragrance Disc:** Use only approved fragrance discs or essential oils designed for this purpose. Do not use flammable liquids.

2. Product Overview

The DEPFALL 40L Towel Warmer Bucket is designed to provide warm, sanitized towels and other fabrics. It features a large capacity, adjustable temperature and timer settings, a UV sanitization lamp, and a fragrance disc holder for a customized experience.

Key Features:

- **40L Capacity:** Accommodates multiple large bath towels, bathrobes, blankets, and other items. Note: Usable

volume is approximately 35L due to internal components.

- **Quick and Even Heating:** Advanced PTC air heater provides rapid and consistent warming. Reaches high temperature in 6 minutes, warms towels in 25 minutes.
- **Adjustable Temperature:** Set heating temperature from 140°F to 185°F (60°C to 85°C). Maximum internal bucket temperature can reach 235°F (113°C).
- **Smart Timer & Delay Function:** Digital LED display with touch controls allows setting heating time from 15 minutes up to 12 hours. A 1-12 hour delay function is also available.
- **UV Lamp:** Integrated UV lamp for enhanced sanitization of items.
- **Fragrance Disc Holder:** Customize your experience by adding essential oils to the integrated holder.
- **Special Hooks:** Four detachable hooks for hanging smaller items like underwear, socks, or scarves. Remove hooks when heating oversized items.
- **Portable Design:** Features a carrying handle for easy relocation.



Image: Overview of the DEPFALL 40L Towel Warmer Bucket highlighting its features including flip-top lid, fragrant disc holder, LED display, UV light, hooks, carrying handle, and air outlet. Specifications like internal volume (40L), voltage (100-120V), max power (600W), noise (56.5dB), timing (15min-12H), temperature (140°F-185°F), and power cord length (5.9 feet) are also shown.

3. Setup

1. **Unpacking:** Carefully remove the towel warmer from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the towel warmer on a flat, stable, heat-resistant surface. Ensure it is not near water sources or in highly humid environments.
3. **Power Connection:** Plug the power cord into a grounded 100-120V electrical outlet.
4. **Fragrance Disc (Optional):** If desired, open the fragrance disc holder located on the underside of the lid. Add a few drops of essential oil to the disc and reinsert it securely.
5. **Hooks (Optional):** Insert the four detachable hooks into the designated slots inside the bucket if you plan to hang

small items. Remove them if heating larger items.

Image: A hand demonstrating how to insert a fragrance disc into the designated holder on the underside of the towel warmer's lid.



Image: A hand installing the detachable hooks inside the towel warmer bucket, illustrating their placement for hanging small items.

4. Operation

The DEPFALL Towel Warmer features a smart touch control panel for easy operation.



Image: A close-up view of the smart touch control panel on the towel warmer lid, showing buttons for UV, Delay, Setup, and On/Off, along with temperature and time adjustments.

4.1 Basic Heating:

1. **Load Items:** Open the flip-top lid and place your dry towels or other heat-resistant fabrics inside the bucket. Do not overfill.
2. **Close Lid:** Close the lid securely. The lid features a slow-close mechanism.
3. **Power On:** Press the "ON/OFF" button on the control panel to turn on the device.
4. **Set Temperature:** Press the "SETUP" button to enter temperature setting mode. Use the "+" and "-" buttons to adjust the desired temperature between 140°F and 185°F.
5. **Set Heating Time:** Press the "SETUP" button again to enter time setting mode. Use the "+" and "-" buttons to set the heating duration from 15 minutes to 12 hours.
6. **Start Heating:** The warmer will begin heating automatically after settings are confirmed or if no further input is received for a few seconds.
7. **Automatic Shut-off:** The warmer will automatically shut off once the set heating time is complete.

4.2 Delay Function (Appointment Mode):

The delay function allows you to set a future time for the warmer to start heating.

1. **Load Items and Close Lid:** Place items in the warmer and close the lid.
2. **Set Delay Time:** With the machine off, press the "DELAY" button. Use the "+" and "-" buttons to set the desired delay time (1-12 hours).
3. **Set Heating Parameters:** After setting the delay, you can then set the desired heating temperature and duration using the "SETUP" and "+/-" buttons as described in Basic Heating.
4. **Confirm:** The warmer will display the countdown for the delay. Once the delay time is over, it will automatically begin the heating cycle.
5. **Cancel Delay:** To cancel the delay mode, press the "ON/OFF" button.



Image: A visual representation of the delay timer function, illustrating how to set an appointment time for heating, from awaiting heat to

heating complete.

4.3 UV Sanitization:

The UV lamp can be activated for sanitization.

- **Activate UV:** Press the "UV" button on the control panel to turn on the UV lamp.
- **Deactivate UV:** Press the "UV" button again to turn off the UV lamp.
- **Safety Note:** The UV lamp is designed to operate with the lid closed. Avoid direct exposure to UV light.



Image: A woman placing items into the towel warmer, which has its built-in UV light active, indicating the sanitization function.

4.4 Official Product Video: How to Use DEPFALL 40L Towel Warmer

Your browser does not support the video tag.

Video: This official video from DEPFALL demonstrates the basic usage of the 40L Towel Warmer, including loading towels, using the fragrance disc holder, closing the lid, and operating the control panel for temperature and time settings. It also shows the UV lamp in action.

5. Maintenance

5.1 Cleaning:

- **Unplug:** Always unplug the appliance from the power outlet before cleaning.
- **Exterior:** Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Interior:** The smooth interior can be wiped clean with a damp cloth. Ensure the interior is completely dry before next use.
- **Fragrance Disc Holder:** Remove the fragrance disc holder and clean it as needed. Replace the fragrance disc regularly for optimal scent.

5.2 Storage:

When not in use, store the towel warmer in a cool, dry place. Ensure it is unplugged and clean before storing.

6. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; power button not pressed.	Ensure the power cord is securely plugged into a working outlet. Press the "ON/OFF" button.
Towels are not warm enough or unevenly heated.	Insufficient heating time; temperature set too low; too many items loaded; items are too thick.	Increase heating time (e.g., to 1 hour for thicker items). Increase temperature setting. Reduce the number of items. Ensure items are loosely placed for better air circulation.
Display shows an error code or behaves erratically.	Temporary electronic glitch.	Unplug the unit, wait 5 minutes, then plug it back in and try again. If the issue persists, contact customer support.
UV lamp not working.	UV button not pressed; lid not fully closed.	Ensure the "UV" button is pressed and the lid is completely closed for the safety mechanism to engage.
No fragrance.	Fragrance disc is dry or missing.	Add essential oil to the fragrance disc or replace the disc.

7. Specifications

- **Model Number:** IZDUAULY
- **Capacity:** 40 Liters (approx. 35L usable volume)
- **Product Dimensions:** 22 x 17.5 x 15.1 inches (55.9 x 44.5 x 38.4 cm)
- **Item Weight:** 17.41 pounds (7.9 kg)
- **Voltage:** 100-120V
- **Max Power:** 600W
- **Heating Temperature Range:** 140°F - 185°F (60°C - 85°C)
- **Max Internal Temperature:** Up to 235°F (113°C)
- **Timer Settings:** 15 minutes - 12 hours
- **Delay Timer:** 1 - 12 hours
- **Noise Level:** 56.5 dB
- **Power Cord Length:** 5.9 feet (1.8 meters)
- **Certifications:** EPA, CE

8. Warranty and Support

DEPFALL products are manufactured with high-quality materials and undergo strict quality control. For warranty information, technical support, or any questions regarding your DEPFALL 40L Towel Warmer Bucket, please refer to the warranty card included with your purchase or contact DEPFALL customer service through the retailer where the product was purchased.

Please have your model number (IZDUAULY) and purchase date ready when contacting support.

© 2024 DEPFALL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CHJB3CYH

More documents and user manuals: **https://manuals.plus/**